1. External Photograph of EUT

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

2. Photograph of Accessory

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

Specification of Accessory		
Battery	**Brand Name**	Zebra
	Model Name	BT000296A01
USB Cable	**Brand Name**	Zebra
	Model Name	HS3100-CHUC1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100