



PRODUCT COMPONENTS

Main Body Diagram (Front)



INSTRUCTIONS

5.Manual



- 1.Time remaining
- 2.Position adjust
- 3.Mechanism/airbag/heat/roller position
- 4.Return
- 5.Heating switch
- 6.Roller massage position selection area
- 7.Setting
- 8.Off
- 9.Pause
- 10.Mechanism speed adjust
- 11.4D strength adjust
- 12.Airbag intensity adjust
- 13.Massage technique selection
- 14.Massage width adjust (it do not works once the kneading start)



- 1.Massage area option
- 2.Mechanism position adjust


INSTRUCTIONS



There are 22 kinds of all-round unique automatic massage mode.

PRODUCT COMPONENTS

Main Body Diagram (Back)



CHAIR INSTALLATION

1. Installation steps

The screws and fittings used during installation are shown below:



No.1 screw



No.2 screw



No.3 screw




No.4 screw



Buckle

1. Remove the back cover

- (1) Twist the four screws on the back cover, remove the back cover, and place the back cover and screws aside.





2. Installation side plate

- (1) Take out the side board from the packaging box, unscrew the two screws in the specified position of the side plate, then remove the decorative parts on the side plate, and place the decorative parts on the side plate aside.
- (2) Connect the bronchus, terminals, and heating lines on the side board with the docking on the main body.
- (3) Hang the installation rice on the side plate to the iron frame corresponding to the main body. Put the side board into the head cover, enhance the gold, fixed rice gold 1. Fixed rice gold 2 card on the outside of the side plate and lock four No. 2 screws.
- (4) Lock the No. 1 screw and No. 3 screw at the specified position of the side plate.
- (5) Connect the wire beam on the side plate with the coating.
- (6) Finally, the disassembled side plate on the side panel is put on the side plate. After the card is entered, pay attention to check whether the gap is uniform, and lock two No. 4 screws at the specified location.
- (7) Install the other side board on the same step.


INSTRUCTIONS

3. Detection



1. Latest body scanning technique.
2. When the shoulder position is being tested, click the "X" button in the upper right corner, and the shoulder position detection will be stopped immediately, and the shoulder position is based on the default shoulder position to start massage.
3. Within 8 seconds after scanning user can do minor adjustment to the shoulder position or press OK to confirm.

4. Auto



- | | | |
|-----------------------|--|---|
| 1. Time remaining | 2. Auto program name | 3. Mechanism speed adjust |
| 4. Position adjust | 5. Mechanism/airbag/heat/roller position | 8. Roller massage position selection area |
| 6. Return | 7. Heating switch | 11. Off |
| 9. 4D strength adjust | 10. Setting | 12. Pause |
| | 13. Auto modes selection | 14. Airbag intensity adjust area |