





Wireless Touch Keyboard

USER MANUAL | GUIDE DE L'UTILISATEUR



WIRELESS TOUCH KEYBOARD
CLAVIER TACTILE SANS FIL


KEYBOARD BUTTONS



- | | | |
|--------------------|----------------------------------|----------------------------------|
| 1 ⚙ Setting | 7 🔊 Volume up | 13 🔴 LED indicator (Low Battery) |
| 2 🔍 Search | 8 🔇 Mute | 14 🖱 Touchpad |
| 3 ⏮ Previous track | 9 🖱 Right mouse button | 15 📦 Battery Cover |
| 4 ⏸ Play/Pause | 10 🖱 Left mouse button | |
| 5 ⏭ Next track | 11 1 LED indicator (Number Lock) | |
| 6 🔊 Volume down | 12 🔴 LED indicator (Caps Lock) | |

SETUP YOUR WIRELESS KEYBOARD

- Step 1: Open the battery compartment on the bottom of the keyboard, then insert batteries
- Step 2: Insert the batteries as shown inside the battery storage
- Step 3: Replace the battery cover




- Step 4: Insert the Nano Receiver into your computer
- Step 5: Turn on your power switch of keyboard
- Step 6: Your Wireless Keyboard is ready to use



SETUP THE CONNECTION BETWEEN THE WIRELESS KEYBOARD AND COMPUTER

If your wireless keyboard has not been connected to your computer after completing the previous steps, the following information will help you to complete the connection.

- Step 1: Make sure the computer is switched on
- Step 2: Press the CONNECT BUTTON on the underside of your keyboard
- Step 3: The LED will flash 10 seconds to indicate the keyboard is pairing with the nano receiver on the computer
- Step 4: Your keyboard will connect automatically
- Step 5: If the keyboard does not work after 10 seconds, repeat above connection procedure again (The receiver has auto pairing function)
- Step 6: When the keyboard battery is low, the low power indicator will start to blink



TOUCHPAD GESTURES

1. Point: Point and slide one finger anywhere on the touchpad to move the screen pointer
2. Scroll: Scroll with two fingers, up or down.



3. Left Click: Tap twice with one finger



4. Right Click: Tap twice with 3 fingers



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.