



Bluetooth Speaker

- 1x Disc Jockey Speaker
- 1x USB-C cable
- 1x User Manual
- 1x Disc Golf Bag Strap

Diagram of the back of the device showing the USB Type-C Charging Port and Reset Hole. The diagram includes the following labels:

- Volume-/Previous song
- Play/Pause/Phone call
- Volume+/Next song
- Power on/off
- USB Type-C Charging Port
- Reset Hole (below cover)

"UDisc" and all related names, logos, product and service names, designs and slogans are trademarks of the UDisc, LLC

2

5

LED Indicator	Battery Status
Flash Red	Low battery (<10%)
Solid Red	Charging
Red Off	Full charged

Answer an incoming call Click 

Reject an incoming call Press & Hold 

End the current call Click 

Redial last-called number Press & Hold

4

5

E



8



9

IC Statemnet

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L' appareil ne doit pas produire de brouillage;
- (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.