Gardyn ®

STUDIO

Grow Guide

Welcome to the Gardyn family!

Get ready to discover the joy of growing your own food.

From seed to harvest and beyond, we've got you covered with comprehensive resources, essential accessories, and, of course, Kelby. We are thrilled you're here and can't wait to see your progress!

Inside this guide you'll find tips on:

Let's get Gardyning!

Meet Your Gardyn Studio

1. Light protective cap
2. Safety straps
3. Camera
4. LED light bar
5. Main switch
6. Light switch
7. Lower blade
8. Water pump
9. Upper blade
10. Rod connector
11. Metal rod
12. Columns
13. Lid
14. Wood cap to watering compartment
15. Lid locks
16. Water tank

Reminder: *Do not plug the device in until instructed to do so.*

STEP 1

Unpacking

Carefully unpack the parts following the order in the video.

LED light bar

Lid with wood cap

Metal rod, upper blade, metal plates, plugs, & plant food spoon

Water tank

2 columns

Power supply

16 yPods

Mount & lock the lid

1 **Remove the tape** and open the lid locks to mount the lid onto the water tank, then close the lid locks.

REAR

LID FRONT

FRONT

Unlock / Lock

2 **Remove the cardboard** and lower the water pump.

The cardboard's appearance may vary slightly from the one shown.

Pump in upper position

Pump in lower position

Assemble & connect the columns

1 **Gently pull on the end** of the irrigation hoses to ensure they are straight inside the columns and avoid any kinks.


2 **Align the arrows, then twist.**
When completed, the arrows will no longer align.

3 **Hold the column vertically** and plug the hose connector onto the tube inside the column's base until snug.

4 **Twist the column** to secure. When completed, the arrows will no longer align.

**5** **Ensure all open slots face the front of the lid,** as shown.

STEP 4

Attach light bar & upper blade

1 **Insert the metal rod** onto the back of the columns, then slide the metal plates into each column and insert plugs to secure.

2 **Hold the light vertically** so that the camera is near the top. Carefully yet firmly slide the bottom of the light onto the lower blade attached to the lid.

Push until you see the grey post in the notch of the light bar.

3 **Remove** the camera's protective film.

4 **Attach the upper blade** to the light bar, then clip it onto the metal rod.

5 **Ensure the upper blad**e is fully clipped onto the metal rod.

Check progress

At this stage, you should see the following:

○ **The camera's** protective film is removed.

○ **The 2 columns** have all slots facing the light and all vine designs aligned.

○ **The LED light bar** is mounted and the light protective cap is flush with the top of the light bar.

○ **The metal rod** is connected to the upper blade and columns by 2 metal plates and plugs.

○ **The water pump** is lowered into the tank and the cardboard is removed.

○ **The lid locks** are pushed against the sides of the water tank in the locked position.

Safety straps

WARNING:
Prevent the device from tipping over. The device must be securely attached to the wall. Use the safety straps provided with the product and the appropriate hardware to affix to your wall type. Never let children hang onto the lights or columns. Never let children climb on the device.

Screw directly into a wood stud when available.

In the absence of a stud, use the appropriate anchor and screw for your wall type.

If you've completed each of these steps, you're ready to secure your device to the wall using the safety straps.

Fill tank & turn on

Fill the tank with 3 gallons of tap water. Later, the app will let you know when and how much water to add.

DO NOT ADD PLANT FOOD when you start your Gardyn. The app will help you learn when it's time to start feeding your plants later on.

[O] OFF

[I] ON

The device is turned ON/OFF by flipping the main switch located on the back of the water tank.

Make sure the main switch is in the OFF [O] position before plugging in or unplugging the device to the power supply. Once the device is plugged in, turn it on by flipping the main switch to the **ON [I] position.**

The main switch will illuminate and your light bar will blink once it is fully powered up.

Install your plants

Watch Video

1 **If you haven't already,** open and unpack the box containing the 16 yPods.

2 **Insert 1 yPod** into each of the open slots on both columns. To insert, twist each yPod until it sits flush with the column.

yPod

Tip *Check out our placement guide to find your plants' ideal spots based on your starter kit!*

Placement Guide

3 **Time to plant!** Place the yCubes into the yPods. yCubes are correctly inserted when they sit flush with the yPod.

yCube

No slot should be left open.
Use Gardyn Caps and skip the yPod to close spots without plants.

Shop Gardyn Caps

4 **Remove** the cardboard covers on every yCube you plant.

Tip *Only see one layer of yCubes in the box? Lift the packaging to find all 16!*

Tip *16 plants or fewer to start?*
The choice is yours! If you plant fewer than 16, be sure to cover open slots with Gardyn Caps, available in the app.