
J5(联想LP40)产品说明书 尺寸: 50x70mm 材质: 80g书写纸 双面印刷 风琴折

联想 thinkplus LivePods LP40 真无线蓝牙耳机



使用说明书 使用前请阅读使用说明书

产品规格

喇叭直径: φ13mm

表克风类型, 硅咪

喇叭功率, 20mW*2

频率响应: 20Hz-20KHz

耳机电池容量: 35mAh

充电仓电池容量: 230mAh

(所有技术信息以实际性能为准)

信噪比. ≥70DB

播放时长,约4小时

失真度: ≤5%

蓝牙耳机 ×2

充电线 x 1

充电盒 x 1

说明书 × 1

表克风灵敏度, -32dB±3dB

阴抗: 32Ω

- 蓝牙版本, V5.0 传输距离。≥10m
 - (2)请勿将产品放入水或其他任何液体中,此产品非防水设计。

产品使用简介

- **移开此产品**。
- (5) 请勿将此产品放置干热源附近或直接暴露在火源附近。
- 产品故障。

产品操作说明

1.开机

方式一: 将左右耳机从充电仓中取出即可开机。

方式一: 用手指长触耳机多功能触摸键3S后, 耳机关机。

注: 当耳机从充电盒中取出,5分钟未与相应蓝牙设备进行配对 连接,便会自动关机;超出信号10-12M信号距离,蓝牙无连接 状态5分钟后,耳机自动关机。

3.TWS配对(左右耳机彼此配对)

- (1)除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更 换产品 内的任何零件。
- (3) 加里有任何游休不小小讲 \ 产品内时 请立即断开连接并
- (4)为避免触电,请在安装或卸载产品时,确保手上没有沾水。
- (6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致

方式二: 用手指长触耳机多功能触摸键2S即可开机。 注, 当耳机处于充电状态下时, 不能开机。

方式一、直接将左右耳机放入充电仓即可关机。

将左右耳机同时从充电仓中取出,左右耳机即可进行TWS配对, 5秒钟左右配对成功。

注,当左右耳机开机一段时间后,如若彼此之间配对不成功,可 同时长按左右耳机达5秒钟,左右耳机关机,然后将左右耳机同 时开机,开机后,左右耳机便会自动配对。

4. 丰副耳自动切换

当左右耳机配对成功后,任意单个耳机入仓充电,便会关机,未 入仓充电耳机为主耳耳机,保持正常运行。

5.与蓝牙设备讲行配对连接

打开欲配对蓝牙设备的蓝牙设置选项,进入选项,找到耳机的蓝 牙配对名"联想thinkplus-I P40",点击配对名讲行配对。

6.播放音乐 上一曲:连续短触左耳耳机多功能触摸键三次

下一曲,连续短触右耳耳机多功能触模键三次 音量加:连续短触右耳耳机多功能触摸键两次

音量减, 连续短触左耳耳机多功能触摸键两次

暂停/播放、短触任意耳机多功能触模键一次 7.电话免提(TWS双耳机配对操作)

来电时、接听、短触任意耳机多功能触摸键一次 来电时, 拒接: 短触任意耳机多功能触摸键2秒钟 结束诵话挂断, 短触任意耳机多功能触模键一次

8. 电话免提(单耳机操作)

来电时,接听、短触耳机多功能触摸键一次

来申时、拒接、短触耳机多功能触描键2秒钟 结束诵话挂断、短触耳机多功能触摸键—次

9.激活SIRI语音助手(仅支持IOS系统用户)

激活语音助手, 短触任意耳机多功能触摸键1.5S松开,可激活 SIRI智能语音功能。

关闭语音助手, 当激活该功能后, 短触任意耳机多功能触模键 1.5S松开即可关闭SIRI语音助手功能。 10. 耳机充电

耳机放入充电仓充电时,耳机没有指示灯,充电仓的绿色灯会点 亮,表示正常为耳机充电。

11. 充电仓充电

给充电仓充电时, 充电仓指示灯呈红色灯闪亮, 充满后呈红色灯

产品中有害物质名称及含量

产品中有害物质的名称及含量

| 有害物质 | | | | | | | | |
|-------|-------|-------------|-------------------|---------------|-----------------|--|--|--|
| 铅(Pb) | 汞(Hg) | 镉(Cd) | 六价铬 (Cr(VI)) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | | | |
| | 铅(Pb) | 铅(Pb) 汞(Hg) | 铅(Pb) 汞(Hg) 锡(Cd) | | | | | |

- 本表格依据S.I/T 11364的规定编制。 ,表示该有审物所在该部件所有物质材料由的全量物在
- GB/T 26572 规定的限量要求以下。 表示该有害物质至少在该部件的某一均质材料中的含量超出
- GR/T 26572 抑完的限器更少 表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害

印刷由路板组件*,包括印刷由路板及其零部件、由子元器件等。 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件



在中华人民共和国造内销售的由子由气产品必须标识此 标志, 标志内的数字代表在正常的使用状态下的产品的 环保使用期限。

保修吉阳.

太傅田王册没有任何形式的担保 立场事法或其他赔示 太傅田王册所 提到的产品、规格及信息仅供参考,内容亦会随时更新干网页,恕不另

- 就本文件附随的产品做如下保证,如产品在您购买日起十二(12)个月 ("保修期")内,在正常使用情况下因质量瑕疵发生损坏,能修理的
- 鱼弗修理, 经厂定确认于注修理的 鱼弗面塩, 修理或面塩后的产品 左剩全保修期(最短不小于30天) 内继统言有保修 购买口以销售营 票日期为准:如无法确定购买日、则保修期自产品生产日期起按十三 (13) 个日计管
- 如申请保修、请先致电产品服务热线、并按我们指示的方式执行。 申请保修时,您需要提供准确、完整和清晰填写的有效销售发票。

1) ト保证不活田干下列情况 .超过三包有效期的:

2.涂改保修卡、产品编码与产品本体不符: 3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故

4.因不可抗力(如地震、战争、火灾等)或意外导致的故障或损

5.拉链、塔扣因受力过大而损坏:

6.因承载过重造成的脱线或撕裂;

7 任何因尘纷物体造成的损坏。 8 有核损或水湿冻免的产品。

Q 困糖白板水导致的损坏 10.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。

1.如产品原有标识标签被更改或损毁,本保证将失效。 产品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时 当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证,目仅在中国大陆地区境内适用 本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权

服务热线,400-812-0102

售后邮箱: frank@szevsan.cn

"Lenovo", "thinkplus" 是联想集团所属企业的商标,提及 的其他公司、产品和服务名称可能是其他公司的商标。 版权所有@2022 联想集团所属企业和其许可方保留所有权利。

FCC 声明

根据FCC规则第15部分,本设备经过测试,符合B类数字设备的限制。 这些限制旨在提供会理的住宅设施由的有害干扰防护 该设备产生使用 并可辐射射频能量,如果未按照规定安装和使用该指示可能会对无线电 诵信造成有害干扰。然而,有不能保证在特定安装中不会发生干扰。如 里这个设备有对无线由或由加接收造成有宝干折。可通过转动来确定设 备、关闭和打开时、鼓励用户尝试通过一个或多个以下更多措施。

- 重新完向武重新完价接收于线
- 増加设备和接收器之间的间距
- 设备连接到与接收器不同的电路上的插座已连接。
- 请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分。操作受以下两个条件限制条件。

(1)本装置不得引起有害干扰。 (2) 本装置必须接受任何接收到的干扰、包括可能导致意外操作的干

扰。未经合规责任方明确批准的变更或修改可能使用用户对设备的操作 权限失效。

FCC ID: 2A8SE-22090001

Lenovo thinkplus LivePods LP40



USER MANUAL Please read all instructions carefully and retain for future use

Product specifications

BT Version - V5.0 Transmission distance. ≥ Up to 10m

Driver diameter: \$ 13mm Impedance 32Ω

Mic Type: Silicon Microphone (MEMS Microphone)

Mic Sensitivity: -32dB ± 3dB Speaker Power - 20mW*2

S/N Rate: ≥70DB THD, ≤5%

Frequency Response - 20Hz-20KHz Playing time - About 4 hours

(All technical data is subject to actual performance)

Earphone battery: 35mAh Rated input: 5V==230mA Charge case battery 230mAh

Packing list

BT Famhone x 2 Charge Cable x

Charge Case x 1 Manual x 1

(1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.

(3) Disconnect the unit with your Bluetooth device and move it to the safe area if the liquid get inside the unit.

shock, if there is water on your hands. (5) Don't expose the unit to extremely high temperature or

Method 1: Bring both earphones out from the charge case.

earnhones

2. Turn Off:

earphone.

earphone will turn off automatically. Note: The earphones will turn off if it has not received a signal for approx.5 minutes.

is not a waterproof product.

(4) Don't assemble or disassemble the unit to avoid electric

(6) Don't place the unit in an electromagnetic interference

1 Turn On:

the earnhones will turn on automatically Method 2: Press and hold on the MF button 2s to turn on the

Note: When the earphone is under charging, it can not be turned on

(2) Don't expose the unit to liquid, moisture or humidity, since it

dispose of the unit in fire as it will result in an explosion.

environment to avoid malfunction

Method 1: Press and hold on the MF button 3s to turn off the times to increase the volume Decrease Volume: Short press the MF button of left Earpod 2 Method 2: Put the earphone back into the charge case, the times to decrease the volume

> Pause/Play: Short press the MF button of one Earpod will resume the music

The earphones will turn off if the distance is exceeds 10-12M 7 Hands free function (two earbuds paired) and no signal received within approx. 5 minutes.

to answer an incoming call. 3. TWS Pairing (R & L earphones TWS Pairing) Bring both earphones out from the charge case, the earphones will automatically turn on and pair with each other successfully

Note: If R & L earphones do not pair successfully after turn on for a while, press and hold on the MF button on both earphones 5s to turn off the earnhones. Then turn on both earnhones again

they will pair with each other automatically. 4.Two earbuds automatic switch:

After left and right earbuds paired, any one earbuds put in the charging case.it will turn off. The earbud not put in charging case, still work normally.

5.Connect with BT: Turn on the device of BT and find "联想thinkplus-LP40" to pair.

6.Playing music Previous track: Short press the MF button of left Earpod 3 times will return you to the previous track

Next track: Short press the MF button of right Earpod 3 times 10. Charging earbuds will take you to the next track Increase Volume - Short press the ME button of right Earnord 2

Answer incoming call: Short press the MF button of any Earpod

Reject Incoming Call: Press the MF button of any Earpod for 2 seconds and release End call: After your phone conversation, Short press the MF

button of any Earpod. 8. Handsfree function (Single earbud)

Answer incoming call . Short press the MF button of any Earpod to answer an incoming call. Reject Incoming Call: Press the MF button of any Earpool for 2 seconds and release

End call: After your phone conversation, Short press the MF button of any Earpod. 9.Active SIRI voice assistant:(Only support IOS system)

Activate voice assistant - touch the Multi function button for 1.5s to turn on. Turn off voice assistant: after activate the voice function, short press button for 1.5S to turn off.

Charge the charging case it flashs red light. After full charge.

11. Charge the charging case

the red light is always on.

when earbuds put in the charging case, No indicator light, The charging case with green light, that shows normal charging.

People's Republic of China must mark this Logo

Name and content of hazardous substances in products

| | Harmful materials | | | | | | | |
|--------------------------------------|-------------------|----|----|--------|-----|------|--|--|
| Part Name | Pb | Hg | Cd | Cr(VI) | PBB | PBDE | | |
| Printed circuit assembly | 0 | 0 | 0 | 0 | 0 | 0 | | |
| Small structural parts such as | 0 | 0 | 0 | 0 | 0 | 0 | | |

This form is compiled in accordance with SJ/T 11364. . Indicates that the content of the hazardous bstance in all homogeneous materials of the part is in elow the limit requirements specified in GB/T 26572. × : Indicates that the content of the hazardous ibstance in at least one of the homogeneous materials of

number in the logo represents the produc

der normal use Environmental protection use

he nart exceeds he limit requirements specified in GB/T 26572. The parts marked with "X" on the form are all harmful due to he limitations of global technological development. Substitution of substances

rinted circuit board components*: including printed circuit poards and their parts, electronic components, etc. irchased may not contain all the above components Electronic and electrical products sold in the

vebpage at any time, without additional line notification.

quality defects damaged, can be repaired free; if the manufacturer confirms that it cannot be renaired, free replacement: repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation If you apply for a warranty please call the product service. hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

2. Alteration of the warranty card and product code does not match the product body; 3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storageimpaired or

> 4. Failure or damage caused by force majeure (such as earthquake war fire etc.) or accident had: 5. The zipper and buckle are damaged due to excessive force;

his user manual does not have any form of guarantee position expression or other implication. he mentioned products, specifications and information are or reference only, and the content will also be undated on the

Varranty statement: The product attached to this document is guaranteed as ollows: If the product is twelve (12) months from the date of

"Warranty Period"), under normal conditions of use due to he above guarantee does not apply to the following situations . The validity period of the three packs is exceeded:

Mentioned other trademarks, company names, products or services'name may be a trademark of affiliated enterprises of Lenovo Group or another company.

Disconnection or tearing caused by excessive load: Any damage caused by sharp objects:

. Products with signs of burning or water immersion; Damage caused by unauthorized disassembly;

 Aging, discoloration, abrasion, rupture and other losses 1. If the original identification label of the product is changed or damaged, this guarantee will become invalid. he completeness and appearance of the product and accompanying materials are not within the scope of the

any discrepancies. The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China Nothing in this document affects consumer rights that cannot

quarantee. You should Check on the spot and raise objections to

be excluded or restricted under the law profit. Service supervision hotline: 400-812-0102 After-sales service Emal: frank@szevsan.cr

"Lenovo" , "thinkolus" belongs to affiliated enterprises

Copyright © 2022 Lenovo Group and its licensors. All rights

FCC Statement

limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

This equipment has been tested and found to comply with the

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected -- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ECC ID: 2A8SE-22090001