



## 802.11be-EHT160 - Ant 0 (Nss = 2)


Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)



Channel 207 (6985MHz)




## 802.11be-EHT320 - Ant 0 (Nss = 2)


## Channel 63 (6265MHz)



## Channel 127 (6585MHz)




## Channel 191 (6905MHz)




## 802.11ax-HE20 - Ant 1 (Nss = 2)


## Channel 33 (6115MHz)




## Channel 61 (6255MHz)




## Channel 93 (6415MHz)




## Channel 97 (6435MHz)




## Channel 105 (6475MHz)




## Channel 113 (6515MHz)



## Channel 117 (6535MHz)




## Channel 149 (6695MHz)




## 802.11ax-HE20 - Ant 1 (Nss = 2)


## Channel 181 (6855MHz)




## Channel 185 (6875MHz)




## Channel 189 (6895MHz)



## Channel 213 (7015MHz)




## Channel 229 (7095MHz)




## 802.11ax-HE40 - Ant 1 (Nss = 2)


## Channel 35 (6125MHz)




## Channel 59 (6245MHz)




## Channel 91 (6405MHz)




## Channel 99 (6445MHz)




## Channel 107 (6485MHz)




## Channel 115 (6525MHz)



## Channel 123 (6565MHz)




## Channel 147 (6685MHz)




## 802.11ax-HE40 - Ant 1 (Nss = 2)


## Channel 179 (6845MHz)




## Channel 187 (6885MHz)




## Channel 195 (6925MHz)



## Channel 211 (7005MHz)




## Channel 227 (7085MHz)




## 802.11ax-HE80 - Ant 1 (Nss = 2)


## Channel 39 (6145MHz)




## Channel 55 (6225MHz)




## Channel 87 (6385MHz)




## Channel 103 (6465MHz)




## Channel 119 (6545MHz)




## Channel 135 (6625MHz)



## Channel 151 (6705MHz)




## Channel 167 (6785MHz)




## 802.11ax-HE80 - Ant 1 (Nss = 2)


## Channel 183 (6865MHz)



## Channel 199 (6945MHz)




## Channel 215 (7025MHz)




## 802.11ax-HE160 - Ant 1 (Nss = 2)


## Channel 47 (6185MHz)




## Channel 79 (6345MHz)




## Channel 111 (6505MHz)




## Channel 143 (6665MHz)



## Channel 175 (6825MHz)




## Channel 207 (6985MHz)




## 802.11be-EHT20 - Ant 1 (Nss = 2)


## Channel 33 (6115MHz)




## Channel 61 (6255MHz)




## Channel 93 (6415MHz)




## Channel 97 (6435MHz)




## Channel 105 (6475MHz)




## Channel 113 (6515MHz)



## Channel 117 (6535MHz)




## Channel 149 (6695MHz)




## 802.11be-EHT20 - Ant 1 (Nss = 2)


## Channel 181 (6855MHz)




## Channel 185 (6875MHz)




## Channel 189 (6895MHz)



## Channel 213 (7015MHz)




## Channel 229 (7095MHz)




## 802.11be-EHT40 - Ant 1 (Nss = 2)


## Channel 35 (6125MHz)




## Channel 59 (6245MHz)




## Channel 91 (6405MHz)




## Channel 99 (6445MHz)




## Channel 107 (6485MHz)




## Channel 115 (6525MHz)



## Channel 123 (6565MHz)




## Channel 147 (6685MHz)




## 802.11be-EHT40 - Ant 1 (Nss = 2)


## Channel 179 (6845MHz)




## Channel 187 (6885MHz)



## Channel 195 (6925MHz)



## Channel 211 (7005MHz)



## Channel 227 (7085MHz)

