


BC82
Alarm Console
Product Label



QR
Should direct to:
vkda.co/s/XXXX-XXXX-XXXX
—
XXXX-XXXX-XXXX should be
replaced with serial number.

QYY
Q represents quarter, each
quarter can be represented
by character "A, B, C, D".
(For example, fourth quarter
of 2021 should be "D21".)

