




CONSTRUCTION PHOTOS OF EUT



Left Earbud



Brand: SENNHEISER, Model: CX400TW1 L


Black color















Right Earbud


Brand: SENNHEISER, Model: CX400TW1 R
Black color








Earbud (main battery cell)








Charging Case

Brand: SENNHEISER, Model: CX400TW1 C

Black color









Charging case (Main battery cell)



Charging Case
Brand: SENNHEISER, Model: CX400TW1 C
White color
Charging case (alternative battery cell)





Earbud (alternative battery cell)



