


Koogeek
QUICK START GUIDE

L3
Smart Fingerprint Lock

QUICK START GUIDE

1. When received the lock, use your fingerprint to activate and open it.
Note: At this point, any fingerprint can be used to unlock.
2. Insert the reset pin into the reset hole and hold for 2 seconds, the green LED will be always on, then loose the reset pin and the lock is already for fingerprint entry mode. Every time you enter a fingerprint, the green LED flashes once. To record more fingerprints, please repeat the above operations.

Note: It is recommended to cover the whole fingerprint area with your finger when registering. As shown below:



3. Download and open the Koogeek Home app from the App Store.
4. Log in or sign up for a Koogeek account or simply tap Skip.
5. Open the Bluetooth on your phone.
6. Tap “+” on the top right corner and follow the on-screen directions to complete the scan or manually enter into the setup code.



7. Click the “Koogeek-L3-XXXXXX” in the accessory list and pair. XXXXXX are the last 6 characters of MAC on your Smart Fingerprint Lock.
Note: Each accessory has an identification code, e.g., Koogeek-L3-XXXXXX. Make sure the last 6 characters of the identification code are consistent with the last 6 characters of MAC sticker in the packing box. You can find the MAC sticker in the packing box. To add more smart fingerprint locks (or repeat the Smart Fingerprint lock setup process), please repeat the above operations.
8. You can add the device to the Home and Room. Please keep the setup code for future use.
9. You can assign a name to your Smart Fingerprint Lock and use this name when speaking to Siri. For example, you can name your Smart Fingerprint Lock “Bedroom door lock”, then launch Siri and speak “Open the bedroom door lock.”
10. For trouble shooting visit www.koogeek.com

The use of a HomeKit-enabled accessory need the follow permission:


Settings > iCloud > iCloud Drive > Turn On

Settings > iCloud > Keychain > Turn on

Settings > Privacy > HomeKit > Koogeek Home > Turn On

Note: The keychain function is defined by Apple Company, and only activate keychain, can HomeKit accessory be connected to your phone.


Overview



Restore Factory Settings

Insert the metal pin into the reset hole and hold for 5 seconds, the green LED will flash slowly, and then loose the pin, the LED flashes 3 times slowly to indicate that the product has been restored to factory settings.

Note: Please execute the operation only when the lock is open.



Delete Fingerprint Information

Insert the metal pin into the reset hole and hold for 8 seconds, the green LED will flash quickly, and then loose the pin, the LED will be on for 1 second, then goes out to indicate that the fingerprint information has been deleted.

Note: Please execute the operation only when the lock is open.



Specifications

LED indicator color: Green

Battery capacity: 280 mAh

Charging port: Micro-USB port

Battery type: Lithium polymer battery

Battery model: BYT 552325

Wireless connection: Bluetooth smart technology

Tips:

1. When the lock was locked or opened successfully, the green LED will flash once to indicate that the operation has been done.
2. Up to 50 fingerprints can be stored in one lock.
3. Run for up to 1 year after being charged for 2 hours.
4. Support checking battery level on the Koogeek Home App or Apple Home app.
5. With a Micro-USB charging port.
6. Two options to open the lock: 1) Fingerprint, 2) Koogeek Home app or Apple Home app.
7. You can remotely check whether the lock was locked or not wherever you are.
8. Support checking the last 100 lock / unlock records.
9. The standby time of the product is 1 year.
10. Please charge the product before the first use.
11. Input wrong fingerprints 6 times in a row, the product will lock up. Please wait for 60 seconds, then use the right fingerprint to unlock.

Customer Service



12-month limited warranty



Lifetime technical support

Customer Service

12-month limited warranty

Lifetime technical support

Safety Warnings:

Do not disassemble

Do not clean with liquid
Do not use in wet or damp areas
Cannot be used in the rain

Legal

Use of the Works with Apple HomeKit logo means that an electronic accessory has been designed to connect specifically to iPod touch, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Controlling this HomeKit-enabled accessory automatically and away from home requires an Apple TV with tvOS 10.1 or later or an iPad set up as a home hub.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.