

标记	处数	分区	更改	日期

[illegible]

57gsm
128g双面铜版纸

01. Inside Box

If anything is missing, please contact the supplier.

02. Product Description

Turn On/Off:

- (1) Press Power Button Ⓜ for 1.5 seconds to turn on the printer.
- (2) To turn it off, please press the Power ButtonⓂ for 1.5 Seconds.

Feed:

- (1) Label paper: Press Feed ButtonⓂ to feed the tape to the proper place and get ready for printing next tape.
- (2) Continuous paper: Press Feed ButtonⓂ to keep paper feeding. It will stop when you let go of the button.

System Status Menu:

- (1) Press Power ButtonⓂ for 1 second to switch to the setting interface.
- (2) Press Feed ButtonⓂ for 1 second, scroll option list and select by pressing Power Button.
- (3) Press Power Button Ⓜ for 1.5 seconds to go back to the main page.

Restore factory settings:

Press the power key to enter the menu option, select restore factory settings, and then press the paper feed key to complete "restore factory settings".

03. Screen Information

Logo guidance

Bluetooth Ⓜ connects to Bluetooth, this logo will light up. This logo will flash when the data is transferring.

Setting/Transfer Ⓜ

When you are using USB wire, this logo will be shown as Ⓜ If you press Power Button for a short time, it will be switched to Setting Mode, the logo will be shown as Setting ModeⓂ.

Cover OpeningⓂ

It indicates that the paper cover is opened or not closed correctly. A message will appear, stating that the paper cover is opened.

Paper ConditionⓂ

If the paper roll is not installed correctly, or there is insufficient paper, this logo will light up. A message will appear, stating that there is no paper. When the paper is detected, it will give you a confirmation so that you are able to proceed.

Print Condition Ⓜ

This light will write the printer is printing or feeding.

External ElectricityⓂ

It will light up when the printer is connected to a power source.

Charging Battery Ⓜ

Please charge your printer when the power display begins to flash.

Text Area

This area shows related text information.

Screen setting

Options	Parameter
Language	English, Chinese
Print concentration	1% (lightest), 2, 4, 6, 8, 10, 15, 20, 30, 40, 50, 60, 70, 80, 90, 100 (darkest)
Print speed	10 (slowest), 20 (normal), 30 (fast), 40 (faster), 50 (fastest)
Paper type	Uncoated paper, continuous paper, Black and white label
Automatic shutdown	5min, 15min, 30min, 1h, 2h, 4h, 8h, 24h, No shutdown
Restore settings	Restores to factory default settings.
Firmware version	Displays Firmware version
Device address	Displays device address

Screen hint

Content	Condition
Shutdown	Battery lower than 1%
Printing	Printing regularly
Feeding	Press Feed button
Overheated, please wait	Print head is overheated
No paper detected	No paper in the bin or paper is installed incorrectly
Cover opened	The paper cover is opened

04. Device Parameters

Hardware	Parameters
Name	Mini-Function (later print)
Model	M110
Print technology	Dye Ink Thermal
Maximum print width	203mm
Type of tape	Thermoplastic film, Thermoplastic continuous paper
Label size	80mm (label size with 4 hole corner)
Print speed	30 Sheets continuously/min, Max 5
Print concentration	adjustable level 1~15
Resolution	200 dpi
Life of print head	500K
Connection type	Bluetooth® 4.2
USB cable	USB Type-C
Battery	Rechargeable
Power case	1.7 x 4.8 x 2.5in.
Weight	550g/2A
Power supply mode	Micro USB
Operating system	iOS/Android
Supported OS	iOS/Android
Printer size	170 mm (height) x 210 mm (width)
Operating temperature	0°C - 30°C
Storage temperature	-10°C ~ 40°C
Relative humidity	20% - 80%
Storage humidity	5% - 95%(No condensation)

Operating Information

- Minimum set: 10°C
- Maximum set: 30°C
- Operating temperature: 0°C - 30°C
- Storage temperature: -10°C ~ 40°C
- Relative humidity: 20% - 80%
- Storage humidity: 5% - 95%(No condensation)

05. Search Phomemo-M110 on App Store or Google Play to Get the App

06. Installing the Paper Roll

Press the "Open" button gently to open the paper bin.

Take out the adjustable plate and remove the left panel.

— 01 —
— 02 —
— 03 —
— 04 —
— 05 —
— 06 —

除非另有说明，否则公差按下表：				Phomemo M110说明书							
尺寸标注	CLASS A	CLASS B	CLASS C								
<6.0	±0.1	±1	±2								
6.0~30.0	±0.1	±1	±2								
30~	±0.1	±1	±2								
120~400	±0.1	±1	±2	型号		材料	128g双铜版纸	表面	不覆膜		
400~1000	±0.1	±1	±2	番号	30400300089	颜色		用量	1张		
设计	陈颖心2019-11-19			文件位置							
审核	江民辉2019-11-19			版本	A0	比例	1 : 1 1	单位	mm	图幅	
核准	王名湛2019-11-20							第 1 张 共 1 张			