


Download the soundcore app to adjust EQ settings, experience Gaming Mode, customize touch controls, update firmware, and explore more features.

If your earbuds cannot connect with the soundcore app, try re-installing the app or updating it to the latest version available in your mobile app store.


Download the app via http://dl-soundcore.soundcore.com/qcdl?flow=soundcore

OVERVIEW



- 1. Adjustable Ear Hook
- 2. Touch Area
- 3. Charging Contactors
- 4. Sound Outlet
- 5. LED Light Strip
- 6. USB-C Charging Port
- 7. Charging Case Button

POWERING ON & PAIRING




1. Open the charging case. The earbuds will automatically power on and enter Bluetooth pairing mode.



2. Select **"soundcore AeroFit 2"** on your device's Bluetooth list to connect. During pairing, the LED light strip on the charging case will start flashing. Once the pairing is successful, the LED light strip will stay on for 1 second before turning off.

DUAL CONNECTIONS

To connect your earbuds with two Bluetooth devices at the same time, there are two methods:




Method 1: Manually Pair with the Second Device

While wearing the earbuds, press and hold the touch control areas on both earbuds for 3 seconds until you hear a sound prompt for pairing mode. You can then proceed to pair with the second device.

 \mathcal{Q} If your earbuds have been connected to two devices, remove at least one before pairing with a new device.


Method 2: Use the soundcore App




In the soundcore app, tap the cogwheel icon in the upper right corner to access **Settings**. Then select **Dual Connections > Enable Dual Connections > Connect New Device**.

MANUAL PAIRING

To manually enter Bluetooth pairing mode:



1. Return the earbuds to the charging case.




2. Leave the case open, then press and hold the charging case button for 3 seconds.



3. The earbuds will enter pairing mode. Proceed to pair with your device.


WEARING



1. Pick up the earbuds and slide the ear hooks all the way to the LV4 position, which offers the largest fit.



2. Rotate the ear hooks along your outer ear for proper positioning.




3. After putting on the earbuds, you can slide the ear hooks back and forth between four levels until you find the most comfortable and secure fit.

Ear Hook Position Guide



SOUND EFFECTS



In the soundcore app, the default sound effect is "soundcore Signature", a special preset recommended by the soundcore team. We offer 22 EQ presets for different scenarios, which you can switch based on your preferences. Additionally, you can create your own sound profile by adjusting eight sliders on the "Custom Equalizer" page.

CONTROLS

		Using Dual Earbuds	Using Single Earbud	
53	Play / Pause Audio	Double tap (R)	Double tap	
	Play the Previous Track	Customize in the soundcore app	- /	
	Play the Next Track	Double tap (L)		
C	Answer a Call	Double tap (L/R)	Double tap	
	Reject a Call / End a Call	Tap and hold for 2 seconds (L/R)	Tap and hold for 2 seconds	
∢ »)+	Increase Volume		Customize in the soundcore app	
◄ »)—	Decrease Volume	- Customize in the soundcore app		
Ŷ	Activate Voice Assistant	Customize in the soundcore app	Customize in the soundcore app	


Customize Touch Controls on soundcore App

Note: The UI images are for illustration purposes only. Actual display contents may vary based on the software version.


nat C Controla	0	at .	a*** 0 0'	Al. Carrola	
0	2	20	3	0	0
	91	AeroFit 2			•
(Andre				Single Tap 🕤	
, Sightle		Sound Effect		Walater*	2
Denille Tag		, Controlle		Volume	
				Next	
Top 3 Times	5	Dur Connections		Pyrylaut	
- Top and Hold	. 6	Garring Made 🔅		Pag/Aum	
				Note:	
The same of					

Tap **Controls** on the home page to personalize touch control actions for either the left or right earbud. **You can** adjust actions such as increasing/decreasing volume, switching songs, playing/pausing audio, and activating the voice assistant.

CHARGING




- 1. Place the earbuds in the charging case and close it.
- Ensure the earbuds and the USB-C charging port are fully dry before charging.



- 2. Connect the charging case to a power supply using the provided USB-C charging cable. Alternatively, for wireless charging, place the charging box at the center of your wireless charger.
- Recharging the charging case takes 1.7 hours via cable and 2.6 hours via wireless charging.

POWERING OFF



To power off, return both earbuds to the charging case and close the case.

The earbuds will automatically power off after 30 minutes if they are not connected. The duration can be customized in the soundcore app.

How to Clean




Charging Contacts


After each use, wipe the earbuds with a soft, dry cloth and clean the charging contacts with a cotton swab to prevent charging and power-off issues caused by sweat accumulation.

RESET

Reset the earbuds if they have issues pairing with each other or with other devices.



1. Return the earbuds to the charging case and leave the case open.




2. Press and hold the charging case button for 10 seconds until the LED light strip flashes white quickly three times, indicating a successful reset.

LED LIGHT GUIDE


Checking the Battery Level

When you open the charging case, the LED light strip will indicate the remaining battery level of the case.




Checking the Charging Status

When you connect the charging case to a power source, the LED light strip will display the charging status:



FIRMWARE UPDATE



You will be notified once a new firmware version is detected when the earbuds are connected to the app. Ensure the earbuds are in the charging case and the case remains open until the firmware update is complete. Avoid using the earbuds during the update.

SPECS

Specifications are subject to change without notice.

Input	5V 1.2A	
Output	5V 0.42A (0.21A per port)	
Battery capacity	750mAh	
Charging time	Earbuds: within 1 hour Charging case: Wired charging time: 1.7 hours to fully charge the charging case, 2.2 hours to fully charge the charging case and the earbuds Wireless charging time: 2.6 hours to fully charge the charging case and the earbuds.	
Driver unit	20*11.5mm	
Frequency response	20~20kHz (20~40kHz when LDAC is enabled)	
Impedance	16Ω	
Waterproof rating (earbuds)	IP55	
Bluetooth version	5.4	

Customer Service



service@soundcore.com support.mea@soundcore.com (For Middle East and Africa Only) support@anker.com (日本)

+1 (800) 988 7973 (US/Canada) +44 (0) 1604 936200 (UK) +49 (0) 69 9579 7960 (DE) 03 4455 7823 (日本) +86 400 0550 036 (中国) +82 1666-8470 (한국) +971 8000320817 (UAE) +966 8008500030 (KSA) +965 22069086 (Kuwait) +20 800000826 (Egypt) +61 3 8331 4800 (Australia) +90 (850) 460 14 14 (Türkiye) +8 (800) 511-86-23 (Russia) 000-8000-504-414 (India)

Variable 'x'	Range of variable	Content	
Eighth	8,9,A,B,C	Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.	
Ninth and tenth	01,02,03	Denotes weeks, 01 means the first week i this year, 02 means the secondary week ir this year, and so on.	
Eleventh	1-7	Denotes date, 1 means Monday, 2 means Tuesday, 7 means Sunday and so on.	
The last five	00001-99999	Denotes serial No.	

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023. For the Statement of Compliance, visit the website: https://uk.soundcore.com/pages/psti-related.