


FIGO
be cool, be figo

Fury Pro
W282




QUICK START GUIDE GUÍA RÁPIDA

1. BEFORE POWERING ON, CHARGE FOR 24 HOURS/ANTES DE ENCENDER, CARGUE POR 24 HORAS



2. INSERT SIM CARD/INSERTE LA TARJETA SIM



P. 1

3. GPRS SETTING/
CONFIGURACIÓN GPRS


GPRS
MENU>SETTINGS>CONNECTIONS>
NETWORK ACCOUNT>OPTIONS>NEW
ACCOUNT

RENAME>ACCESS POINT>USER
NAME>PASSWORD>GATEWAY PORT>
AUTH TYPE>SET HOMEPAGE>
ADVANCED SETTINGS

MENU>AJUSTES>CONEXION>CUENTA
DE RED>OPCIONES>CUENTA NUEVA

RENOMBRAR>PUNTO DE ACCESO>
NOMBRE DE USUARIO>CONTRASEÑA>
PUERTO DE COMUNICACIÓN>PUERTO>
TIPO DE AUTH>ESTABLECE LA PÁGINA
DE INICIO>COMUNICACIÓN AVANZADA

4 FM RADIO/RADIO FM




PLUG IN HEADSET (NOT INCLUDED)
CONECTE LOS AURICULARES
(NO INCLUIDO)

P. 2

5. AUDIO PLAYER/
REPRODUCTOR DE AUDIO

1. INSERT THE MICRO SD CARD/
INSERTE LA TARJETA DE MEMORIA


2. CONNECT THE PHONE WITH THE
COMPUTER VIA USB CABLE/
CONECTE EL TELÉFONO CON LA
COMPUTADORA VÍA CABLE USB



P. 3

CONTINUE/CONTINUAR

3. COPY AND TRANSFER MUSIC FILES/
COPIAR Y TRANSFERIR ARCHIVOS DE
MÚSICA



4. ENJOY THE AUDIO PLAYER/
DISFRUTE DEL REPRODUCTOR DE
AUDIO

P. 4


FIGO
be cool, be figo

Fury Pro
W282




GUIA RÁPIDO GUIDE RAPIDE

1. ANTES DE LIGAR, CARREGUE POR
24 HORAS/AVANT LA MISE SOUS
TENSION, CHARGE PENDANT 24
HEURES



2. INSIRA O CARTÃO SIM/
INSERER LA CARTE SIM



P. 1

3. CONFIGURAÇÃO GPRS/
CONFIGURATION GPRS

GPRS
MENU>CONFIGURAÇÕES>CONEXÃO>
CONTA DA REDE>OPÇÕES>CONTA
NOVA

RENOMEAR>PONTO DE ACESSO>NOME DO
USUÁRIO>SENHA>PORTA DE
COMUNICAÇÃO>PORTA>TIPO DE AUTH>
ESTABELECEER PÁGINA INICIAL>
CONFIGURAÇÕES AVANÇADAS

MENU>PARAMÈTRES>CONNEXION>
COMPTE RÉSEAU>OPTIONS>
NOUVEAU COMPTE

RENOMMER>POINT D'ACCÈS>NOM
D'UTILISATEUR>MOT DE PASSE>PORT
DE COMMUNICATION>PORT>TYPE
D'AUTHENTICATION>ÉTABLIR PAGE
D'ACCUEIL>COMMUNICATION AVANCÉE

4. RADIO FM




CONECTE O FONE DE OUVIDO NÃO
INCLUIDO/BRANCHEZ CASQUE
(NON FOURNI)


P. 2

5. REPRODUCTOR DE ÁUDIO/
LECTEUR DE AUDIO

1. INSIRA O CARTÃO MICRO SIM/
INSERER LA CARTE MICRO SIM




2. CONECTE O TELEFONE COM O
COMPUTADOR VIA O CABO USB/
CONNECTER LE TÉLÉPHONE A
L'ORDINATEUR VIA UN CÂBLE USB



P. 3

CONTINUAR /CONTINUER

3. COPIAR E TRANSFERIR ARQUIVOS
DE MÚSICA/ COPIER ET TRANSFÉRER
DES FICHIERS MUSICAUX



4. APROVEITE O REPRODUCTOR DE
AUDIO/PROFITER DU LECTEUR DE
AUDIO

P. 4

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 0.5 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.