




Wireless Security Camera System

ASSURE B1



USER MANUAL

Please read this manual carefully before use and keep it for future reference.



The latest version of multilingual user manuals could be obtained by scanning the QR code or visiting <https://www.heimvision.com/pages/download/>, since we update the user manual regularly. Please contact us if you have any problems.

Safety Cautions

- 1 For security, please use the original accessories provided.
- 2 Unplug the power adapter if you don't use the products.
- 3 Please obey the local security regulations and policies when installing the products.
- 4 We assume no liability or responsibility for any fires or electrical shock caused by improper installation.

What's Included




HeimVision Camera
x1




HeimVision Base Station
x1




Mounting Bracket
x1




Adapter
x1



Charging Cable
x2




Ethernet Cable
x1




Screw Kit
x1

Product Overview

HeimVision Base Station



HeimVision Camera



A guide to LED Indicator

Base Station

Working Indicator	Solid white	Watching live video/Camera wakes up
	Off	Camera in sleep mode
Network Indicator	Solid green	Base Station connected to network
	Off	Base Station disconnected to network
	Flash green	Base Station upgrading
Power Indicator	Solid white	Base Station powered on
	Off	Base Station has no power

Camera

Working Indicator	Solid blue	Working normally
	Off	In sleep mode/disconnected
	Flash blue	Firmware upgrading
Power Indicator	Solid green	Charging
	Off	Fully charged
	Flash green	No battery installed and powered by charging cable
Low Battery Indicator	Solid red	Low battery
	Off	Normal

Getting Connected

- 1 Search for **HeimSmart** on App Store™/Google Play™ or scan the QR codes below to download and install our App.



iOS




Android

Note:

Google Play™ is a trademark of Google Inc., and App Store™ is a trademark of Apple Inc.

- 2 Plug the **Ethernet cable** into the Base Station and router, then connect the Base Station to power.




- 3 Power on the camera.

Option 1:

Install 4 AA batteries into your camera to power it on. Please observe the correct polarity when inserting each battery.

(not included)




Notes:


- ① We recommend to use your camera at $-20^{\circ}\text{C}\sim 50^{\circ}\text{C}$ ($-4^{\circ}\text{F}\sim 122^{\circ}\text{F}$).
- ② If the **Battery Indicator** turns red, it means that the battery power of camera gets low. Please charge or replace the batteries in time.
- ③ Do NOT mix old and new batteries or different brands of batteries.
- ④ DO NOT charge the camera through the **Micro USB Port** if your battery is non-rechargeable.

Option 2:

Connect a 5V 2A adapter to the camera's **Micro USB Port** to power it on.

**Option 3:**

Install 4 AA rechargeable batteries, then connect a solar panel to the camera's **Micro USB Port** to supply power for it.




- ④ Launch **HeimSmart** app, register an account with a valid email and log in. Then follow the steps below to connect your Base Station and camera to **HeimSmart**.

Notes:

- ① Please allow HeimSmart app to use your WLAN & Cellular Data and access your location.
- ② Make sure your phone and the Base Station are connected to the same router's network. Otherwise, the HeimSmart app will not be able to find the Base Station.
- ③ If your phone and the Base Station are connected to the same router's network, but HeimSmart still cannot find the Base Station, please long press the **Pair/Reset** button for 10s to reset the Base Station.

Step 1:

Tap **+** on the **Devices** interface.

**Step 2:**

Select **Base Station**.



Step 3:

Ensure the base station is connected to your router, and tap **Next**.

**Step 4:**

Ensure the base station is powered on, and tap **Next**.

**Step 5:**

Connect your mobile phone to the same router's network as the base station, and tap **Next**.

**Step 6:**

Wait for HeimSmart to discover your base station.




Tip:

If HeimSmart cannot discover your base station, please

- * ensure that you've connected the Base Station to the router through the Ethernet cable.
- * ensure that your mobile phone and the base station are connected to the same network.
- * long press the **Pair/Reset** button to reset the base station and try again.

Step 7:

Select your base station after it's discovered.

**Step 8:**

Keep the camera as near as possible to the base station (within 1m/3.3ft) when pairing them, and tap **Next**.

**Step 9:**

Pair the camera with the base station.

- ① Ensure the camera is powered on.
- ② Press the **Pair/Reset** button on the camera three times, and you will hear "Pairing Mode".
- ③ Press the **Pair/Reset** button on the base station three times, and you will hear Di sound from it.
- ④ Wait until you hear "**Pairing successful**" from the camera, and then tap **Next**.



Step 10:

Wait for pairing.



Step 11:

Return to the homepage after finishing pairing.



- 5 One Base Station could pair with up to four cameras. If you have bought more than one camera, please follow the steps below to get your second/third/fourth camera paired with the base station. (Optional)

Step 1:

Tap **+** on the upper right corner of the **Devices** interface.




Step 2:

Select **Cam B1**.



Step 3:

Select your base station.



Step 4:

Keep the camera as near as possible to the base station (within 1m/3.3ft) when pairing them, and tap **Next**.



Step 5:

Pair the camera with the base station.

- ① Ensure the camera is powered on.
- ② Press the **Pair/Reset** button on the camera three times, and you will hear "Pairing Mode".
- ③ Press the **Pair/Reset** button on the base station three times, and you will hear Di sound from it.
- ④ Wait until you hear "**Pairing successful**" from the camera, and then tap **Next**.

**Step 6:**

Wait for pairing.

**Step 7:**

Return to the homepage after finishing pairing.

