
尺寸: 70X100mm 材质: 105g双铜纸

工艺: 风琴折页 单黑印刷



For more details, please consult online customer service.

封面



Notice Please read this user manual carefully before use.

Safety Tips

For the best viewing effect, please use the projector in dark room. Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor

- 2. Ensure that the environment is ventilated to prevent overheat caused
- Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine. If foreign objects fall into the machine accidentally, please power off immediately and seek professional
- 4. Do not place any liquid on the machine to avoid leakage.
- 5. Avoid violent vibrations when transporting. Please protect the lens
- 6. Do not touch the vents when using the projector to avoid burns due 7. Do not look directly at the lens while the projector is running to
- 8. Please clean the filter regularly to prevent malfunction caused by

Notice \land

Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.

Warn 🛕

Do not touch! The inside of the projector contains uninsulated

Warn \land

Do not install the projector around flammable objects to prevent

Safety Tips



To ensure the performance and stability of the projector. please place it horizontally and leave a space of about 30cm between the projector and the wall.



Do not install in places with poor ventilation.



Do not install in dust or Do not block the vents. smoky places.

Do not install in high

temperature or humid places.

Specifications

Item		Specification
Product		HM400Pro
Native Resolution		1280X720
Projection Technology		LCD Display
Lamp Type		LED Lamp
Interface	HD	HD IN*1
	USB	USB 2.0 * 1
	Earphone	3.5mm audio port
Environment		
Power Input		AC 110-240V 50~60HZ
Operating Temperature		0 ~ 30°C
Storage Temperature		-20 ~ 65°C
Operating Humidity		0 ~ 90% Non-condensing

1 Package Contents








Power cord Remote control

Remote Control Introduction



| (5) (3) Mouse Mode Navigation key • Menu Return •-VOI - •

Mute

Using the device

1 Network & Internet

This projector can connect to the Internet through Wi-Fi.

- * On the home page, select "Setting" to go to the "Network & Internet", make sure that Wi-Fi is turned on.
- Select your Wi-Fi network name when it appears in the list.
 Complete the connection process by following on-screen prompts.

2 Bluetooth


How do I connect a speaker to my projector?


- * Turn on the Bluetooth feature on your projector and the speaker. * On the home page, select "Setting" to go to the "Bluetooth", make sure
- * Search for available devices on your projector's setting menu and select
- * Complete the pairing process by following on-screen prompts.

Screen Adjustment

1 Adjust the focus(Sharpness adjustment)

After the machine is placed horizontally, turn the focusingring up and down to make the picture clearer.





Q&A

1 Unable to Boot Up

* Check if the power cord is connected properly, and if the power light is on.Try to unplug and plug the power if the projector still can not

2 Remote Controller is Insensitive or Unresponsive

- * Do not cover IR receiver.
- * In the infrared mode, make sure remote points at IR receiver directly.
- * There is an obstacle between the remote control and the projector.
- * The batteries are out of power or the battery is not installed correctly * Pair the Bluetooth remote control and make sure is working within 5

3 Why is there no display when I connect HD port?

*Check if the interface is securely connected.

- 4 Blurry Display
- * The projection lens is not correctly focused.
- * The environment is too bright.


5 Screen Freeze

* Please reboot the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again

* If you have any questions or suggestions, please contact our

Maintenance Suggestion





To make this projector work longer, we recommend you to follow the

- 1.Before cleaning the projector, turn off the projector, then turn off the main power and unplug it from the outlet.
- 2.Clean the filter regularly every month to prevent clogging.
- 3. Make sure to close the projector off once you finished using it. 4.Make sure not to use it continuously for more than 6 hours.
 - F© (€ RoHS 🌣 🗵

Warranty Card

Client Name: _____ Client ID: ____ Client Phone Number: ____ Purchase shop: _ Return Address: ___

Fault description:

(For quick repair, please describe the problem in details.)

This device couplies with part 15 of the PCC Rodes. Operation is subject to the following two conditions: (1) This device may not cross herraful interference, and (2) this device must ascept any interference received, including interference that may arose mile and operation.

7.HD Port

10.AC Port

12.Bracket

9.Vent

8.3.5mm Audio Port

11.Focusing ring

Any Changes or modifications not expressly approved by the purty expossible for coupliness could read the user's notherty to openie the equipment.

Note: This equipment has been tested and found to compily with the limits for a Class B. digital device, parsonn to part 15 of the FCC Rules. These limits are designed to posside ressonable protection agricut Santolid interference in a residential incollation. This epigenest generates uses and concoding todo frequency energy and, if not motified and used in accombace with the instructions, may come bareful interference to radio communication. However, there is no guarantee that interference will not some as a particular installation. If this equipment does came horaful interference to under or television recognism, which can be determined by turning the egospoint off and on, the user is assuminged to try to correct the interference by one or more of the following measures:

-Reprient or relocate the receiving streams.

Projector Introduction

1.Projection Lens

3.Bracket

5.Power On

6.USB Port

2.IR Remote Sensor

4.IR Remote Senso

-lacterise the separation between the equipment and receives -Counce the equipment into an order on a circuit different from that we which the

received is assessed.

«County the dealer or an experienced ratio TV technicism for help. «This egyptome complies with PCC radiation exposure limits set forth for an incretsified environment. This agripment should be incolled and opened with minimum distance 20cm between the collector & your body.