




	PP0	PP1	PP2	PP3	PP4	PP5	PP6	PP7	PP8	PP9	PP10	PP11	PP12	PP13	PP14	PP15	P23	P26
DB0	110	17	46	6	12	115	14	79	8	37		MINI JPN1	[F8]	VOL -	MUTE	STOP	VEDIO	
DB1	112	18	47	21	13	116	75	83	9	38		MINI JPN2		NEXT/ FWARD	MENU	[CLY] MIN	EJECT	
DB2	113	19	48	35	15	117	76	84	10	39		MINI JPN3		VOL +	[43]	EMAIL		
DB3	114	20	49	50	27	118	90	89	11	40		MINI JPN4		PREV/ RMIND	[57]	MM		
DB4	1	2	31	7	28	119	29	45	23	43		80	[34]	PLAY/ PAUSE	GAME	CALC	30	
DB5	16	3	32	22	41	121	124	56	24	52		85		[60]	REC	TV		
DB6	61	4	33	36	42	122	125	107	25	54		86	ACPI SLEEP	[62]				
DB7	53	5	34	51	120	123	126	APP	26	55		81		131	132	133	[63] MIN	

NOTE : MINI KEYBOARD ACK500/595/590 JAPAN MODE
JPN1,JPN2,JPN3,JPN4 -- 4 SPECIAL KEYS

JPN1	JPN2	JPN3	JPN4
FN ON	80 HOME	85 PsUp	86 PsDn
FN OFF	79 <—	83 ^	84 v
			89 —>

KISS	
Title	ACK-600H/600HM MATRIX SCHEMATICS
Size	Document Number
A	ACK600H.SCH
Date:	October 19, 1999 Sheet 2 of 2
REV	1
2	