



Front



Back



The EUT is placed at the center of turntable