

OHP-610说明书: 100g铜版纸, 无膜, 4C+1专印刷, 折页 成品尺寸: 85*120mm

Internal Use (内部公开)

PACKAGE CONTENTS

Wireless Headset x 1
Volume Cable x 1
Type-C Charging Cable x 1
1.5m AUX Cable x 1

PRODUCT OVERVIEW

- Button + (Volume Up / Last Track)
- Button O (Play/Pause/Call)
- Button - (Volume Down / Next Track)
- Power Switch
- Microphone
- 3.5mm AUX Input
- LED Indicator
- Type-C Charging Port

USING YOUR HEADSET

1. Power on / off
Toggle the power switch to power on/off.

LED Indicator	Status
Steady blue for 1 second with voice prompt saying "System on"	Power on
Steady red for 1 second with voice prompt saying "System off"	Power off

2. Pair with your device
The headset will enter pairing mode automatically. Open the Bluetooth function and connect the Bluetooth named as Oaimo BoomPop25 on your device to finish the pair.

LED Indicator	Status
Fast-flashing blue with voice prompt saying "Pairing"	Enter pairing mode
Steady blue with voice prompt saying "Connected"	Connected to a device

3. How to connect to another device
1) Disconnect the Bluetooth connection with the last device.
2) Enter the pairing mode to achieve the connection again.
3) Make sure the distance of the headset and your device is less than 1 meter / 3.3 feet at the first time of connection.
4) The headset will automatically connect to the last connected device if available. If not, the headset will enter pairing mode.

4. Connected via AUX
1) The speaker will enter AUX mode once the cable is plugged in. (AUX will be banned when using AUX mode)

5. Charge your Headset

LED Indicator	Status
Lightly flashing red with voice prompt	Low battery
Steady flashing red	Being recharged
Light off	Fully recharged

1) Use the attached Type-C cable to charge the headset.
2) The headset will automatically power off when being charging.

6. Control by gestures
1. Place your hand from the back and touch the right headset directly to confirm its position.
2. Move your hand slightly to the right and about 1 cm away to start the gesture controls by Oaimo as below picture.

7. Control by gestures

Gesture	Function
Play/Pause	Start/pause music
Volume up	Increase volume
Last track	Play previous track
Next track	Play next track
Power off	Turn off headset

BASIC PRODUCT SPECIFICATIONS

Bluetooth Version	V5.0
Bluetooth Range	100m
Speaker Diameter	40mm
Battery Capacity	500mAh
Charging Time	2.5 Hours
Playtime	20h in BT mode
Suggested Format	MP3, AAC, WAV, AAC, Type-C

TROUBLE SHOOTING

Problem Description	Cause	Solution
Headset not working	The battery is empty	Recharge the battery
Headset not pairing	The headset is not in pairing mode	Press the power button for 3 seconds to enter pairing mode
Headset not connecting to device	The device is not in Bluetooth mode	Turn on Bluetooth on the device

CONSIDERATE HINTS

- Do not turn up the volume to a high level constantly as this could shorten the service life of the product or impair your hearing.
- When encounter any fault during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the product or other components.
- The wireless transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

CUSTOMER SERVICE

365 DAYS WARRANTY

365 DAYS WARRANTY

WARRANTY CERTIFICATE

Name	
Address	
Tel. No.	
Date of purchase	
Store name	
Warranty period	

WELCOME GUIDE

BoomPop25 | OHP-610