
# 尺寸90\*110MM 材质: 120g铜版纸 单色印刷 折法:风琴折



#### Auto Time Setting


Under Bluetooth connection, the clock will auto-sync time according to your phone. If you want change hour format, press the " 🕒 " button.

#### NOTICE:

Because of the MAP/HFP protocol restriction, some phones did not support the auto-setting. If the clock cannot auto-correct time, please set time manually.

#### Manual Time Setting

1. Press the " () " button to set HOUR setting. Press " 📢 " or " 🍽 " button to set hour.



2. Press the " 🕒 " button to confirm and enter MINUTE setting. Press " 📢 " or " 🕨 " button to set minute.



3. Press the " 🕒 " button to confirm and enter 12/24 hour 



4. Press the " () " button to finish time setting.

#### NOTE:

When the wireless speaker is on, time cannot be set manually, only can press the "(-)" button to switch 12/24 hour format.

### Alarm On / Off

Long press the "  $\Delta$  " button to turn on/off the Alarm. If the "  $\Delta$  " icon on the display disappears, this alarm will NOT go off the next day.

#### Alarm And Ringtone Setting

1. Press the "  $\Delta$  " button to enter HOUR setting. Press " ◀ " or " 🇭 " button to set hour.





10

again that day.

NOTICE:

View		Getting Started	List of Track			
		1. Plug the adapter into a standard household outlet, you will see 88:88 on the display and the machine is ready to be set.	<b>∫</b> Nature Sounds			
			1	Sea Wave 1	7	Croak
С С С С С С С С С С С С С С С С С С С		<ul> <li>2. Pull out the insulator sheet before use. Backup battery is to preserve the time and alarm settings in case of power outage.</li> <li><b>NOTICE:</b></li> <li>1. If the display is "blank" after plugging in, please check whether the "Display Dimmer" on the back is at a high position.</li> </ul>	2	Sea Wave 2	8	Bird Chirp
			3	Music Box	9	Summer Night
			4	Rain	10	Campfire
			5	Thunderstorm	11	Wind
Alarm Setting	Time Set		6	Stream	12	Yoga Music
Volume Up	Sleep Timer	2. It is NOT a battery-powered alarm clock. The battery just preserves time and alarm settings in case of power	네비아 White Noises		Series Fan Sounds	
		outage. The screen will go blank if only use battery. Please keep plugged in.	1	Brown Noise 1	1	Fan Sounds 1
Volume Down	Music Play/Pause	Sound Selection	2	Brown Noise 2	2	Fan Sounds 2
Bluetooth Speaker	Previous Track/ +	1. Press the " 🎜 " button to switch on/off the sound mode.	3	Pink Noise	3	Fan Sounds 3
) Night Light	Next Track/ -		4	White Noise 1		
DODZE Snooze/Light Color Switch		<ol> <li>Press the "</li></ol>	5	White Noise 2		
3		4	5			

#### Wireless Speaker Pairing


1. Long Press the " **BT** " button to turn on/off t speaker. When the wireless speaker turns on, will blink for pairing.



2. Enable your phone bluetooth and select "AC2 available/paired list. After pairing successfully light on



3. Press the "  $\bigtriangleup$  " button to confirm and enter RINGTONE setting. Number P01-P08 will be shown on the display and the sound will be played accordingly to indicate the alarm ringtone (P01-Beep, P02-Piano, P03-Bird Chirp, P04-Sea Wave, P05-Stream, P06-Music Box, P07-Yoga Music, select your preferred ringtone. Press " **4+** " or " **4-** " button to select your preferred ringtone volume.



The alarm continues to ring for 1 hour with the icon flashing and the light on for 1 hour. After 1 hour the alarm and light turn off, the alarm icon stays on and the alarm will not ring

#### Alarm Pause / Snooze

- When the alarm goes off, you have two options: 1. Press any button except SNOOZE button to stop the alarm when it's ringing. Alarm will go off next day.
- . Press SNOOZE button to snooze, "  ${igsir 0}$  " icon will blink on the display. The alarm will go off again 9 mins later. If you want to cancel snooze, press "  $\Delta$  " , and the alarm 1 will not go off today.


#### Night Light Setting

- 1. Press the " 👻 " button to turn on/off the night light. 2. Press the "SNOOZE " button to select which color of the
- night light you like.

12

#### Dimmer Control of Screen Display&Night Light

The "Display Dimmer" dial and the "Light Dimmer" dial are at the back of the machine, and the adjustable brightness range is from 0 to 100%.



13

- automatically.
- OFF to turn off the timer.
- timer

#### NOTE:

Support Sleep Timer Setting 1. When the machine is on, press the "  $\Sigma$  " button If you have any issue with this clock, please contact us at repeatedly to select a sleep timer ranging from 1H, 2H, 3H, customer@kerweilai.com. We will address your issue within 4H, OFF. The led light of the selected timer will light on 24 hours. accordingly. If no operation is performed within 5S, the machine will return to the time display and start the timer 2. Press the "  $\Sigma$  " button to select the timing duration as 3. When in sleep timer mode, press the "  $\Sigma$  " key to check the remaining time. Press the " $\overline{X}$  " key again to reset the When the music is playing, the volume of the music gradually decreases until it turns off 1 minute before the off time; when the light is on, the brightness of the light gradually decreases until it turns off 1 minute before the off time 14 15

the wireless n, " <b>BT</b> " icon	<ul> <li>3. Press " ◀ " or " ▶ " button to play the previous track or next track, or press " BT " button to pause it.</li> <li>4. Press " ◀+ " or " ◀- " button or use your phone to adjust the speaker volume.</li> </ul>
-Blink	NOTICE: 1. When wireless speaker turns on, the "AC209" will automatically connect to the last phone if available. If not, "AC209" will enter pairing mode.
209" from its ly, " <b>BT</b> " will	<ol> <li>Long press " BT " button to exit the current bluetooth device connection and enter paring mode again, "BT " icon will blink.</li> <li>Place your speaker and phone no more than 15 meters (49ft) away from each other.</li> </ol>
Blink	
	7

## **FCC Requirement**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.