

Scanning Translator


Manual

Contents

English.....	1-6
Deutsch.....	7-13
Русский.....	14-20
Francais.....	21-27
Espanol.....	28-34
Portugues.....	35-40
日本.....	41-46
中文.....	47-52

Information to User

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.



Scan window

Introduction

The scanning pen is an intelligent scanning pen that integrates scanning translation, voice translation, dictionary, text excerpt, intelligent recording, favorites, and word library.

Power On/Off

Power-on method:When the device is off,press and hold the power button for 3 seconds to power on.

Shutdown method:

- ① In the power-on state,press and hold the power button for 3 seconds to display the power-off button, click the power-off button to power off.
- ② The product can be set by itself for how long the system will automatically shut down after it has not been used.

Connect Network

Click "Settings"."WIFI", select the router network, and enter the password to connect.




Main interface



Scan text operation guide:

Hold the scanning pen in hand, keep the angle between the pen and the paper surface at 70 to 90 degrees (the more vertical the scanning, the better the recognition effect),align the pen tip to the middle of the text, press down the pen tip lightly, and start scanning to the right after the light is on.The content that needs to be scanned can be translated by lifting the pen at the end.



Scan Translation


Support online and offline scanning and translation, support 12 languages for scanning and translation, Chinese, English, Japanese, German, Spanish, French, Italian, Portuguese, Russian, Korean, Cantonese and traditional Chinese vocabulary single or multi-line scanning.

Click the "Multi-line" icon to choose whether to open multi-line scanning.



- 1.After scanning, the screen will automatically display the original text and the translated text and read the original text aloud.Click the original or translated word/Chinese character to view the details.Click the“☆”icon to add to favorites for future review.
- 2. Click on the original text or translation to view the interpretation and analysis, and can also conduct oral assessment in the state of the

Internet



Voice Translation

131 languages are supported for translation in the connected state. After confirming [Language A] and [Language B], press and hold [Volume-/Translation A key] to say the sentence you want to translate.After releasing the voice key, the device will Automatically translate language A into language B; similarly, long press [Volume +/Translate B key] to speak language B, after releasing, the device will translate language B into language A.



After completing the voice translation, you can press and hold the translation record to perform operations such as [Delete/Delete All/Favorites].

Dictionary

The dictionary function covers Chinese-English dictionary, English-Chinese dictionary, English-Japanese dictionary, Chinese dictionary, idiom dictionary, Tang poetry Select any dictionary to enter different dictionaries to look up words.



Operation steps: Click [English-Chinese Dictionary], enter the word "hurry" in the query box, click query, you can find the definition, pronunciation, example sentences, etc. of "hurry", and you can also save it.




Text excerpt

This device supports text excerpts in 22 languages.

Click the language icon to select another language.




After selecting the language, align the text to excerpt sentence by sentence, and click Finish to save when finished.



Smart Recording

Click [New Recording] in the upper right corner, click the icon at the bottom of the screen to start recording.



Favorites

Favorites include scanning translation, Chinese-English dictionary, English-Chinese dictionary, English-Japanese dictionary, Chinese dictionary, idiom dictionary, word bank, voice translation and other favorites.There is a“★”icon to indicate that the content can be bookmarked and modified.After bookmarking, find the corresponding folder in the favorites to view the favorited content.

Word Bank

The vocabulary database covers primary school vocabulary,junior high school vocabulary, high school vocabulary, grade 4 vocabulary, grade 6 vocabulary, postgraduate vocabulary, IELTS vocabulary, TOEFL vocabulary, SAT vocabulary, GRE vocabulary, a total of more than 38,000 vocabulary.

Operation method: Click [Level 4 Vocabulary],select the letter A, the screen will display English words starting with A, select [abandon], you will see the pronunciation of the second word, you can also click on the collection and speaking practice.



Set Up

- 1. WLAN: Configure the WIFI network of the device.Please connect this device to the Internet first, and the effect will be better.
- 2. Brightness: Adjust the brightness of the product.
- 3. Volume: adjust the volume.
- 4. System language: You can choose the product system language.
- 5.Bluetooth:Connect to audio devices such as Bluetooth headsets and Bluetooth speakers.
- 6. Standby time: Set the automatic lock screen time.
- 7. Automatic shutdown:Set the automatic shutdown time.
- 8. Pen holding direction: You can choose left/right hand to hold the pen according to your habit
- 9. Pronunciation Ounce: Choose between British or American pronunciation.
- 10. Speech rate:select the pronunciation rate.
- 11. Version update: Check whether it is in the latest version and update.
- 12. Clear data: Clear product usage data.
- 13. System upgrade: Check if the system needs to be updated.
- 14. About this machine: Display the product model, serial number and other information.
- 15. Storage space: View storage space.
- 16. Storage path: Check the storage path.
- 17. Reset: Choose whether to reset system data.

Common Problem

·Unable to scan recognition/low

recognition rate

- ① Keep the pen and the paper at an angle of 70 to 90 degrees, the more vertical the scanning, the better the recognition effect;
- ② Make sure that the alignment line of the pen head is placed in the middle of the text, press down the pen head lightly, and move the pen to the right to scan at a constant speed after the light is on.
- ③ If the handwriting cannot be recognized, the printed text should be confirmed within the recognizable range: Font size:2-6, Fonts: Arial, bold, italics(both italics and bold), Language:Chinese, English,
- ④If the printing effect of printed text is poor, it will directly affect the recognition effect.

·How long does it take to charge?

How long will it last?

When charging, please use the standard professional charging cable of this product or the mobile phone Type-C charging cable. The charging time is 2 hours, and it can be used continuously for 3 hours after being fully charged. When the power is 100%, the standby time is 50 days when it is turned off.

·Garbled garbled screen when scanning special symbols such as"V:*?"<>|"are not supported.

Waterproof performance statement:

This product does not have a waterproof design, please do not use it in splashing water or other environments that cause the product to enter water.

Charging and battery usage precautions

- 1.Please make sure that the charging interface is clean and free of dirt before charging.
- 2.When connecting the charging cable to the charging interface, make sure that the charging cable is connected correctly.Do not forcibly connect the charging cable.
- 3. This product is not equipped with a power adapter. If consumers use a power adapter for power supply, they should purchase a power adapter that has obtained CE or FCC certification and meets the standard requirements.
- 4.If the battery has abnormal phenomena such as high temperature, discoloration, deformation, bulging, and leakage during use, charging or storage, please stop using it to avoid safety problems.
- 5. When charging, because the temperature of the battery will rise, do not put it with flammable materials to avoid fire.
- 6.It is strictly forbidden to disassemble, backlog, heat or burn the built-in battery of this product, or use sharp objects, screwdrivers, etc. to puncture or pry the battery. The above operations will cause the battery to catch fire.
- 7. To reduce the risk of electric shock to children, please charge this product under the guidance of parents or other guardians.

Warn

Do not place the device in an environment where the temperature is too low or too high (below-10℃or above 50℃) for a long time. The extreme temperature environment will cause the device to deform and shorten the service life of the device; Do not use the device during thunderstorms; Please keep the device and all away from children and pets, which may cause suffocation or other serious consequences if swallowed; Do not place the device in water.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.