

Attachment 2 : EUT Detailed Photographs

(1) EUT Photo (HL858A1-Z (DC -Jack))



(2) EUT Photo (HL858A1-Z (DC -Jack))




(3) EUT Photo (HL858A1-Z (DC -Jack))



(4) EUT Photo (HL858A1-Z (DC -Jack))




(5) EUT Photo (HL858A1-Z (DC -Jack))




(6) EUT Photo (HL858A1-Z (DC -Jack))




(7) EUT Photo (HL858A1-Z (DC -Jack))




(8) EUT Photo (HL858A1-Z (DC -Jack))




(9) EUT Photo (HL858A1-Z (DC -Jack))




(10) EUT Photo (HL858A1-Z (DC -Jack))




(11) EUT Photo (HL858A1-Z (DC -Jack))




(12) EUT Photo (HL858A1-Z (DC -Jack))




(15) EUT Photo (HL858A1-Z (DC -Jack))




(16) EUT Photo (HL858A1-Z (DC -Jack))



(17) EUT Photo (HL858A1-Z (DC -Jack))




(18) EUT Photo (HL858A1-Z (DC -Jack))




(19) EUT Photo (HL858A1-Z (DC -Jack))



(20) EUT Photo (HL858A1-Z (DC -Jack))



(21) EUT Photo (HL858A1-Z (DC -Jack))



(22) EUT Photo (HL858A1-Z (DC -Jack))



(23) EUT Photo (HL858A1-Z (DC -Jack))



(24) EUT Photo (HL858A1-Z (DC -Jack))



(25) EUT Photo (HL858A1-Z (DC -Jack))



(26) EUT Photo (HL858A1-Z (DC -Jack))



(27) EUT Photo (HL858A1-Z (micro USB))



(28) EUT Photo (HL858A1-Z (micro USB))




(29) EUT Photo (HL858A1-Z (micro USB))




(30) EUT Photo (HL858A1-Z (micro USB))




(31) EUT Photo (HL858A1-Z (micro USB))




(32) EUT Photo (HL858A1-Z (micro USB))




(33) EUT Photo (HL858A1-Z (micro USB))




(34) EUT Photo (HL858A1-Z (micro USB))




(35) EUT Photo (HL858A1-Z (micro USB))




(36) EUT Photo (HL858A1-Z (micro USB))




(37) EUT Photo (HL858A1-Z (micro USB))




(38) EUT Photo (HL858A1-Z (micro USB))




(39) EUT Photo (HL858A1-Z (micro USB))




(40) EUT Photo (HL858A1-Z (micro USB))




(41) EUT Photo (HL858A1-Z (micro USB))




(42) EUT Photo (HL858A1-Z (micro USB))




(43) EUT Photo (HL858A1-Z (micro USB))




(44) EUT Photo (HL858A1-Z (micro USB))




(45) EUT Photo (HL858A1-Z (micro USB))




(46) EUT Photo (HL858A1-Z (micro USB))




(47) EUT Photo (HL858A1-Z (micro USB))



(48) EUT Photo (HL858A1-Z (micro USB))



(49) EUT Photo (HL858A1-Z (micro USB))



(50) EUT Photo (HL858A1-Z (type C))



(51) EUT Photo (HL858A1-Z (type C))




(52) EUT Photo (HL858A1-Z (type C))




(53) EUT Photo (HL858A1-Z (type C))




(54) EUT Photo (HL858A1-Z (type C))




(55) EUT Photo (HL858A1-Z (type C))




(56) EUT Photo (HL858A1-Z (type C))




(57) EUT Photo (HL858A1-Z (type C))




(58) EUT Photo (HL858A1-Z (type C))




(59) EUT Photo (HL858A1-Z (type C))




(60) EUT Photo (HL858A1-Z (type C))




(61) EUT Photo (HL858A1-Z (type C))




(62) EUT Photo (HL858A1-Z (type C))




(63) EUT Photo (HL858A1-Z (type C))




(64) EUT Photo (HL858A1-Z (type C))




(65) EUT Photo (HL858A1-Z (type C))




(66) EUT Photo (HL858A1-Z (type C))




(67) EUT Photo (HL858A1-Z (type C))



(68) EUT Photo (HL858A1-Z (type C))




(69) EUT Photo (HL858A1-Z (type C))



(70) EUT Photo (HL858A1-Z (type C))



(71) EUT Photo (HL858A1-Z (type C))



(72) EUT Photo (HL858A1-Z (type C))

