


# User Guide

**Model No.: V19F**



Please read this manual carefully and keep it for future use.



#### Product Overview:

- Earbuds\*2 pcs(L,R)
- Ear tips\*2 pair(S,L)
- Charging Case
- Type C Charging Cable
- User Manual

- 1.Earphones LED Indicator Light
- 2.Multi-function Button ( MFB )
- 3.Charging Point
- 4.Ear tips
- 5.Charging Case LED Indicator Light
- 6.Charging port

#### Power On/Off

Open the charging case and take out the earphones,the earphones will be automatically power on.When the earphones is power on,put the earphones into the charging case and close the charging case,the earphones can be power off and charging.

#### Pairing

Open the charging case and take out the earphones,the L/R earphones will enter pairing mode automatically.Then wait a few seconds,the L/R earphones will connect with each other automatically,at the same time,wearing the earphones,you can hear the voice prompt of "pairing",then open the Bluetooth function on the phone, search device name "V19F" for connection,if connected successful you will hear voice prompt of "connected".

#### Volume Control

Triple click MFB (L) to turn volume down.

Triple click MFB (R) to turn volume up.

#### Play Music

Play/Pause Music: Short press MFB (L/R) once to play/ pause music.

Previous Track: Doubleclick MFB(L) turn to previous song

Next Track:Double click MFB(R) turn to next song

**Note:Single earphone mode can't control volume and songs**

### Calling

Answer a call: Short press MFB (L/R)

Hang up a call: Long press MFB(L/R) for 2s during a call

Reject a Call: Long press MFB(L/R) for 2s

### Activate voice assistant

Long press MFB( L/R ) for 2s to activate Siri or Google assistant,double click MFB( L/R ) will close voice assistant

### Resetting The Device

Please follow the below steps in case the earbuds don't auto pair

Step 1: Remove "PLX5" from the list of paired devices

Step 2: L/R earphones in the charging case and in charging mode,long press L/R MFB for 5s will clear the device pairing record,and the red & white LED will quick flash 3 times

Step 3: Take out both earbuds from the case,they will now auto pair with each other

### LED Indicator guide

Status	Description	Voice Prompt
Power On	White LED flash light one time	"Power On"
Power Off	Red LED flash light one time	"Power Off"
TWS During Pairing Status	Red and white lights will flash alternate	"Pairing"
TWS Pairing Successful	Red and white lights will slow flash alternate	"Pairing"
Connected With Device	N/A	"Connected"
Earphone Battery Low	The red LED flash twice on every 30 seconds	"Battery Low"
Earphone Charging	Red LED will bright all the time when the earphones are charging	N/A
Earphone Fully Charged	Red LED will light-off	N/A

### Attention Please

Fully charge before use.

Do not press any key for pairing. earphones will go to pairing mode automatically after taken out.

Put the earphones in CORRECT POSITION for charging.

- If the battery is not replaced properly, there will be explosion risk. The battery can only be replaced with the same type or equivalent type of battery. It is not recommended to replace the

battery without permission, but can be returned to the manufacturer for replacement.

- Batteries [battery packs or combination batteries] shall not be exposed to such conditions as lighting, baking, or similar overheating.

### **FCC Statement**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### **Storage & Maintenance**

When not using the earbuds, it is recommended that they are stored away in the charging case and placed in a safe, dry location, away from sources of water, light, heat, and dust. They are best stored in an airtight box or bag (not included).

If the earbuds or case is dirty, wipe it down with a clean microfiber cloth. Do not clean with water or any sort of cleaning liquid or detergent.

FCC ID:2AB9S-V19F