MINIS0

USER MANUAL 使用說明書

ELEGANT WIRELESS HEADSET CASQUE AUDIO SANS FIL سماعات لاسلكية أنيقة AURICULARES DE DIADEMA INALÁMBRICOS ELEGANTES 優雅經典頭戴藍牙耳機

使用產品前請仔細閱讀本使用說明書,並請妥善保管。 PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Product Parts Multifunctional Button Volume-/Previous LED Indicator Light TF Card Slot USB-C Charging Port Volume+/Next Mode

. Volume-/Previous . LED Indicator Light	4. Mode 6. 3.5mm Audio Port		Bluetooth	V5.4	Frequency Respons
. TF Card Slot . USB-C Charging Port	8. Mic		Pairing Name	MINISO-P16	Sensitivity
			Function	Multimedia, phone calling	Charging Port
		Function Charging In Battery Capacity Music Playback Ti Impedance	Charging Input	5V==180mA	Transmission Dista
	MA			200mAh	Charging Time
			Music Playback Time	Around 9h	Calling Time
3 - 10	X // / ///		Impedance	32Ω	Standby Time
(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c			Working ambient	0-45℃	
			Functions		
45	- 77				

Bluetooth	V5.4	Frequency Response	20Hz-20KHz
Pairing Name	MINISO-P16	Sensitivity	110±3dB
Function	Multimedia, phone calling	Charging Port	USB-C
Charging Input	5V==180mA	Transmission Distance	≤10m
Battery Capacity	200mAh	Charging Time	≤1.5h
Music Playback Time	Around 9h	Calling Time	Around 8h
Impedance	32Ω	Standby Time	Around 20h
Working ambient	0-45℃		

Product Parameters

Function	Instructions
Turn On	Press Multi-function Button for around 3 seconds, red and blue lights blink alternately
Turn Off	Press Multi-function Button for around 3 seconds, light turns off

Bluetooth	MINISO-P16, then choose to pair, blue light blinks
Low Battery	When battery is lower than 3.3V (20%), there is an audio alert every 30 seconds; when the battery is lower than 3.2V, earphones turn off automatically, blue light blinks
Previous Track	Long press volume- button for around 2 seconds to move to previous track, blue light blinks
Next Track	Long press volume+ button for around 2 seconds to move to next track, blue light blinks
Volume-	Press volume- button to turn volume down gradually, blue light blinks
Volume+	Press volume+ button to turn volume up gradually, blue light blinks
Pause	Press Multi-function Button button to pause, blue light blinks
Play	Press Multi-function Button button to play, blue light blinks
Answer Call	Press Multi-function Button button to answer the call, blue light blinks
End Call	Press Multi-function Button button to end the call, blue light blinks
Reject Call	Long press Multi-function Button button for around 3 seconds to reject the call, blue light blinks
Automatic Turning Off	If earphones not used for 5 minutes, it will turn off automatically, light turns off
Auto Connection	When turning on, the earphones automatically connect to the last connected device, 2. If the distance between the earphones and the device is more than 10 meters, if the device got back into the connection range within 5 minutes, the device will be connected automatically

Bluetooth	MINISO-P16, then choose to pair, blue light blinks	
Low Battery	When battery is lower than 3.3V (20%), there is an audio alert every 30 seconds; when the battery is lower than 3.2V, earphones turn off automatically, blue light blinks	
Previous Track	Long press volume- button for around 2 seconds to move to previous track, blue light blinks	
Next Track	Long press volume+ button for around 2 seconds to move to next track, blue light blinks	
Volume-	Press volume- button to turn volume down gradually, blue light blinks	
Volume+	Press volume+ button to turn volume up gradually, blue light blinks	
Pause	Press Multi-function Button button to pause, blue light blinks	
Play	Press Multi-function Button button to play, blue light blinks	
Answer Call	Press Multi-function Button button to answer the call, blue light blinks	
End Call	Press Multi-function Button button to end the call, blue light blinks	
Reject Call	Long press Multi-function Button button for around 3 seconds to reject the call, blue light blinks	
Automatic Turning Off	If earphones not used for 5 minutes, it will turn off automatically, light turns off	
	When turning on, the earphones automatically connect to the last connected device. 2. If the distance between the	

Support Line IN, plug 3.5mm jack, light turns off

1.Do not store or use the product in an environment where the temperature is

lower than +10 ° C or higher than 45 ° C. If the ambient temperature is too high or too low, faults may occur.

2. Please place the device and its accessories in a ventilated, cool place away

2. Please place the device and its accessories in a ventilated, cool place away from direct sunlight.
3. Control the volume and time when using the product to avoid hearing damage.
4. Do not pull or twist the product, and avoid contact with liquid and sweat.
5. Do not disassemble, hit, crush the product or throw the device into fire to avoid explosion. If the battery bulges or leaks, stop using it.
6. When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, etc.)
7. Due to the features of BT technology, the strength of the signal is related to the specific environment. If there are more overlapping wireless signals nearby, or there is strong electromagnetic interference, the signal received by the BT speaker will become weaker or even disconnected;
8. If not used for a long time, please charge the product once every three months to avoid battery over-discharge damage;
9. Stop using the equipment before deaning or maintaining the equipment. Please wipe the equipment with a clean, dry soft cloth;
10. It is recommended to use a brand manufacturer, certified charger with an

Trease when the equipment win a dean, by soft door, 10. It is recommended to use a brand manufacturer, certified charger with an output voltage of 5V to charge this product. Please avoid using fast-charging chargers with output voltages exceeding 5V to avoid excessive charging voltage damage to the product!

1.Fail to pair the wireless earphones with your cellphone.

Solution: Check if the earphones are in pairing mode, and whether the phone BT function is on. Check the list on your phone, remove the earphones from the list, follow the instructions of user manual to pair the earphones with your phone

again.

2.Cannot turn on the wireless earphones.

Solution: Check the battery to see if it is low.

3.Can the battery of the wireless earphones be replaced?

Answer: No. The lithium polymer battery in the earphones is irreplaceable.

4.The wireless earphones got disconnected with the phone within 10 meters.

Solution: BT is wireless so that it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.

5. Cannot hear audio playing when the earphones are connected to the computer

Solution: Check whether the computer's audio output is already connected to

wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.

6.Can I operate the Apps of my phone through the earphones after connecting

the wireless earphones to the phone?

Answer: Some apps may not support being operated through the earp to their settings.

Device*1 , Charging Cable*1 , User Manual*1

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference

that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



