


1. Photographs of Conducted Emissions Test Configuration

Test fixture mode
(TX)

Front view



Side view



Under table view




**Adapter mode
(WIS-FM-001)**


Front view



Side view



Under table view




Adapter mode
(WIS-SM-003)

Front view



Side view



Under table view




USB mode
(WIS-FM-001)

Front view



Side view



Under table view




USB mode
(WIS-SM-003)

Front view



Side view



Under table view




2. Photographs of Radiated Emissions Test Configuration


For radiated emissions 30MHz~1GHz

Test fixture mode
(CTX)

Front view




Rear view




For radiated emissions above 1GHz

Test fixture mode
(CTX)

Front view



Rear view



————THE END————