





VHT-20 MHz CHANNEL 9 CARRIER LEVEL

VHT-20 MHz CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHzVHT-20 MHz CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz


VHT-20 MHz CHANNEL 10 CARRIER LEVEL




VHT-20 MHz CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 11 CARRIER LEVEL






VHT-20 MHz CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 3 CARRIER LEVEL

VHT-40 MHz CHANNEL 3, SPURIOUS
30 MHz ~ 3 GHzVHT-40 MHz CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz


VHT-40 MHz CHANNEL 5 CARRIER LEVEL




VHT-40 MHz CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 6 CARRIER LEVEL






VHT-40 MHz CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz





VHT-40 MHz CHANNEL 7 CARRIER LEVEL


VHT-40 MHz CHANNEL 7, SPURIOUS
30 MHz ~ 3 GHzVHT-40 MHz CHANNEL 7, SPURIOUS
2 GHz ~ 25 GHz

VHT-40 MHz CHANNEL 9 CARRIER LEVEL




VHT-40 MHz CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHzVHT-40 MHz CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz


802.11ax-20 MHz(SU) CHANNEL 1 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 2 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 3 CARRIER LEVEL





802.11ax-20 MHz(SU) CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz



802.11ax-20 MHz(SU) CHANNEL 6 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz


802.11ax-20 MHz(SU) CHANNEL 8 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz





802.11ax-20 MHz(SU) CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 9 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz


802.11ax-20 MHz(SU) CHANNEL 10 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 11 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 3 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 5 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 6 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz





802.11ax-40 MHz(SU) CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz






802.11ax-40 MHz(SU) CHANNEL 7 CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 7, SPURIOUS
30 MHz ~ 3 GHz802.11ax-40 MHz(SU) CHANNEL 7, SPURIOUS
2 GHz ~ 25 GHz

802.11ax-40 MHz(SU) CHANNEL 9 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz802.11ax-40 MHz(SU) CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz

Aux. Antenna


802.11b CHANNEL 1 CARRIER LEVEL



802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 2 CARRIER LEVEL



802.11b CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 3 CARRIER LEVEL



802.11b CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 4 CARRIER LEVEL



802.11b CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 5 CARRIER LEVEL



802.11b CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL



802.11b CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL



802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 2 CARRIER LEVEL



802.11g CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 3 CARRIER LEVEL



802.11g CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 8 CARRIER LEVEL



802.11g CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 9 CARRIER LEVEL



802.11g CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz



802.11g CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz



802.11g CHANNEL 10 CARRIER LEVEL

