

风琴折：75mm×75mm

TWS Y60

功能操作说明



■ 产品示意图



①指示灯 ②充电指示 ③Type-C充电口
④充电触点 ⑤触控区域

■ 产品信息

·型号: Y60	·蓝牙版本: V5.3
·驱动单元: 13mm	·喇叭阻抗: 32Ω±15%
·充电仓电池容量: 300mAh	·耳机电池容量: 25mAh
·频率响应: 20 Hz ~ 20 kHz	·音乐时间: ~4.5H (最大音量)
·通话时间: ~2.5H (最大音量)	·待机时间: 10米以上
·充电时间: 2H	·待机时间: 约90天

■ 包装明细



·耳机充电仓 ·蓝牙耳机 ·Type-C充电线 ·使用说明书

■ 蓝牙配对

- 步骤一：将耳机从充电仓取出。
- 步骤二：将手机蓝牙打开。
- 步骤三：按照耳机蓝牙名Y60。
- 步骤四：点击连接，连接成功后即可使用。
- 注意：如果只有配对设备信息，耳机将在2-4S内自动回连设备；若未检测到设备，耳机将在3分钟后自动关机。**

■ 开机

- (1) 打开充电仓上盖并取出耳机，此时耳机自动开机并进入配对模式。
- (2) 耳机不在充电仓内且耳机处于开机状态，长按左右耳机3秒开机。

■ 关机

- (1) 将左右耳机放入充电仓，关闭充电仓盖子，耳机将自动关机并充电。
- (2) 在耳机连接状态下，长按任意一只耳机3秒关机。

■ 耳机操作说明

	播放/暂停	任一侧单击
播放状态	上一曲	双击左耳
	下一曲	双击右耳
	音量+	三击左耳
	音量-	三击右耳
通话状态	接听/挂断	任一侧单击
	拒接电话	任一侧长按
切音助手	唤醒语音助手	任一侧长按1.5秒

■ 使用注意事项

- ① 耳机请存放在干燥通风的环境下，避免与盐、水、火、高温接触，以免影响产品性能。
- ② 避免使用刺激性的、有机溶剂或含有这些成份的物品擦拭。
- ③ 耳机请按正确规范使用，注意使用环境对耳机的影响，为保证连接顺畅，建议手机和耳机之间的距离在10米范围内。
- ④ 如耳机有连接不上或通讯不畅等其他问题，请勿私自拆卸耳机本体及其配件否则不予保修。
- ⑤ 的开机充电，请选用标配的本款充电器或本公司指定的符合要求的充电器。
- ⑥ 为保证您正常使用耳机，请确保耳机的电量充足。

TWS Y60

Function Instructions



■ Diagrammatic Sketch




①Indicator light ②Charging status ③Type-C charging port
④Charging contacts ⑤Touch area

■ Specifications

·Model: Y60	·BT version: V5.3
·Driver unit: 13mm	·Speaker impedance: 32Ω±15%
·Charging case battery: 300mAh	·Earbud battery: 25mAh
·Frequency response: 20Hz ~ 20kHz	·Music time: ~4.5H (Maximum volume)
·Talk time: ~2.5H (Maximum volume)	·Transmission distance: 10m
·Charging time: ~2H	·Standby time: ~90 days

■ Package List



·Charging box ·Earphones ·Type-C ·User manual

■ Bluetooth pairing

- Step 1: Take the earphones out of the charging bin.
- Step 2: Turn on Bluetooth.
- Step 3: Find the headset bluetooth name Y60.
- Step 4: Click Connect, voice reminder after successful connection.
- Notice: If there is pairing device information, the headset will automatically connect to the device within 2-4S. If the headset is not connected to the device, the headset will automatically turn off after 5 seconds of standby.**

■ Turn On

- (1) Open the top cover of the charging compartment and take out the headset. At this time, the headset automatically starts and matches, waiting for the connection of the mobile phone.
- (2) The headset is not in the charging bin and the headset is off, long press the left and right headphones for 5 seconds to turn on.

■ Turn Off

- (1) Put the left and right earphones into the charging bin, close the top cover of the charging bin, and the earphones will automatically shut down and charge.

- (2) While the headset is connected, press and hold either headset for 5 seconds to shut it off.

■ Operation of earphone

	Play/Pause	Single tap
Playing State	Previous track	Double click left
	Next track	Double click right
	Volume+	Triple tap left
	Volume-	Triple tap right
Call state	Answer/End a phone call	Single tap
	Reject a phone call	Long press
In Use	Activate voice assistant	Tap and hold for 1.5 seconds

■ Precautions for use

- ① Headphones should be stored in a dry and ventilated environment to avoid contact with oil, water vapor and steam in order to avoid affecting product performance.
- ② Avoid cleaning with irritating, organic solvents or materials containing these ingredients.
- ③ The headset should be used according to the correct specification requirements, and pay attention to the influence of the using environment on the headset. To ensure smooth connection, it is recommended that the distance between the mobile phone and the earphone be within 10 meters.
- ④ If the earphone fails to connect or communicate properly, do not remove the earphone without permission. The machine body and its accessories are not guaranteed otherwise.
- ⑤ To charge the earphone, please use the standard ear charger or the one specified by our company. Chargers required.
- ⑥ To ensure normal use of the earphone, ensure that the power of the earphone is sufficient.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.