



TT-HFB-PN

10x Bluetooth Earbuds User Manual

Manuel utilisateur · Manual de usuario

English

Introduction

Thank you for purchasing ToughTested® Procomm 10x Bluetooth Earbuds, model number TT-HFB-PN.

ToughTested audio products are made to go to work. Ergonomic design combined with state-of-the-industry materials and specifications bring you an audio collection that looks and performs like no other. With noise control technology and exclusive, proprietary features, ToughTested earbuds are engineered and certified to help reduce environmental noise while providing clear, precise audio for music and calls.

Table of contents

- Safety information
- Package contents
- Location of controls
- Changing ear tips
- Charging the Procomm earbuds
- Pairing the Procomm earbuds
- Playing music on your Procomm earbuds
- Managing phone calls on your Procomm earbuds
- Switching to Speaker mode on your Procomm earbuds
- Earbud organization and storage
- Protecting your ears in noisy environments
- Specifications
- Care and Maintenance
- Warranty

Safety information

Please read this user's manual carefully and follow all instructions.

In particular, please heed the following cautions:

- Do not turn up the volume to an excessively high level. Extended exposure to high-decibel sounds may cause permanent hearing loss.
- Do not turn up the volume so high that you can't hear what's around you or respond to potentially hazardous situations.
- Do not use earbuds while driving or cycling, which could hinder traffic safety.
- Do not immerse earbuds in water.
- Do not pull on the cords to remove the ear tips from your ears. Instead, gently remove the ear tips with your fingers.
- Do not expose earbuds to extreme heat or direct sunlight for extended periods.

Package contents

Procomm 10x Bluetooth Earbuds
Flexfoam™ secure fit ear tips (small and medium)
Triple flange ear tips (small and medium)
Micro USB charging cable
User manual

2

Location of controls



3

Changing ear tips

The Procomm 10x Bluetooth Earbuds come with Flexfoam™ ear tips and triple flange ear tips, two sizes of each. Flexfoam ear tips provide maximum noise reduction, while triple flange ear tips provide an accurate and secure fit inside the ear.

To change the ear tips:

1. Gently twist the old ear tip until it comes off the earbuds.
2. Place the ear tip's cylindrical opening on the earbud's driver stem.
3. Gently twist the ear tip downward into place until it fully covers the driver stem.

Note: Do not yank the ear tips off the earbuds. This may damage your earbuds.

Charging the Procomm 10x Bluetooth Earbuds

The Procomm 10x battery lasts for approximately 15 hours of talk time or 22 hours of play time per charge.

1. Connect the small end of the micro USB charging cable to the micro USB port on the earbuds.
2. Connect the large end of the micro USB charging cable to the USB charging port on an AC charger, wall outlet, or laptop. The LED indicator will remain RED during the charging process.
3. Disconnect the cable from the earbuds and the charging port once charging is complete. The earbuds take approximately 1 hour to fully recharge.

Note: Select devices support a battery readout meter feature, which shows the remaining battery life of the Bluetooth-connected device. Check your device's user guide to see if this feature is supported.

Note: A voice prompt will say "battery low" when the battery is dying.

Pairing the Procomm Bluetooth Earbuds

Pairing the Procomm 10x to a device

The Procomm Bluetooth Earbuds connect to Bluetooth-enabled devices with version 4.1.

In order to pair the earbuds to your device, follow the directions below:

1. Press and hold the power button to turn the earbuds ON. A voice will say "power on" and the earbuds will enter pairing mode. The LED indicator will alternately flash blue and red.
2. Set your device to search for Bluetooth devices.
3. Open the Bluetooth feature on your device. Consult your device's user guide for more information.
4. Select "ProComm 10x" from the list of devices in the populated list.
5. If asked, enter the password "0000."
6. A voice prompt will say "your headset is connected" when pairing is complete.

Connecting to multiple devices

These earbuds have a multi-connection feature, which connects the earbuds to two devices simultaneously. In order to activate this feature, follow these steps:

1. While paired to your first device, press and hold the volume up and volume down buttons simultaneously for 5 seconds to disconnect from your first device. The voice prompt will say, "Pairing. Your headset is disconnected."
2. The LED indicator will alternately flash blue and red, which indicates that the earbuds are in pairing mode again.
3. Follow the directions in "Pairing the ProComm 10x to a device" to pair to the second device.
4. Use your first device to connect the earbud again without disconnecting from the second device.

Note: In multi-connection mode, the earbuds will receive calls from one device and audio from the other.

Playing music on your Procomm 10x Bluetooth Earbuds

Play/pause music

Short press the power button to begin playing music.

Short press the power button to pause the music.

Short press the power button again to resume playback.

6

Adjusting volume

Short press the volume up button to increase the volume.

Short press the volume down button to decrease the volume.

Note: Volume can also be controlled directly from the connected device.

Navigating a playlist

Long press the volume up button to skip to the next song.

Long press the volume down button to return to the last song.

Managing phone calls on your Procomm Bluetooth Earbuds

To accept a phone call

Short press the power button to accept an incoming phone call. A voice prompt will say "call answered" when the call is answered. The earbuds will vibrate to signal an incoming call.

To end a phone call

Short press the power button to end the call. A voice prompt will say "call terminated" when the call ends.

To reject an incoming phone call

Long press the power button to reject an incoming phone call. A voice prompt will say "call rejected" when the call is rejected.

To accept a second incoming call

Short press the power button to accept a second incoming call.

Note: your first call will automatically be placed on hold once you accept a second incoming call.

To reject a second incoming call

Press and hold the power button for approximately 2 seconds to reject a second incoming call.

To switch between phone calls

Long-press the power button to switch between the two active phone calls.

Toggling between earbuds and speaker

The speaker mode on the earbuds also acts as a speakerphone. Short press the earbud/speaker toggle button in order to switch from earbuds to speakerphone and back again.

Note: The accepted call will be heard through the earbuds' current mode.

Using your earbuds with voice-activated search and dial

The Procomm earbuds can access voice-activated search and dial functions such as Siri on Apple products.

Double-press the power button in order to activate the device's digital personal assistant.

Double-press the power button to end the session.

Speaker mode

The Procomm 10x has speakers built into the right and left neckband. To switch from headphone mode to speaker mode, short-press the earbud/speaker toggle button. Current audio will immediately route to the speakers.

Short-press the earbud/speaker toggle button to return to headphone mode.

Earbud organization and storage

The earbuds are equipped with magnets that organize the ear tips.

The magnetic ear tips connect in two ways:

1. At the base of the neckband
2. To each other

Note: Metallic materials may be attracted to the headset. Do not place credit cards or magnetic storage media near the headset because information stored on them may be erased.

Protecting your ears in noisy environments

The Procomm 10x has an EPA noise-reduction rating of 23dB. It's important to note that this number is a benchmark guideline. Because each person's ears are unique in shape and hearing sensitivity, the actual amount of noise reduction experienced with the earbuds varies from person to person.

The Procomm 10x comes with two sizes of Flexfoam ear tips, which are particularly effective at blocking ambient noise because they expand to fit snugly in the ear canal.

For more information on hearing safety, visit:

www.tough-tested.com

www.hearingconservation.com

www.cdc.gov/niosh/topics/noise

www.dangerousdecibels.org

Specifications

Driver: 9.2mm (earbuds); 18mm (speaker)

Frequency response: 20Hz-20kHz

Impedance: $16\Omega \pm 15\%$ at 1kHz

Sensitivity: $105 \pm 5\text{dB}$ at 1kHz 1mW

Distortion THD: 1.5% at 1kHz 1mW

Maximum input power: 0.01W(EARBUDS); 0.8W(SPEAKER)

Care and Maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all accessories and enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits. If your device gets wet, allow it to dry completely.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronics components can be damaged.
- Do not store the device in hot areas. High temperature can shorten the life of the electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.

All of the above suggestions apply equally to your device, battery, charger, or any enhancement.

Warranty

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

-*“Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

-*“Note: This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, used and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication.”

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Note: Ear tips are replacement parts and are not included in the product warranty. To find out how to order replacements, visit www.tough-tested.com.

Thank you for purchasing a ToughTested® product from Mizco International, Inc.

We want you to enjoy this product without any problems. However, in the unlikely event that it malfunctions, we will either repair or replace it as part of the product's limited warranty.

At the first sign of trouble and before returning the product, we encourage you to call the ToughTested® toll-free customer support line for assistance at 1 (800) 266-4026.

If the product has malfunctioned during normal use, the responsibility of ToughTested® is limited solely to the repair or replacement, at its option, of the product. This

warranty does not extend to damage or failure that results from misuse, neglect, accidents, alteration, abuse, or improper installation or maintenance.

All brands represented herein are registered trademarks of their respective manufacturers. Design and specifications are subject to change without notice.

Disassembling any of the fixed parts will void your warranty.

© Mizco International, Inc. All rights reserved.

All trade names are registered trademarks of the respective manufacturers listed.

Mizco International, Inc., Avenel, N.J. 07001

Tech support: 1 (800) 266-4026; techsupport@mizco.com

www.mizco.com

Importer of record:

NIKE Trading

Italy SRL

Via Boccaccio 81L

20090 Trezzano Sul Naviglio (MI)

ITALY