

Music

(Need media player support)

Music play / pause

Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first)

Track back/forward

Press the Volume "+" for 2 seconds once to skip track forward, press Volume "-" for 2 seconds once to skip track backward.

Switch Music and Call

When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ended, the music is resumed.

More features


Battery Indicator

When the earphone is connected to a device with iOS system, a battery indicator will appear at the upper right of the system, indicating battery status of the earphone.



Auto power-off

When the distance between the earphone and the mobile phone is beyond effective range, a voice prompt 'Connection lost' and earphone disconnects with the mobile phone, the earphone will power off automatically once no active for 10 minutes.



The diagram illustrates the auto power-off feature. On the left is a smartphone. On the right is a person's head wearing an earphone. A dashed line between them is labeled 'Effective range'. Above this line is a clock icon with '10min' next to it, indicating the timeout period.

Automatic connection after powering on

When the earphone and phone have been paired once, they will automatically connect when the earphone is on and Bluetooth activated on the phone.

Connection standby

After successful pairing and connection, you will hear the voice prompt "Connection successful". the earphone will be in turning on mode or standby mode automatically and the blue LED will flash twice every 5 seconds, when the earphone disconnect the phone, you will hear the voice prompt "Connection lost".

Voice dial (Need phone support.)

Press Vol+ and Vol- simultaneously, you will hear beep, and wait for phone prompt and then tell the phone to dial the name of a stored contact.

Charging

Your earphone has enough power to complete the pairing and a few calls. When battery is low, you will hear the voice prompt "Battery low". It takes 1.5 hours to fully charge the earphone. The red LED will turn on during charging. The red LED will turn off and the blue LED will turn on after being fully charged.

Note: The lifetime of the battery will be significantly reduced if your earphone is left uncharged for a long period. We recommend that you recharge your earphone at least once a month.

Clear paired list

In standby mode, press Vol- and Multifunction buttons simultaneously for about 5 seconds, LED indicator flashes blue/red 5 times quickly, then clear all paired list, the earphone will enter pairing mode automatically after power on next time.

Hard reset


In turning on mode, press and hold the Multifunction button with the charge plugged to reset the earphone and power off/you can release the charge plugged 2 seconds after mounting the charger).

canjice

**RING COLLAR
MUSIC WIRELESS HEADSET**

W2 INSTRUCTION

Product overview



The diagram shows a top-down view of the JBL Quantum 300 wireless headset. It features a black headband with a central adjustment slider (4). The earcups are on the sides, each with a microphone boom (6) and a control panel (5). The control panels include a multifunction button (3) and a volume +/- track (1). A charging port (2) is located on the side of the left earcup. A status indicator (7) is located on the side of the right earcup.

- 1. Volume + / Track forward
- 2. Multifunction button
- 3. Volume - / Track back
- 4. Charge port
- 5. Status indicator
- 6. Talking mic
- 7. Turn on / off

Basic operation

Volume control

Press the Volume "+" or "-" to turn volume up or down, you hear beep once reach the maximum or minimum volume.


Status indicator

Instruction	LED status	Voice prompts
Power on	Stays blue 1.5 seconds	Power on
Power off	Stays red 1.5 seconds	Power off
Standby	Blink blue twice every 5 seconds	/
Pairing	Flashes Red and Blue alternately	Pairing
Incoming call	Blink blue once every 3 seconds	/
Battery low	Flashes red twice every 8 seconds	Battery low
Charging	Stays on red while charging, Stays on blue after fully charged	/

Pairing

Pair one phone

1. Press and hold the Power button for about 3 seconds until LED flashes blue and red alternately, you hear "Power on" and "Pairing", now earphone is in pairing mode.
2. Activate Bluetooth on your phone and set it to search for new devices.




The diagram illustrates the pairing process. On the left, a hand is shown pressing the power button on the earphone. On the right, a smartphone screen displays the Bluetooth settings menu, with the 'Search' button highlighted at the bottom. The earphone is shown with a blue and red LED light flashing, indicating it is in pairing mode.

3. Select "W2". If your phone asks, enter 0000 (four zeros) for the passcode or accept the connection. The LED indicator stops flashing red and blue once successfully paired, you hear "Connection successful". Some phone list an option to "Play through earphone", select to use the earphones.

Pair another phone

Multipoint technology enables you to pair another phone and take a call from either.

To pair with another mobile phone, follow the steps for "Pair one phone". After pairing successfully, restart the earphone to connect to 2 paired mobile phone automatically.



Call

Answer a call

Press any button (Multifunction/Vol+ / Vol-) once.

Reject a call

Press and hold the Multifunction button for about 2 seconds.

End a call

Press the Multifunction button once.

Redial the last call

Double-press the Multifunction button in standby mode. The mobile phone will redial the last call number.

Mute on/off

Press the Volume “+” for about 2 seconds to mute on/off.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.