




Wireless Earphone  BT18 User Manual	FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the Console, the dealer or an experienced radio/TV technician for help.	RF warning statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. • These instructions are for your safety. Please read through them thoroughly before use and retain for future reference. PARTS INCLUDED • Wireless Earphone • MicroUSB to USB charge cable • User manual FEATURES • Wirelessly listen to music with integrated technology. • Fashion design, let music surrounding your life any time. • Hands free function, truly free your hand. • Set in rechargeable Li-ion battery, long stand-by and working time. • Support power displaying on iPhone, easy to know when will be charged. • DIY design, available to be detachable when you want. • Sound reminder function, easy to set the device according to sound remind. BATTERY WARNING • Please make sure the charging time is about 2 hours at the first time.	• Do not throw the device in a fire, battery may explode or leak. • The Helmet with the electronic core shall not exposed to excessive heat such as burning sun, fire or the like. • Do not replace the semi rechargeable Li-ion battery alone. STRUCTURES Fig.1 	Fig.2  Press down and pull down to detach SPECIFICATIONS • Frequency: 2,402GHz-2,480GHz • Range: 30-40 meters (depending on device) • Transmission distance of Microphone: ≤1 meter • Li-ion battery: 3.7V/1000mAh • Playback time: ≤4 hrs • Charging Voltage: 5V • Charging time: ≤1 hrs • Standby time: ≥240 hrs • Connection name: BT-B	USING THE HEADSET Power On Press the power button 3 seconds, the device will be sound reminder as "Power on". Pairing 1. Press the BUTTON 3 seconds with the sound reminder of "power on" and the sound reminder of "pairing", then seek the Connection name of "BT-B" to pair. 2. Automatically repair If your device is the latest recent paired device, the headset will be automatically repaired with your device when the device open it again. 3. Automatically search The device will be automatically into pairing mode again once the paired device is off. Broadcasting/Pause Press button to pause the song, press it again to continue the song. Upper song/decrease the sound press "+" one time for upper song, continue press the button to decrease the sound. Next song/increase the sound Press "+" one time for next song, continue press the button to increase the sound.
CALL ANSWER 1) Android smart phone: the cap will be alarming with "DONG, DONG..." while somebody calling. iPhone: the Headset will be alarming with phone calling music which is the same as the phone calling music in iPhone. 2) answer phone: press the power button one time to pick phone up. 3) Hangup: Press the button again to hangup. 4) Redial phone function: Press the button two times to redial the most recently phone number directly. 5) Phone number broadcasting: somebody call you, the device will sound broadcast the calling phone number, and the user will easy to know who calling. Power save mode The device will be off automatically after 5 minutes if no working device paired. Low power warning The device will be with the sound remind of "power low" while is working, it seems the power not enough, need to be charged. Power Off Press the button 3 seconds again, the device closed with the sound reminder of "power off", and the LED indicator off.	CHARGING THE HEADSET Note: the Device will need to be fully charged prior to initial use (approx. 2 hours). 1. Connect the micro-USB end of the charge cable to the micro-USB port on the Cap (Fig.1) 2. Connect the USB end of the charge cable to the USB port of the computer or adapter (not included). 3. The LED indicator (Fig.1) will turn solid RED while charging and will turn off when fully charged. Note: the Device can not be music playing or call answering while it is charging. INSTALLING STEP Step 1 Take out the Wireless part from the color box, and find out the two earphone, put the earphone into the both sides of the computer or adapter (not included). Step 2 And then, put the suitable position, try to put the helmet on the head so that the device is on suitable position, you can modify the position by hand in order to will use it, (reference, Fig.3)	Installation diagram Fig.1  Use a threading knife to loosen the threads. Easy to install. Fig.2  Move the clip and align it on the left side of the helmet Edge in. Fig.3  Adjust the position of the horn from left to right. Then lock the upsetting wire and fix it.	Fig.4  Peel off the white stripping paper of the wood magic sticker. Fig.5  Adhesion of Fur Magic to the helmet's Left ear position. Fig.6  Stick the left horn to the magic horn. The microphone is attached as shown in the picture.	Fig.7  The right trumpet retracts like a demon skull while strip paper. Fig.8  Stick the right horn to the magic horn. Fig.9  The horn line is buried behind the helmet. In the interior, the rechargeable head is exposed. Charging and cocoa.	Installation universal Off Road FLIP UP Half Face Full Face Compatibility devices: Applicable to the following equipment:  DISPOSAL AND RECYCLING Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. Attention should be drawn to the environmental aspects of battery disposal. 

