



1. External Photograph of EUT

Brand Name: Zebra / Model Name: MC3300R

SKU 1, SKU 4, and SKU 7



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R





Brand Name: Zebra / Model Name: MC3300R

SKU 2, SKU 5, and SKU 8



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R





Brand Name: Zebra / Model Name: MC3300R

SKU 3, SKU 6, and SKU 9



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



Brand Name: Zebra / Model Name: MC3300R



**2. Photograph of Accessory****Brand Name: Zebra / Model Name: MC3300R**

Specification of Accessory		
Sentry 2X battery	Brand Name	Zebra
	Part Number	BT-000337
MC32 2X battery	Brand Name	Symbol
	Part Number	82-000012-02
Adapter	Brand Name	Zebra
	Part Number	PWR-WUA5V12W0US
USB cable	Brand Name	Zebra
	Part Number	CBL-MC33-USBCHG-01
GUN HOLSTER	Brand Name	Zebra
	Part Number	SG-MC3021212-01R

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: MC3300R



3. Internal Photograph of EUT

Brand Name: Zebra / Model Name: MC3300R

Adapter



Brand Name: Zebra / Model Name: MC3300R

Sentry 2X battery



Brand Name: Zebra / Model Name: MC3300R

MC32 2X battery

