

1. Photographs of Dynamic Frequency Selection Test Configuration

For AP Mode:

FRONT VIEW




CLOSE-UP VIEW




For Mesh Mode:

FRONT VIEW



CLOSE-UP VIEW



————THE END————