

wireless speaker



USER'S MANUAL: Item V80020BT Speaker

Specifications

Speaker: 45mm
Output: 4 Ω 3W
Bluetooth Version: 5.3
Transmission distance: 10m

Battery: 300 mAh
Charge time: 1-2 Hours
Play time: 1-2 Hours**
Size: 96.8*88*32mm


The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.

** Applicable at 50% of maximum volume. Results will be lower when volume is higher.


A Quick Look

- 1-Power On/Off
- 2-Volume +/Next Track
- 3-Play/Pause
- 4-Mic
- 5-Call Controls
- 6-Charging Port
- 7-Volume-/Previous Track
- 8-LED Indicator


Control Panel:




Charging



Insert one end of the included USB charging cable into the charging port on your speaker.



Insert the other end of the USB cable into a suitable USB charging adapter (not included).



The LED Charging Indicator Light turns red while the speaker is charging and will turn off when fully charged.

Bluetooth Pairing




1. Take the unit out of the box.

Control Panel



2. To turn on the speaker, hold down the power button until the LED indicator light flashes. Hold down the button again to turn off the product.



3. On your phone, go to the Bluetooth page in the settings app. Make sure Bluetooth is on before connecting to the available device "V80020BT Speaker".

Music Controls



When the connected smartphone is receiving a call:
-Press to answer/end a call.
-Press and hold to reject a call.
-Press twice to redial the last called number.



-Press to Play/Pause music.



-Press the + button to turn the volume up.
-Press and hold the + button to go to the next song.



-Press the - button to turn the volume down.
-Press and hold the - button to go to the previous song.

wired earphones

USER'S MANUAL: Item V80020BT Wired Earphones


A Quick Look

- 1-Right Earphone
- 2-Left Earphone
- 3-USB-C Jack
- 4-In-line Microphone
- 5-Multi-function Button




Connecting

Connect the earphones to phones, tablets, or any audio source with a USB-C port and play music from your device. Make sure the earphone's jack is fully inserted into the USB-C port to properly work.



Music Controls



PRESS

► Play/Pause Track

PRESS TWICE

►► Next Track

PRESS THREE TIMES

◄◄ Previous Track

To play or pause the current audio, press the Multi-function button.

To go to the next track, press the Multi-function button twice.

To go to the previous track, press the Multi-function button three times.

Additional features may be available depending on the device the earphones are connected to.

Voice Assistant

If the earphones are connected to a smartphone with a voice assistant enabled (such as Siri for iOS or Google Assistant for Android), you can turn on the voice assistant from your earphones by pressing and holding the Multi-function button for 2 seconds.

Phone Control

If the earphones are connected to a smartphone, you can accept or hang up calls by pressing the Multi-function button. To decline calls, press and hold the Multi-function button for 2 seconds.

In-line Microphone

The earphones contain an In-line microphone that you can use to talk during calls.

VIVITAR® true wireless earphones



USER'S MANUAL: Item V80020BT Wireless Earphones

Specifications

Driver Diameter: 13mm
Bluetooth Version: 5.3
Transmission distance: 10m
Battery capacity (Earbuds): 25 mAh
Battery capacity (Case): 230 mAh
Charging input: DC 5V 1A (max)
Play time: 3-4 Hours**

** Applicable at 50% of maximum volume.
Results will be lower when volume is higher.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.


A Quick Look



Charging




Insert one end of the included USB charging cable into the charging port on your case.
Insert the other end of the USB cable into a suitable USB charging adapter (not included).




The LED Indicator will flash red while the speaker is charging and turn solid red when fully charged. If earbuds are charging inside, the indicator will turn green. When fully charged, the indicator will turn off.

Bluetooth Pairing



Using Your Earbuds: Music Controls



TWS Earbuds can be used independently One earbud can be used when the other is off, as long as it is connected to Bluetooth.

Important Safety Precautions

1. READ ALL INSTRUCTIONS BEFORE USING YOUR DEVICES.
2. Do not use your devices near water. Do not place your devices on any wet surfaces.
3. Do not allow children to use the devices without proper adult supervision.
4. Do not expose your devices to excessive heat or fire.
5. Do not use in extremely dry environments, as this can lead to static discharge during usage.
6. Do not expose your devices to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair these products yourself. Contact a qualified service center if your devices are in need of service.
8. Do not drop, puncture or expose your devices to excessive physical force.
9. Your devices are not intended for commercial use.
10. Do not place the devices near objects that generate a strong magnetic field.
11. Use only the supplied charging cable. Unplug this device when not in use for long periods of time and during lightning storms.
12. Use a soft cloth to clean your devices. Never use any abrasive chemicals.
13. Please recycle or dispose of your devices properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earbuds for further information.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.


This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Using Your Earbuds: Call Controls



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

© 2024 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 1800 592 9541
www.vivitar.com

Speaker's FCC ID : 2AL9B-V80020BT
TWS's FCC ID : 2AL9B-A11014