



The diagrams illustrate the M1000i device from three perspectives:

- Front View:** Shows the top of the device with callouts 1 through 7. Callout 1 points to the top edge, 2 to the top display area, 3 to the central display, 4 to the left side, 5 to the bottom display area, 6 to the bottom edge, and 7 to the right side.
- Side View:** Shows the left side of the device with callouts 8 and 9. Callout 8 points to the top edge, and 9 points to the side edge.
- Back View:** Shows the bottom of the device with callouts 10 and 11. Callout 10 points to the bottom edge, and 11 points to the bottom display area.

1. Left Button
2. Scroll Wheel Button
3. Right Button
4. Fire Button
5. DPI+
6. DPI-
7. Light Switch Button
8. DPI Lock
9. Forward
10. Backward
11. Polling Rate Switch Button
12. USB Receiver
13. Switch

1. **Programming Function:** Support customized buttons setting, polling rate adjustment, customized lighting modes and DPI adjustment via the programming software, which can be installed from included CD or <https://gamingffe.com/pages/download>

-
- The diagrams illustrate the components of the Logitech G502 mouse:
- Top View:**
 - 1: Left mouse button
 - 2: Right mouse button
 - 3: Scroll wheel
 - 4: Left mouse button
 - 5: Scroll wheel
 - 6: Right mouse button
 - 7: DPI button
 - Side View:**
 - 8: Left mouse button
 - 9: Right mouse button
 - 10: DPI button
 - Bottom View:**
 - 1: Left mouse button
 - 2: Right mouse button
 - 3: Scroll wheel
 - 4: Left mouse button
 - 5: Scroll wheel
 - 6: Right mouse button
 - 7: DPI button

1. Bouton Gauche
2. Molette De Défilement
3. Bouton Droite
4. Bouton De Tir
5. DPI +
6. DPI -
7. Interrupteur D'éclairage
8. Verrouillage DPI
9. Boutons Précédent
10. Bouton Suivant
11. Commutateur Du Taux De Polling
12. Récepteur USB
13. Commutateur

1. Veuillez ne pas utiliser la souris sur le verre ou le miroir.
2. Le logiciel de programmation n'est disponible que sous Windows.
3. Les boutons Précédent et Suivant ne sont pas disponibles sur Mac OS.

The diagram consists of three views of the mouse: a front view on the left, a side view in the middle, and a bottom view on the right. Numbered callouts point to various features: 1 points to the left button, 2 to the scroll wheel, 3 to the right button, 4 to the left button's side, 5 to the scroll wheel's side, 6 to the right button's side, 7 to the rear button, 8 to the left button's top, 9 to the scroll wheel's top, 10 to the right button's top, 11 to the left button's bottom, 12 to the right button's bottom, and 13 to the rear button's bottom.

1. Botón izquierdo
2. Botón de rueda de desplazamiento
3. Botón derecho
4. Botón de fuego
5. DPI+
6. DPI-
7. Botón de interruptor de luz
8. DPI Lock
9. Adelante
10. Hacia atrás
11. Botón de cambio de velocidad de sondeo
12. Receptor USB
13. Interruptor

The diagrams illustrate the features of the Logitech G502 mouse from three perspectives:

- Top View:** Shows the main body of the mouse. Callouts include: 1 (Left button), 4 (Left button), 2 (Right button), 3 (Right button), 5 (DPI button), 6 (DPI button), and 7 (DPI button).
- Side View:** Shows the profile of the mouse. Callouts include: 8 (Thumb rest), 9 (Thumb rest), and 10 (Thumb rest).
- Bottom View:** Shows the underside of the mouse. Callouts include: 1 (Front foot), 10 (Front foot), 11 (Front foot), 12 (Front foot), 13 (Front foot), 14 (Front foot), 15 (Front foot), and 16 (Front foot).

1. Pulsante Sinistro
2. Pulsante Rotellina di Scorrimento
3. Bottone Giusto
4. Pulsante di Fuoco
5. DPI +
6. DPI -
7. Pulsante Interruttore Luce
8. Blocco DPI
9. Inoltrare
10. Arretrato
11. Pulsante di Commutazione della Frequenza di Polling
12. Ricevitore USB
13. Interruttore

- | | | |
|--------------|-------------|--------------------------|
| 1. 左ボタン | 5. DPI+ | 10. 戻るボタン |
| 2. スクロールホイール | 6. DPI- | 11. ボールジョイスティック
調整ボタン |
| 3. 右ボタン | 7. ライト切替ボタン | 12. USBレシーバー |
| 4. ファイアボタン | 8. DPIロックキー | 13. スイッチ |
| | 9. 進むボタン | |

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

本品牌及其所使用的标志、名称、图像以及所有内容设计，其版权均均为本公司所有，未经授权任何组织、个人、商业团体不得擅自使用、翻印，本公司保留追究其法律责任的权利！

