

Size: 105.3 x 140.3mm, Insturciton manual will be 80g glossy coated art paper , with CMYK printing

Quick Start Reference/Troubleshooting:

- Press the power button for 3sec to turn the recording mixer on or off. The button will glow green when power is on and turn grey when charging.
- 6 red buttons are flashing or you hear a siren, the recording mixer needs to be charged. If not charged immediately, sound quality may suffer. Please note that the recording mixer can be charged while in use however, if they pick up noise from the charging current.
- Use all knobs plugged into the recording mixer are properly essential all the way. Otherwise, your mixer may not output correctly. If you're connecting to a phone, Bluetooth, or the USB, to remove phone call or other noise from the output volume.
- Recording volume adjusts the output volume your listeners will hear. Be sure to list the output volume levels using the "Record" knob to the desired output volume.
- When using a single mobile phone to broadcast, music volume and external background volume is adjusted using the phone volume. The recording mixer volume controls the microphone. When listening to the live broadcast, we recommend listening on a separate mobile phone/computer away from the microphone. A feedback loop may occur if the output volume and input are in the same area.
- When using a computer to record, test your microphone and sound mixer output before beginning to record. When connecting your sound mixer to the first time, your computer will download the correct device name automatically. Your computer may need a restart to complete the installation. If you hear small sounds from your microphone, increase the microphone output on your computer's volume control panel. We do not recommend using speakers while recording, as your microphone may pick up the sound. We recommend headphones or earphones for the best results.
- Before each broadcast, we recommend you test all the mixer features to ensure they are working. This way your recording can go on without issues.
- Connect the Bluetooth accompaniment: turn on the Bluetooth of the mobile phone, search the device to find "PY-PODC", and click the connection. After the connection is successful, the power button indicator light of the sound card will be blue, indicating that the Bluetooth is connected.
- The included LED display shows your volume and echo effect on a scale of 1-15. When you turn the MC, Microphone volume will scale. When the Reverb, the echo effect scale.

Specifications

Mean upper shell material: Metal knob, metal frosted body
 Mixer cover lower shell material: ABS plastic
 Mixer card chips: DSP noise reduction chip
 Mixer card dimensions: 4.9in x 4.1in x 1.06in (125x106x27mm)
 Supply voltage: DC 5V
 Power supply mode: built-in 18650/3.7V1200MAH lithium battery
 Use time: 8 hours with full power
 Bluetooth version: 5.3
 Frequency: 2.41-2.43ghz
 Model #: PY-PODC-BLK
 FCC ID: 2B8R-PYPODC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Bluetooth connection

Setting up the Mixer:

1. Dual mobile phone live connection: Shows two phones connected to the mixer's L1 and L2 inputs.
2. Single mobile phone live connection: Shows one phone connected to the mixer's L1 input.
3. Three mobile phone connection method: Shows three phones connected to the mixer's L1, L2, and L3 inputs.
4. Mobile phone broadcast with computer accompaniment connection: Shows a phone connected to L1 and a computer to the USB port.
5. Computer broadcast with computer recording song connection: Shows a computer connected to the mixer's USB port.

Microphone Installation

1. Screw the table clamp on the edge of a table.
2. Insert the adjustable arm into the hole.
3. The adjustable arm installation is complete.
4. Fix shock mount with Microphone stand.
5. Mount the microphone on the stand.
6. Fix the pop filter net on the cantilever support.
7. The installation is complete.

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

poppy

PODCAST STARTER KIT

The sound card V8

MC Volume Reverb Treble Bass Record Mute Mic Monitor Electro Chorus Male Solo M3 Dodge Clear Ambient Cartoon Contrast Reverb L30 Applewolf Boos Jazzy Failure

User Manual