

802.11n-HT20 AVGPSPD - Ant 1 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)



802.11n-HT40 AVGPSPD - Ant 1 - CDD Mode


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE20 AVGPSPD - Ant 1 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE40 AVGPSPD - Ant 1 - CDD Mode


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11b AVGPSPD - Ant 2 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPSPD - Ant 2 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)




802.11n-HT20 AVGPSP - Ant 2 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)




802.11n-HT40 AVGPSP - Ant 2 - CDD Mode

Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE20 AVGPSPD - Ant 2 - CDD Mode


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE40 AVGPSPD - Ant 2 - CDD Mode

Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)

