User Manual



LOCATION OF CONTROLS (CONT):

AT EXPLORA PORCE OR A difficial A

Remote Control



- 2. [Hee] button: Previous track/Tune down through radio stations in
- FM mode 3. [+] or [-] buttons: Increase/Decrease the volume
- 4.[MODE] Mode conversion
- S. [$\mathbb M$] button: Mute-turn OFF/ON sound 6, [\mapsto] button: Next track/Tune up through radio stations in FM mode 7, [\mapsto] button: Play/Pause
- 8. [RESET] button: Volume recovery system default settings
- 9. [FM SCAN] button: Press & Hold = FM Scan
- 10, [EQ] button: Switch sound settings 11. Numeric buttons





BASIC OPERATION:

RADIO OPERATION:

1 Press the (101) button to turn ON the unit.

button for one full second and release. 5 Press the IEM SCANI button on the remote control to search all available stations. Press it again to stop on a station.

6. To store preset radio stations in FM Mode:

a. Tune to the station you want to save.

to store the station.

repeatedly until the FM indicator turns GREEN. 3. Press the [155] or [155] button on the speaker or the remote control to tune down/up through radio stations.

unit is OFF

- 1. Flip Main Power Switch on the rear of the unit to the ON posit 2. Press the [(b)] button to turn ON the unit. A source indicator will light up GREEN when the unit is ON; the light will go out when the
- 3. Press the [MODE] button on the speaker or the [MODE] button on the remote control repeatedly to switch the playback source. The Source indicator will light up GREEN accordingly.
- 4. Press the EVOL+AVOL-I buttons on the speaker or the E+/-I buttons on the remote control to adjust volume level.
- 5. Press the [EQ] button to set EQ mode as desired.
- 6 Press the [If] button on the remote control to turn off the sound Press it again to turn the sound back on.

2. Press the [MODE] button on the speaker or the remote control

4. To scan to the next available station, press and hold the [1221] or [1221]

b. Press and hold a numeric button for 3 seconds on the remote control

c. Numbers between 1 and 9 may be used. For example, if you press and

hold "1" then you will have programmed "Station 1".

USB / SD CARD PLAYBACK:

- I, Insert an SO card once included into the SO card dist on the speaker to plp APIT mater. Res.

 Press the (1) District on Silver in the Sil
- 3. Press the [*3*] button to pause the music.
- Press the [*G*] button again to resume play.
- 4. Press the [199] button to skip forward to the next track and the $[\,\,{}^{\scriptscriptstyle{100}}_{\,\rm F}\,]\,$ button to skip backward to the previous track.
- Use numeric buttons to select your desired track. For example, pressing "2" + "0" + "9" means track 209

BLUETOOTH PAIRING & LINKING OPERATION:

1. Keep your Tower Speaker and Bluetooth enabled device within 3.

on the remote control repeatedly until the Bluetooth indicator flashes

Elfabling Green: Pairing Mode Solid Green: You are connected to the Blaetooth device. If you would like to use a new Blaetooth device with the speaker, you must unpaid the speaker from your device using your devices Blaetooth memal. If you prove off the speaker wise this work of the pair time you turn the speaker on the Blaetooth indicaser will flush Green which maken it is in Jairing mode.

GREEN. The Bluetooth indicator will remain GREEN when pairing is

Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.

Searching for devices

5. When the device finds the Tower Speaker, confirm by selecting Fisher-FTS190 from the list.

1 found

Bluetooth: Enabled

Select Device:

Paired Devices: Fisher-FTS190

Bluetcoth: Enabled

feet of each other during the pairing process.

2. Press and hold the (C)1 button to turn ON the unit. 3. Press the [MODE] button on the speaker or the [MODE] button

Select 'Pair' to connect the Tower Speaker to your Bluetooth enabled device.





7. Your Bluetooth enabled device will confirm that the pairing was completed, and prompt you to accept the connection. Please respond YES to connect the Tower Speaker to your Bluetooth enabled device.



8. When attempting to reconnect the Tower Speaker to your Blaetooth enabled device, your may see the message below, and your Blaetooth device will premarp you to accept the connection request to the Fliebe-FTS190 speaker, and an option hot to sak the agian. Flease accept the connection, and if you ack! Thom's akt his agian! your Blaetooth device will sutomatically accept future connection requests from your Tower Speaker.



enhance radio reception ability, fully unwind and the back of the speaker. AUXII IARY PLAYBACK:

1. Plug one end of the indluded 3.5 mm Auxiliary cord to the headphone lack on your device

៙៙៙

- 2. Plug the other end of the 3.5 mm Auxiliary cord into the AUX jack on the top of the speaker.
- 3. Press the [🕒] button to turn ON the unit.
- I. Press the [MODE] button on the speaker or the [MODE] button on the remote control repeatedly until the AUX indicator turns
- 5. Use your device's audio controls for music playback.



USB Charging:

- 1. There is a USB charger on the top of the unit that can charge iPhones, iPods and iPads or any device that charges using a

- 1. Press the [□□□] button to pause the music.
 Press the [□□□] button again to resume play.
 2. Press the [□□□] button to skip forward to the next track and the [□□□] button to skip backward to the previous track.
- 3 Press the IVOL+/VOL-I buttons on the speaker or the I+/-I buttons on the remote control to adjust volume level



TROUBLESHOOTING:

- •The volume level may be too law. Try increasing the volume by pressing the (VOL+) button on the speaker or the (+) button on the remote control.
 •The connected device might not be in playback mode.
 •Play music from the connected diseasoful device.
 •The sound output of the connected diseasoful device.
 •The sound output of the connected diseasoful device.

The volume level for the Tower Speaker is too high.

•Try reducing the volume level by pressing the [VOL-] button

Speaker and try the connection again. If a device was connected to the speaker, unpair it before connecting your new device. Do this using your Bluetooth device's Bluetooth

LEGAL INFORMATION

PCC Part 15: This device complies with Part 15 of the PCC Pales, Operation is subject to the following two

(1) this device may not cause harreful interference, and
(2) this device must accept any interference received, including interference that may

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance as all void the user's such only to operate the equipment. NOTE: This equipment has been tested and found to comply with the applications of pass to disjud death or fine Part 16 of the Federal Communications Loomerasis. PCCT right These registerments or invested to provide sectional processing agreement are invested to provide sectional processing agreement and furthermore on enclaring lists lightor. The equipment generality is provided to provide sectional processing agreement and furthermore in an enclaring lists lightor. The equipment generality captures are on an interest to be about the provided and provided an

However, there is no guizantee that interference will not occur in a perculair installation. If this occurrence ties is coast harmful interference to radio or tallevision is acceptor, which can be determed by turning the copyrence of and out, the user is oncouraged to try to correct the interference by one or more of the fireform of subsequence of the control of the fireform of t

Leasant the experience between five experience and experience and experience are proposed to the experience of experience and experience are proposed on the experience and experience and experience are proposed on the experience and experience are the experience are proposed on the experience and experience are proposed experience are

PLAY MUSIC FROM BLUETOOTH DEVICES:



In the box

0

0

0



warranty card

User manual

3.5mm auxiliary cord



