

**PERFORM**  
TRUE WIRELESS EARBUDS

**USER MANUAL**  
FCC ID:2BKTL-PRF001

**SAFETY & CARE INSTRUCTIONS**

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage it and void the warranty.  
Do NOT attempt to disassemble or modify the Earbuds or Charging Case in any way  
Spot Clean ONLY.  
Keep out of reach of children.  
This product is not a toy.  
The Earbuds Are Sweat And Water Resistant But Should Not Be Submerged Into Water As It Will Damage Them.

**CONTENTS:** 2 x Earbuds, 2 Additional Silicone Tips, 1 x Charging Case, 1 x Type C Charging Cable, 1 x Manual

**CHARGING YOUR EARBUDS**

- Place each earbud into its charging slot and close the cover.
- Use the charging cable provided and plug the other end into any USB charging port.

\*\*To prevent damage, it is recommended to use the charging cable that is provided. Fully charge the charging case and earbuds for a minimum of 3 hours before first use.

**POWERING ON & OFF**

- Take the earbuds out from the case, they will automatically power on.
- Place the earbuds back into the charging case, the earbuds will automatically power off.
- To manually power on, press and hold the TOP of either one of the earbuds for 4-5 seconds until the LED indicator flashes blue.
- To manually power off, press and hold button on either one of earbuds for 4-5 seconds until the LED indicator turns off.

**BLUETOOTH PAIRING WITH YOUR DEVICE**

- Open the charging case, remove the earbuds & they will automatically power on and pair to each other, voice will prompt 'CONNECTED'. The right earbud will automatically connect to the left earbud.
- Pairing mode will last for 2 minutes. While in pairing mode, turn ON the Bluetooth Connection on your device, Scan/Search & select "PERFORM".
- Once paired, PERFORM will voice prompt 'CONNECTED'.

**SINGLE EARBUD MODE:** When Bluetooth is connected, you can use either of the earbuds only by putting the other one back into the charging case & closing the cover.

**NOTE:** Power on PERFORM and they will automatically connect to the last connected device if available within the Bluetooth range.

**EARBUD TAP-TOUCH FUNCTION GUIDE**

**NOTE:** PERFORM has a sensitive tap-touch feature. There is a multi-function touch button on each earbud.

**NOTE:** Power on PERFORM and they will automatically connect to the last connected device if available within the Bluetooth range.

**TAP-TOUCH TO ACCESS FUNCTIONS**

<b>PREVIOUS SONG</b> TAP 3 TIMES	<b>NEXT SONG</b> TAP 3 TIMES	<b>PLAY/PAUSE</b> TAP TWICE
<b>VOLUME UP</b> Tap ONCE	<b>ACTIVATE VOICE ASSISTANT</b> PRESS & HOLD FOR 2 SECONDS	<b>VOLUME DOWN</b> Tap ONCE
<b>ANSWER CALL</b> Tap Once	<b>END CALL</b> Tap TWICE	<b>REJECT CALL</b> Press & Hold For 2 Seconds

**TECHNICAL SUPPORT & WARRANTY INFO**

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com.  
SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU, 2011/65/EU & 2012/19/EU.  
EU Declaration of Conformity for this product can be viewed at www.SimplyTechCorp.com/docs.

DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018  
MADE IN CHINA

Please read before using this product and retain manual for future reference.

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**PERFORM**  
TRUE WIRELESS EARBUDS

**BEDIENUNGSANLEITUNG DUR ARTIKELNUMMER**  
FCC ID:2BKTL-PRF001

**SICHERHEITS- UND PFLEGEHINWEISE**

Setzen Sie Teile dieses Produkts KEINEN Flüssigkeiten, Feuchtigkeit, scharfen Gegenständen oder extremen Temperaturen aus, da dies zu Schäden und zum Erlöschen der Garantie führen kann.  
Versuchen Sie NICHT, die Ohrhörer oder das Ladeetui zu zerlegen oder in irgendeiner Weise zu modifizieren.  
NUR punktuelle Reinigung.  
Außerhalb der Reichweite von Kindern aufbewahren. Dieses Produkt ist kein Spielzeug.  
Die Ohrhörer sind schweiß- und wasserabweisend. Sollte aber nicht in Wasser getaucht werden. Es wird Ihnen schaden.

**INHALT:** 2 x Ohrhörer, 2 zusätzliche Silikon Tipps, 1 x Ladekoffer, 1 x Typ C Ladekabel, 1 x Handbuch

**LADEN SIE IHRE OHRHÖRER AUF**

- Setzen Sie jeden Ohrhörer in seinen Ladesteckplatz ein und schließen Sie die Abdeckung.
- Verwenden Sie das mitgelieferte Ladekabel und stecken Sie das andere Ende in einen beliebigen USB-Ladeanschluss Hafen.

\*\*Um Schäden vorzubeugen, wird dies empfohlen das mitgelieferte Ladekabel zu verwenden. Laden Sie das Ladeetui vollständig auf und Ohrhörer mindestens 3 Stunden vorher erste Benutzung.

**EIN- und AUSSCHALTEN**

- Nehmen Sie die Ohrhörer aus der Hülle, sie werden automatisch eingeschaltet.
- Setzen Sie die Ohrhörer wieder ein Ladeetui, die Ohrhörer automatisch ausschalten.
- Zum manuellen Einschalten halten Sie gedrückt die OBERSEITE eines der Ohrhörer für 4-5 Sekunden bis die LED-Anzeige aufleuchtet blinkt blau.
- Zum manuellen Ausschalten halten Sie gedrückt Drücken Sie die Taste an einem der Ohrhörer für 4-5 Sekunden, bis die LED-Anzeige erlischt.

**BLUETOOTH-PAIRING MIT IHREM GERÄT**

- Öffnen Sie das Ladeetui und entfernen Sie es Ohrhörer und sie werden automatisch eingeschaltet einschalten und miteinander koppeln, die Stimme wird funktionieren Eingabeaufforderung „VERBUNDEN“. Der richtige Ohrhörer verbindet sich automatisch mit der linken Seite Ohrhörer.
- Der Pairing-Modus dauert 2 Minuten. Schalten Sie im Pairing-Modus das Gerät ein Bluetooth-Verbindung auf Ihrem Gerät, Scannen/suchen und wählen Sie „PERFORM“.
- Nach der Kopplung PERFORM wird eine Sprachaufforderung geben "IN VERBINDUNG GEBRACHT".

**EINZEL-EARBUD-MODUS:** Bei Bluetooth ist angeschlossen, können Sie beides nutzen Sie können die Ohrhörer nur entfernen, indem Sie den anderen zurückstecken Legen Sie es in das Ladeetui und schließen Sie die Abdeckung

**NOTIZ:** Schalten Sie PERFORM ein und sie werden es tun automatisch mit dem zuletzt verbundenen Gerät verbinden Gerät, sofern innerhalb der Bluetooth-Reichweite verfügbar

**OHRHÖRER TAP-TOUCH FUNKTIONSANLEITUNG**

**NOTE:** PERFORM verfügt über ein sensibles Hahn-Touch-Funktion. Es gibt eine Multifunktion Touch-Taste an jedem Ohrhörer.

**NOTE:** Schalten Sie PERFORM ein und sie werden es tun automatisch mit dem letzten verbinden angeschlossenes Gerät, sofern innerhalb der verfügbar Bluetooth-Reichweite.

**TAP-TOUCH TO ZUGANG FUNKTIONEN**

<b>VORHERIGE LIED</b> 3 MAL TIPP	<b>NÄCHSTE LIED</b> 3 MAL TIPP	<b>SPIELEN/PAUSE</b> TIPP ZWEIMAL
<b>VOLUMEN HOCH</b> Tippen Sie EINMAL	<b>AKTIVIEREN SIE STIMME ASSISTENT</b> DRÜCKEN UND HALTEN 2 SEKUNDEN	<b>VOLUMEN RUNTER</b> Tippen Sie EINMAL
<b>ANTWORT ANRUF</b> Tippen Sie auf Einmal	<b>ENDE ANRUF</b> Tippen Sie ZWEIMAL	<b>ABLEHNEN ANRUF</b> Drücken und halten Für 2 Sekunden

**TECHNISCHE HILFE & GARANTIENINFORMATIONEN**

Für dieses Produkt gilt eine einjährige Garantie auf jegliche Mängel. Für Garantieleistungen, Fragen oder wenn Sie Probleme mit diesem Produkt haben, kontaktieren Sie uns unter help@SimplyTechCorp.com.  
SimplyTech Electronics Inc. erklärt, dass das Funkgerät mit den Richtlinien 2011/65/EU, 2014/53/EU & 2012/19/EU konform ist.  
Die EU-Konformitätserklärung für dieses Produkt kann unter www.SimplyTechCorp.com/docs eingesehen werden.  
VERTRIEBEN VON: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018  
HERGESTELLT IN CHINA

Bitte lesen Sie das Handbuch vor der Verwendung dieses Produkts und bewahren Sie es zum späteren Nachschlagen auf.