

## FRONT PAGE

**When folded, please make sure that this title page is visible and not folded inside.**



**SAFETY AND CARE INSTRUCTIONS**

Read all the instructions before using the product and then store them for future reference. Failure to follow these safety instructions could lead to fire, electrical shock, personal injury, property damage, or damage to the product.

- This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local / state guidelines.
- Do not expose to rain, moisture, or other liquid. Do not use near water such as swimming pools, bathtubs, or sinks. If it becomes wet, immediately unplug the product from a power source. Do not handle the unit. Use cord or wall charger with wet hands.
- Do not charge, or use, the product if it has been submerged in water, or if water has got inside the product.
- Do not expose to heat sources, the sun, or leave in a hot vehicle. Do not dispose of in a fire.
- Do not expose the product to extremely high or low temperatures. Use this product in a location with a temperature of 32°F - 95°F. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 110°F could cause serious damage and explosion.
- Do not disassemble; there are no serviceable parts inside. Do not drop. Do not use if damaged or modified. If you see any sagging, swelling, leakage, or other abnormality. Never insert objects other than the specified cables into the product. Damaged or modified battery may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Charge using the correct wall charger, and make sure that the charger is inserted all the way into the electrical outlet. Disconnect the charger once the product is fully charged.
- This product is not a toy. Keep out of reach of children or those that require supervision.
- Do not use abrasive cleaning solvents to clean the unit.

Note: Lithium-ion batteries will self-discharge over time, and it is normal for battery performance to decline after several years of usage. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

**FCC STATEMENT**

Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**  
The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Mic: FCC ID: 2AHAS-XBS91083M  
Speaker: FCC ID: 2AHAS-XBS91083

**ONE YEAR LIMITED WARRANTY**

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

\*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service: customerservice@xtremecables.com

**XBS9-1083**  
User Manual V1.0 0724  
855-999-8041 | [www.xtremecables.com](http://www.xtremecables.com)



**Scan to Extend Your Warranty**

## BACK PAGE

**INTRODUCTION**

Thank you for purchasing the LED Light Show Mini Karaoke Bluetooth Speaker with Mic. This device is perfect for karaoke enthusiasts and includes a built-in filter for optimal sound quality. The mic also offers audio filters to enhance your karoke experience. Please read this manual carefully for proper usage and maintenance.

**FEATURES**

- Multiple light show modes
- Wireless microphone
- Karaoke filters
- Full audio control buttons
- Recharge via USB-C port, cable included
- Bluetooth range 10m


**SPECIFICATIONS**

- Bluetooth Range: 33ft
- Operating Current: Speaker: 0.4-1.5A | Mic: 30mA
- Wattage: 10W
- Charging Specification: 5V/1A
- Battery Capacity: Speaker: 1800mAh | Mic: 400mAh
- Charging Time: Speaker: 5 hours | Mic: 2 hours
- Frequency Response: 20Hz-20kHz
- Decibel: 20dB
- Dimensions: Speaker: 3.94 x 3.94 x 2.76 inches  
Mic: 5.31 x 1.46 x 1.46 inches  
Cable Length: 11.8 inches
- Net Weight: Speaker: 12.7 oz | Mic: 1.83 oz

**WHAT'S INSIDE**

- Mini Karaoke Bluetooth Speaker | Wireless Mic
- USB-C Charging Cable | User Manual

**GETTING TO KNOW YOUR PRODUCT**



**NOTE:** Before first use, charge the speaker and mic for at least 3 hours.

**CHARGING**  
Connect the USB charging cable to the speaker's and microphone's charging port. Plug the other end of the USB cable into a power source (e.g., USB wall adapter, computer). The charging indicators will light up red.

**OPERATION**  
To power on, hold down  button for 3 seconds. After the product is started it will automatically be in pairing mode.  
To power off, hold down  button for 3 seconds.

**BLUETOOTH PAIRING**  
- Ensure the speaker is powered on.  
- Open the Bluetooth settings on your device and search for new devices.  
- Select "Xtreme XBS9-1083" from the list of available devices.  
- Once paired, a confirmation tone will sound.

**SPEAKER CONTROLS**  
Play/Pause: Tap   
Volume Up: Tap   
Volume Down: Tap   
Next Track: Hold   
Previous Song: Hold   
Short press  to switch between modes. (Bluetooth/USB/TF).  
Short press  to cycle through different color modes.  
Short press  to add Karaoke filter.