## **Quick Start Guide**

**Product Specification** 

Product Name	LED LAMP
Model No.	11A19060WRGBW01
FCC ID	2AB2Q-11A19060WRGBK
Operating frequency	2402-2480MHz
Working Voltage	120Vac
Support Function	BLE(1Mbps/2Mbps/125kbps/500kbps)
Number of channels used	40
Operating Temperature	-20~40°C
Manufacturer & Address	LEEDARSON LIGHTING CO., LTD. Xingda Road, Xingtai Industrial Zone, Changtai County, Zhangzhou, Fujian, China

The following are the general user guide:

## Step 1:

Screw the bulb into a standard socket.

# Step 2:

Turn on the bulb with your wall switch to apply power to the bulb.

If you're not using a wall switch, then use your alternate method to apply power to the bulb.

# Step 3:

Remove the transparent plastic sheet on the remote control and supply power to the remote control.

### Step 4:

Press the first two keys of the remote control at the same time to pair the remote control and the bulb.





**Step 5:** After pairing, you can use the remote control to adjust the bulb.

For additional help, regulatory and safety Information, please go to: Federal Communications Commission (FCC) Interference Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

### Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.