

IDI-RTU5 PA600 Assembly




Figure 1 PA600 Power Amplifier PCB




Figure 2 PA600 T/R Switch and control PCB Top

IDI-RTU5 PA600 Assembly



Figure 3PA600 T/R Switch and control PCB Bottom




Figure 4 PA600 Internal

IDI-RTU5 PA600 Assembly



Figure 5PA60 Rear View



Figure 6PA600 Front View