

SINGSATION™

SOLO PRO

ALL-IN-ONE
KARAOKE SYSTEM

QUICK START GUIDE

Instructions en français.....	7
Instrucciones en español.....	14



Step 1: Unpack

Make sure the following items came in this package.



Singstation Solo Pro
Karaoke System +
Wireless Speaker



Micro-USB
charging cable


Step 2: Charge

Before you start using the Singstation Solo Pro for the first time, it's a good idea to charge it completely.

To charge the Singstation Solo: Plug the included micro-USB charging cable into the charging jack on the underside of the Singstation Solo Pro's control panel.

Plug the other end of the USB charging cable into a power source, like a computer or a USB charging adapter.


The charging indicator on the front of the Singstation Solo Pro is red while the speaker is charging. It turns off when the Singstation Solo Pro is fully charged.



Step 3: Turn on

Press and hold the **POWER/PAIR** button until the Singstation Solo Pro plays its startup sound. Then release it. The **POWER/PAIR** light starts blinking.


After a few seconds, the Singstation Solo Pro goes to Bluetooth pairing mode to set up with your smartphone.



Step 4: Pair + Connect

Enable Bluetooth on your smartphone or other device.

Make sure the **POWER/PAIR** light on the front of the Singstation Solo Pro is blinking. (If it isn't, give a short double-press on the **POWER/PAIR** button. The **POWER/PAIR** light starts blinking.)



Continues on the next page...

If you've previously paired your phone or other Bluetooth device with the Singstation Solo, it will automatically attempt to reconnect to that device when you switch it on. If you want to pair to a new device, give a short double-press to the **POWER/PAIR** button. The Singstation Solo announces "Pairing" and the **POWER/PAIR** button starts blinking.

Choose **Singstation Solo PRO** from the pairing options on your smartphone. (If it's not in the list, choose "Scan" from your phone's Bluetooth menu.)

The Singstation Solo Pro announces "Device Connected" when it's finished pairing and connecting to your smartphone. The **POWER/PAIR** light turns solid blue.

Note: The process of enabling Bluetooth and connecting varies from device to device. See your device's owners manual for more information and specific instructions.

Bluetooth Wireless Connection Tips

- Make sure the Bluetooth capability of your device is turned on.
- The Bluetooth wireless connection works up to a range of roughly 33 feet (10 meters). This range may vary, however, based on other factors, such as room layout, wall material, obstacles, your device's Bluetooth performance, etc. If you're having problems connecting to this speaker, move closer to it.
- If your device asks you for a password to connect, use "0000".

Step 5: Sing along!


Make sure the Singstation Solo Pro is on. (Press and hold the **POWER/PAIR** button on the front of the Singstation Solo if it isn't.)

Start playing music on your Bluetooth device and **sing along!**

To adjust the volume of your voice: Use the **VOLUME +** and **-** buttons on the front of the Singstation Solo Pro.

To adjust the volume of the music: Use the volume controls on your Bluetooth device.

To adjust voice echo: use the **ECHO** slider on the front of the Singstation Solo Pro.



Tour of the Singstation Solo Pro

POWER/PAIR button turns the Singstation Solo Pro on/off (press and hold until you hear the startup/shut-down sound), and puts the Singstation Solo Pro into pairing mode (short double-press when on).

POWER/PAIR indicator shows the Bluetooth status:

- blinking blue while pairing or reconnecting
- solid blue when paired
- off when the Singstation Solo Pro is off.

ECHO adjusts the echo effect on your voice.

VOLUME + and – buttons adjust the volume of your voice. (Adjust the volume of your music from your phone.)

Charging indicator turns red while the Singstation Solo Pro is charging. It turns off when it's charged.

Charging jack (underside of the control panel) connects to the provided USB charging cable to plug the Singstation Solo Pro into a power source or adapter.

