

- Section 1: Table of Contents
- Section 2: Component Checklist
- Section 3: Vehicle Features & Functions
- Section 4: Charging the Battery
- Section 5: Transmitter Battery Installation
Transmitter Features & Functions
- Section 6: Proper Use
Precautions & Care
- Section 7: Trouble Shooting & Support


- (1) R/C Vehicle With USB Cord
- (1) Transmitter
- (2) AA Batteries

1. Remove the screw to open the Battery Compartment Cover.
2. Insert 2 "AA" size batteries. Make sure the positive (+) and negative (-) markings on the batteries match up to the ones inside the Battery Compartment.
3. Replace the Battery Compartment Cover and replace the screw.



Keep your battery & transmitter batteries
from short-circuiting.
Do not store batteries in a container with
other electronic devices.

Features and Functions



This transmitter is equipped with 2.4GHz technology which allows up to 8 vehicles to be raced at the same time.

The transmitter will automatically sync with the vehicle.



OWNER'S MANUAL

Please read and understand all precautions prior to use.

Thank you for choosing a premium New Bright product.

USA & Canada
30 Day Limited Warranty

New Bright Industries warrants to the original purchaser that this product will be free of defects in materials and workmanship for thirty (30) days from the date of purchase. In the event of such defect within the warranty period, New Bright will repair or replace the product at no extra charge. This warranty does not cover damages resulting from unauthorized modifications, accidents, misuse or abuse.

Should your item have a defect covered under this warranty, first call the toll free number listed below. After problems can be resolved in this manner, if necessary, you will be issued a Return Authorization number (RA) and instructions on how to obtain a Product Return Form. The Product Return Form is to be used when returning a product to us (package one paid and insured by the consumer).


When returning a defective product, please package the product, the Product Return Form and a copy of the latest sales receipt as proof of purchase. Be sure to mark the RA number on the Product Return Form. If the product is returned without a signed return receipt, it will be excluded from coverage under this warranty. Please allow 4 to 8 weeks for delivery of repaired or replacement vehicles (depending on your location).

New Bright Industries liability for defects in materials and workmanship under this warranty shall be limited to repair or replacement at our sole discretion. It is not intended that we be responsible for incidental, consequential or resulting damages (except in those states that do not allow this exclusion or limitation).

Sold only in the USA & Canada.

Contact New Bright Industries Customer Service Toll Free at:
1-877-867-0295
71-877-867-0295
Monday through Friday, 9:00 AM to 5:00 PM Eastern Time

U.S. Toy Sales and Marketing Co., Inc.
3000 Oak Creek Drive - 4th Floor
Piquette MI 48670
1-877-867-0295
http://www.newbright.com



The ON/OFF switch controls the main power to the vehicle. To save battery life, always remember to put switch in the OFF position when not in use.

The 4 Wheel Drive Function allows the vehicle the ability to climb steep angles. Each wheel has independent suspension during forward and reverse drive. The vehicle also has elongated shocks and anti-free that help grip the ground.

* Steering Trim that is forced to between front wheels on the top side of the chassis, under the vehicle body. The vehicle will be in the left or right steering position during the Steering Trim may need to be adjusted.

This vehicle is equipped with an internal Lithium-Ion battery that is recharged via USB. ON/OFF Switch must be in the OFF position prior to charging.



1. Locate the ON/OFF switch and USB cord on the under-side of the vehicle.
2. Turn the ON/OFF switch to the "OFF" position.
3. Slide open Storage Compartment cover.
4. Remove USB cable from the Storage Compartment. (Use care when extending cord as it is attached to inside internal battery). Cord can be plugged into any computer or USB outlet brick (not included).
5. While charging, the LED under the vehicle will be on. Once fully charged the LED will turn off. Charging is completed in approximately 1 hour. Return cord and secure storage lid before operating the vehicle.



- Problem - Vehicle does not move or moves slowly.**
- Make certain there are fresh batteries in the transmitter and that they have been installed in the correct position.
 - Are the (+) and (-) markings on the batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
 - Are the metal contact tabs touching, rusty or dirty in the transmitter?
 - Has the vehicle been fully charged?
 - Make certain that the vehicle ON/OFF switch is in the "ON" position.

- Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.**
- Make certain there are no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

Always remove Batteries from transmitter when not in use.
Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.
Do not attempt jumps or tricks with this vehicle.
Do not attempt to remove internal battery.
Do not use included USB cord for anything other than its intended purpose. Always keep USB cord stored when not in use.
Adult supervision recommended.

FCC CAUTION:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and uses radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, it is recommended that you consult the dealer or an experienced radio/TV technician for help.

- Never look directly at the emitting antenna.
- Do not use the equipment in a hazardous environment.
- Connect the equipment to an outlet with a ground connection.
- Connect the device to an approved safety TV antenna for help.