



# Indicator Light Power key

# → Type-C Port

Quick Flashing

# Scan the QR code to get the installation video.

### Setting Steps for Speaker Use

1.Insert the 3.5mm Aux cable of the receiver into the Speaker's AUX connection

2.Connect the Phone/Pad with the receiver through Bluetooth and play songs;

3.Turn on the microphone and start singing.



### (Please read the following notes carefully)

(please refer to the description):

The microphone is on, the indicator light of mentioned problems fail to be solved by re-plugging the receiver.

### Steps for Pairing

1.Keep one microphone power off, Hold the VOLUME+ key and POWER key at the same time for over 5s, the indicator light of microphone will frequently flicker to start the pairing mode;

2.Keep another microphone power off, Hold the VOLUME- key and POWER key at the same time for over 5s, the indicator light of microphone will frequently flicker





within a range of about half a meter. Make sure no other objects in between; 4.Holding press the receiver POWER key for 5s untill the indicator light of receiver to flicker frequently;

5.The microphone and receiver have been paired up once the indicator light of

ON/OFF key at the same time for both moment, the indicator light for both they have been paired.

## The power indicator light of microphone is not on.

otherwise, please charge in time.

## What kind of charger is compatible to the

The mobile phone charger that supports 5V output can be utilized to charge the microphone. Please identify from the words on the charger whether it supports 5V output.

### Microphone is no sound

Solid Red

1. Check if the microphone is turned on and

3.If the indicator light is not on, you can follow the official Facebook account or Youtube account to view the pairing process and

### Speaker is no sound

1.Check if the receiver indicator light is on,

2.During the warranty period, parts necessary will be provided free of charge to make the product capable of being operated for its ordinary purpose.

3. This warranty does not include transport,

er's Defects.

1.1-year Limited Warranty for Manufactur-

This warranty is effective only for the ORIGINALLY PURCHASE and not for resale. Therefore under circumstances, rights under this warranty are not assignable.

due to any of the following: specifications of the original parts.

2.Misuse, abuse, neglect and improper

3.Usage of wrong electrical supply/voltage. 4.Usage not in accordance with the

5.Accidental or intentional damages

6.Corrosion rust or stains. 7.Normal wear and tear.

8.Breakdowns caused by other appliances

10.Damages due to natural disasters or acts of war or public disturbances. 11.Repairs or alterations by an unauthorized

high-temperature and damp places so as to avoid any breakdown.

2.It is recommended to charge in time in the event that the product is not in use for a long time so as not to compromise the service life of battery.

3.The product has been paired before delivery for direct use. Please DO NOT pair unless it is necessary, otherwise, the product may not function properly.

NOTE: This equipment has been tested and NOTE: In sequipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed. radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the which can be determined by turning equipment off and on, the user is encouraged to try to correct the

Setting Steps for Universal

1.Insert the 3.5mm Aux cable of the receive into the Car's AUX connection socket.

2.Connect the Phone/Pad with the receiver

3. Turn on the microphone and start singing.

Auto/Car

UHF

Increase the separation between the

equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could woit the user's authority.

to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful intenference: (2) this device must accept any interference

FCC ID: 2A7ZRPWMAZ-Q1 (Microphone) FCC ID: 2A7ZR-Q1PRO (Receiver)

... 3.6~4.2V (Lithium Polymer Battery 1000mA) Working Current ... ... 55mA Charging Interface . Input Current ... Microphone Mode Material ..... ... ABS

### .. 173mm×ф38.8mm Receiver

Working Voltage .. .... 3.6~4.2V (Lithium Polymer Battery 1000mA) Working Current ...... 200mAh Input Voltage ..... ..... < -94dBm Sensitivity ...... Communication Distance ...... 10m

Bluetooth Name .. Loostone PureMic Q1PRO

PUREMIC WIRELESS MICROPHONE USED ON MULTIPLE WAYS Users Manual

### LS04.04.00.0088.00

产品名 ▶ 亚马逊(	Q1 Pro说明书	RED 032C 材质	▶ 105g哑粉纸	风琴折	
设计于 ▶ 郭丽娜	尺寸 ▶ 展开尺寸:350x120mm 折叠尺	T艺:50 x 120mm 工艺	•	双面印刷版面的对齐	