


Zigbee Vibration Sensor - User manual -




1 Network Configuration

1. Power on the product.




Anticlockwise rotating the battery cover to open




Remove the battery insulation film to power on the product

2 Installation Instructions

1. Use a 3M sticker to affix the product to the target position.



2. Put the sensor suitable place.



FCC Statement


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.

• Please read the manual carefully and use the product correctly

Thank you for purchasing and using this product. Before using the product, please read the manual carefully and use the product correctly. In order to avoid damage to the equipment, such as all consequences caused by abnormal operation. The company will not bear any responsibility.

* The pictures in this manual are used to guide the user's operation and are for reference only. Please refer to the actual product for details.


• Product description



Reset

Version NO.: V1.0

2. Press the RESET button for 3s and release, the red LED will flash for network configuration.



3. Set the zigbee gateway to add device status on the APP (Refer to the gateway manual), search for the device.

Note: Zigbee sensors must be connected to a Zigbee gateway in order to use.

3 Product Parameters

Product Name	Zigbee Vibration Sensor
Wireless Protocol	Zigbee3.0
Acceleration range	$\pm 2g$
Tilt alarm	$\pm 10^\circ$
Working Voltage	3V
Battery Type	CR2450
Standby Current	$\leq 10\mu A$
Standby Time	≥ 15 hh Months
Working Temperature	$-10 \sim 55^\circ C$
Working Humidity	$0 \sim 99\%RH$
Product Size	$\Phi 40 \times 13mm$

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

(Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet part 15B exposure requirement. The device can be used in portable exposure condition without restriction.