

<div><div>60.00 mm</div><div>100.00 mm</div><div><div><div>Selfie Stick</div><div>稳拍器自拍杆 Q19</div></div><div><div>APP识别图</div><div>APP下载二维码</div><div>APP Store</div><div>Google Play</div></div><div><div>产品使用说明</div></div></div></div>	<div><div>操作界面</div><div><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div><div>9</div><div>10</div><div>11</div><div>12</div></div><div><div>① 云台电源开关</div><div>② 云台充电接口</div><div>③ 手动旋转</div><div>④ 补光灯</div><div>⑤ 补光灯开关</div><div>⑥ AI跟踪镜头</div><div>⑦ 云台锁</div><div>⑧ 旋钮</div><div>⑨ 补光灯充电口</div><div>⑩ 铝合金杆</div><div>⑪ 遥控器</div><div>⑫ 三脚架</div></div></div></div></div>	<div><div>蓝牙连接</div><div><div><div>初次连接:</div><div>1.将手机固定在手机夹的 正中间,保持相机平衡。</div><div>2.长按云台开关键并抬起杆, 直到灯打开并进入配对 状态。手机搜索 "Gimbal AI XXXXXX" 匹配。 配对成功后,指示灯将熄灭。</div></div><div><div>低功耗模式:</div><div>在云台开机状态下,3秒云台开关键进入退出低功耗模式, 20秒无操作,云台自动关机。</div></div><div><div>自动连接:</div><div>开机可自动连接已配对的手机。</div></div><div><div>遥控链接:</div><div>在云台开机状态下,开启遥控器激活无操作5秒进入睡眠 休眠状态,单击任意按键唤醒。</div></div></div></div>	<div><div>更换电池</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>云台充电</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>取出遥控器</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>稳定器模式</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>自拍杆模式</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>AI跟拍模式</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>手势功能</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>如何转换跟拍模式</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>补光灯功能</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>规格</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>
<div><div>Selfie Stick</div><div>Gimbal Stabilizer Q19</div></div> <div><div>APP识别图</div><div>APP下载二维码</div><div>APP Store</div><div>Google Play</div></div> <div><div>User Manual</div></div>	<div><div>Operation Interface</div><div><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div><div>9</div><div>10</div><div>11</div><div>12</div></div><div><div>① Gimbal power button</div><div>② Gimbal charging port</div><div>③ Manual rotation</div><div>④ Fill light</div><div>⑤ Light power button</div><div>⑥ AI tracking lens</div><div>⑦ Gimbal lock</div><div>⑧ Fill light charging port</div><div>⑨ Knob</div><div>⑩ Aluminum alloy rod</div><div>⑪ Wireless remote</div><div>⑫ Tripod</div></div></div></div></div>	<div><div>How to connect</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Replace a battery</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Gimbal charging</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Remove the remote</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Stabilizer mode</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Selfie mode</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>AI tracking mode</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Gesture function</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Switch to tracking mode</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Fill light</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>	<div><div>Specification</div><div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>① 取出螺丝</div><div>② 向上滑动电池盖</div><div>③ 更换电池</div></div></div></div></div>

材质:157g铜版纸

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.