

2. External Photograph of the Host

Host: Touch All-in-One Computer (Elo or **elo** / ESY10i1)





Host: Touch All-in-One Computer (Elo or **elo** / ESY10i1)





3. Photograph of Accessory for the Host

Host: Touch All-in-One Computer (Elo or **elo** / ESY10i1)

List of Accessory for Host (Touch All-in-One Computer):

Specification of Accessory		
AC Adapter 1	Brand Name	DELTA
	Model Name	ADP-65JH HB
AC Adapter 2	Brand Name	FSP
	Model Name	FSP065-REB

Remark: For accessories equipped with this EUT, please refer to the following photos.



Host: Touch All-in-One Computer (Elo or **elo** / ESY10i1)



Host: Touch All-in-One Computer (Elo or / ESY10i1)

AC Adapter 1



Host: Touch All-in-One Computer (Elo or **elo** / ESY10i1)

AC Adapter 2

