



Desktop Printer
S821
Phomemo

Package Contents / 同梱品一覧 / Packliste




1. Printer (プリンター)	2. Power adapter (電源アダプター)	3. USB cable (USBケーブル)	4. Quick start guide (クイックスタートガイド)
--------------------	----------------------------	------------------------	------------------------------------

Attention: All pictures in this instruction manual are for illustration purposes only. The actual product may vary due to product enhancement.
注意: 説明書中の製品、アクセサリーはいずれも説明図のみです。製品の改良やアップデートにより、実際の製品と説明図に違いがある場合があります。ご注意ください。

Hinweis: Bei den Produkten und Zubehörsachen in diesem Handbuch handelt es sich um schematische Darstellungen. Aufgrund von Produktaktualisierungen oder Verbesserungen kann das tatsächliche Produkt von den schematischen Darstellungen abweichen, bitte beziehen Sie sich auf das tatsächliche Produkt.

Printer Components / 機種の説明 / Produktstruktur



English	日本語	Deutsch
1. Indicator Light (Power)	電源ランプ	Betriebsanzeige
2. Indicator Light (WiFi)	WiFiランプ	WiFi-Anzeige
3. Power Button	電源ボタン	Ein/Aus-Taste
4. Paper Output Slot	排紙口	Papierausgabe
5. USB Port	USBポート	USB-Schnittstelle
6. DC Port	DCポート	DC-Schnittstelle
7. Open Cover Button	蓋開けボタン	Abdeckungsknopf

03. Warning

- Please use our official power adapter to ensure the quality of your printing.
- Please do not touch the print head as an overheated print head may cause undesirable burns.
- The paper cutter is very sharp. Please be careful when handling it. (Only applies to models with paper cutter)
- Please connect to your 2.4 GHz WiFi. 5 GHz is currently not supported.
- When printing, please do not pull the paper by force to prevent affecting your printing experience.
- The optimum working temperature for the printer is around 0°C-40°C. The too high or too low temperature may affect the printing quality.

04. Instructions


- Open the cover by pressing the Open Cover Buttons on the two sides of the printer.



- Take out a random paper roll and tear the edge of the paper roll.



- Install the paper roll back into the paper compartment and pull the paper out of the Paper Output Slot. Close the Cover



05. Connect to the computer

- Connect one end of the data cable to your computer and the other end to the printer's USB port. Connect your printer to a power source and turn on your printer.
- Enter our official website and download the printer's drivers. Install the drivers.
- Add the printer to your computer and establish a connection. Once the connection is established, you can print your documents from your computer.

Tip: If you wish to obtain more tutorials on how to install the driver, please open your Phomemo APP - Profile -> Use Tutorial to obtain more guidance



06. Connect to the computer

- Connect one end of the data cable to your computer and the other end to the printer's USB port. Connect your printer to a power source and turn on your printer.



07. Printer State

Function	Indicator Light
Turning on the printer	Indicator Light (Power) - Red, Green & White (Flashing)
Printing	Indicator Light (Power) - Green (Flashing)
Idle State (including after printing, installing paper rolls, closing the cover or paper compartment)	Indicator Light (Power) - Green (Lit)
Turning off the printer	Indicator Light (Power) - Off
Upgrading Firmware	Indicator Light (Power) - Red & Green (Alternating Flashing)
Print Head overheated	Indicator Light (Power) - Red (Flashing)
Out of Paper/Unable to detect paper	Indicator Light (Power) - Red (Lit)
Incorrect RFID	Indicator Light (Power) - Red (Lit)
Printer's Cover Open	Indicator Light (Power) - Red (Lit)
WiFi Connecting	Indicator Light (WiFi) - White (Flashing)
WiFi Connected	Indicator Light (WiFi) - White (Lit)
Disconnecting	Indicator Light (WiFi) - White (Flash Three Times)

08. Official printing paper type

Normal thermal paper: Does not contain Bisphenol-A.
Writable Quick-drying thermal paper: Thermal paper that does not contain Bisphenol-A, can be written on, and dries ink quickly.
*The printing papers mentioned above are official printing papers.
*Any issues with your printer arising from using non-official printing papers will not be covered under our warranty policy.

09. After-sales Service

1. Please search for "Phomemo" on your phone's app market and download the app.
2. Turn on the printer, open the app, and connect to the printer by following the instructions on the app.
3. Choose the file you want to print on the App. You may check the print preview and start printing.

Warning: 1. Please ensure your Bluetooth is turned on. Make sure to put your phone near the printer.
2. If you're connecting through WiFi, please connect to the 2.4 GHz WiFi, not the 5 GHz WiFi.



10. Warranty Card

- Return
- Exchange
- Repair

User Info: Name, Gender, Phone, Address, Purchase date, Product order number, Product Serial Number, Return reason.

Failure condition, Handling situation, Delivery date, Maintenance Serial Number.

Inspector: Delivery date.

11. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm from the radiator your body.

12. IC Warning

IC Caution: Radio Standards Specification RSS-Gen, issue 5- English: This device complies with license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt (RSS). Operation is subject to the following two conditions: This device must not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.

The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- French: Cet appareil conforme des émetteurs / récepteurs exempts de licence d'Innovation, Science et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: Cet appareil ne doit pas produire d'interférence radioélectrique. Cet appareil doit accepter toute interférence radioélectrique, y compris celle qui peut causer un fonctionnement indésirable de l'appareil.


Déclaration d'exposition RF: L'équipement est conforme à la limite d'exposition aux rayonnements de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

03. 注意事項

- 必ず当社の公式電源アダプターを使用してください。
- 印刷ヘッドは非常に熱い。印刷ヘッドに触ると火傷の原因となる場合があります。
- 紙の切断刃は非常に鋭い。取り扱いには注意してください。(紙の切断機能は一部のモデルにのみ搭載されています。)
- 2.4 GHz WiFiに接続してください。5 GHzは現在サポートされていません。
- 印刷中は、紙を無理に引っ張らないでください。印刷体験に影響する可能性があります。
- 最適な動作温度は約0°C〜40°Cです。温度が高すぎたり低すぎたりすると、印刷品質に影響する可能性があります。

04. 使用ガイド

- プリンタ両側の蓋開けボタンを押して上蓋を開けます。



- 付属のロール紙を取り出し、ロールの縁から裂きます。



- ロール紙をセロテープでプリンタの紙出口付近まで紙を引出し、上蓋を閉じます。



05. プリンタの状態

Function	Indicator Light
Turning on the printer	Indicator Light (Power) - Red, Green & White (Flashing)
Printing	Indicator Light (Power) - Green (Flashing)
Idle State (including after printing, installing paper rolls, closing the cover or paper compartment)	Indicator Light (Power) - Green (Lit)
Turning off the printer	Indicator Light (Power) - Off
Upgrading Firmware	Indicator Light (Power) - Red & Green (Alternating Flashing)
Print Head overheated	Indicator Light (Power) - Red (Flashing)
Out of Paper/Unable to detect paper	Indicator Light (Power) - Red (Lit)
Incorrect RFID	Indicator Light (Power) - Red (Lit)
Printer's Cover Open	Indicator Light (Power) - Red (Lit)
WiFi Connecting	Indicator Light (WiFi) - White (Flashing)
WiFi Connected	Indicator Light (WiFi) - White (Lit)
Disconnecting	Indicator Light (WiFi) - White (Flash Three Times)

06. Official printing paper type

Normal thermal paper: Does not contain Bisphenol-A.
Writable Quick-drying thermal paper: Thermal paper that does not contain Bisphenol-A, can be written on, and dries ink quickly.
*The printing papers mentioned above are official printing papers.
*Any issues with your printer arising from using non-official printing papers will not be covered under our warranty policy.

09. After-sales Service

1. Please search for "Phomemo" on your phone's app market and download the app.
2. Turn on the printer, open the app, and connect to the printer by following the instructions on the app.
3. Choose the file you want to print on the App. You may check the print preview and start printing.

Warning: 1. Please ensure your Bluetooth is turned on. Make sure to put your phone near the printer.
2. If you're connecting through WiFi, please connect to the 2.4 GHz WiFi, not the 5 GHz WiFi.



10. Warranty Card

- Return
- Exchange
- Repair

User Info: Name, Gender, Phone, Address, Purchase date, Product order number, Product Serial Number, Return reason.

Failure condition, Handling situation, Delivery date, Maintenance Serial Number.

Inspector: Delivery date.

11. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm from the radiator your body.

12. IC Warning

IC Caution: Radio Standards Specification RSS-Gen, issue 5- English: This device complies with license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt (RSS). Operation is subject to the following two conditions: This device must not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.

The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- French: Cet appareil conforme des émetteurs / récepteurs exempts de licence d'Innovation, Science et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: Cet appareil ne doit pas produire d'interférence radioélectrique. Cet appareil doit accepter toute interférence radioélectrique, y compris celle qui peut causer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF: L'équipement est conforme à la limite d'exposition aux rayonnements de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

03. 注意事項

- 必ず当社の公式電源アダプターを使用してください。
- 印刷ヘッドは非常に熱い。印刷ヘッドに触ると火傷の原因となる場合があります。
- 紙の切断刃は非常に鋭い。取り扱いには注意してください。(紙の切断機能は一部のモデルにのみ搭載されています。)
- 2.4 GHz WiFiに接続してください。5 GHzは現在サポートされていません。
- 印刷中は、紙を無理に引っ張らないでください。印刷体験に影響する可能性があります。
- 最適な動作温度は約0°C〜40°Cです。温度が高すぎたり低すぎたりすると、印刷品質に影響する可能性があります。

04. 使用ガイド

- プリンタ両側の蓋開けボタンを押して上蓋を開けます。

- 付属のロール紙を取り出し、ロールの縁から裂きます。

- ロール紙をセロテープでプリンタの紙出口付近まで紙を引出し、上蓋を閉じます。

05. プリンタの状態

Function	Indicator Light
Turning on the printer	Indicator Light (Power) - Red, Green & White (Flashing)
Printing	Indicator Light (Power) - Green (Flashing)
Idle State (including after printing, installing paper rolls, closing the cover or paper compartment)	Indicator Light (Power) - Green (Lit)
Turning off the printer	Indicator Light (Power) - Off
Upgrading Firmware	Indicator Light (Power) - Red & Green (Alternating Flashing)
Print Head overheated	Indicator Light (Power) - Red (Flashing)
Out of Paper/Unable to detect paper	Indicator Light (Power) - Red (Lit)
Incorrect RFID	Indicator Light (Power) - Red (Lit)
Printer's Cover Open	Indicator Light (Power) - Red (Lit)
WiFi Connecting	Indicator Light (WiFi) - White (Flashing)
WiFi Connected	Indicator Light (WiFi) - White (Lit)
Disconnecting	Indicator Light (WiFi) - White (Flash Three Times)

06. Official printing paper type

Normal thermal paper: Does not contain Bisphenol-A.
Writable Quick-drying thermal paper: Thermal paper that does not contain Bisphenol-A, can be written on, and dries ink quickly.
*The printing papers mentioned above are official printing papers.
*Any issues with your printer arising from using non-official printing papers will not be covered under our warranty policy.

09. After-sales Service

1. Please search for "Phomemo" on your phone's app market and download the app.
2. Turn on the printer, open the app, and connect to the printer by following the instructions on the app.
3. Choose the file you want to print on the App. You may check the print preview and start printing.

Warning: 1. Please ensure your Bluetooth is turned on. Make sure to put your phone near the printer.
2. If you're connecting through WiFi, please connect to the 2.4 GHz WiFi, not the 5 GHz WiFi.

10. Warranty Card

- Return
- Exchange
- Repair

User Info: Name, Gender, Phone, Address, Purchase date, Product order number, Product Serial Number, Return reason.

Failure condition, Handling situation, Delivery date, Maintenance Serial Number.

Inspector: Delivery date.

11. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm from the radiator your body.

12. IC Warning

IC Caution: Radio Standards Specification RSS-Gen, issue 5- English: This device complies with license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt (RSS). Operation is subject to the following two conditions: This device must not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.

The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- French: Cet appareil conforme des émetteurs / récepteurs exempts de licence d'Innovation, Science et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: Cet appareil ne doit pas produire d'interférence radioélectrique. Cet appareil doit accepter toute interférence radioélectrique, y compris celle qui peut causer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF: L'équipement est conforme à la limite d'exposition aux rayonnements de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

03. 注意事項

- 必ず当社の公式電源アダプターを使用してください。
- 印刷ヘッドは非常に熱い。印刷ヘッドに触ると火傷の原因となる場合があります。
- 紙の切断刃は非常に鋭い。取り扱いには注意してください。(紙の切断機能は一部のモデルにのみ搭載されています。)
- 2.4 GHz WiFiに接続してください。5 GHzは現在サポートされていません。
- 印刷中は、紙を無理に引っ張らないでください。印刷体験に影響する可能性があります。
- 最適な動作温度は約0°C〜40°Cです。温度が高すぎたり低すぎたりすると、印刷品質に影響する可能性があります。

04. 使用ガイド

- プリンタ両側の蓋開けボタンを押して上蓋を開けます。

- 付属のロール紙を取り出し、ロールの縁から裂きます。

- ロール紙をセロテープでプリンタの紙出口付近まで紙を引出し、上蓋を閉じます。

05. プリンタの状態

Function	Indicator Light
Turning on the printer	Indicator Light (Power) - Red, Green & White (Flashing)
Printing	Indicator Light (Power) - Green (Flashing)
Idle State (including after printing, installing paper rolls, closing the cover or paper compartment)	Indicator Light (Power) - Green (Lit)
Turning off the printer	Indicator Light (Power) - Off
Upgrading Firmware	Indicator Light (Power) - Red & Green (Alternating Flashing)
Print Head overheated	Indicator Light (Power) - Red (Flashing)
Out of Paper/Unable to detect paper	Indicator Light (Power) - Red (Lit)
Incorrect RFID	Indicator Light (Power) - Red (Lit)
Printer's Cover Open	Indicator Light (Power) - Red (Lit)
WiFi Connecting	Indicator Light (WiFi) - White (Flashing)
WiFi Connected	Indicator Light (WiFi) - White (Lit)
Disconnecting	Indicator Light (WiFi) - White (Flash Three Times)

06. Official printing paper type

Normal thermal paper: Does not contain Bisphenol-A.
Writable Quick-drying thermal paper: Thermal paper that does not contain Bisphenol-A, can be written on, and dries ink quickly.
*The printing papers mentioned above are official printing papers.
*Any issues with your printer arising from using non-official printing papers will not be covered under our warranty policy.

09. After-sales Service

1. Please search for "Phomemo" on your phone's app market and download the app.
2. Turn on the printer, open the app, and connect to the printer by following the instructions on the app.
3. Choose the file you want to print on the App. You may check the print preview and start printing.

Warning: 1. Please ensure your Bluetooth is turned on. Make sure to put your phone near the printer.
2. If you're connecting through WiFi, please connect to the 2.4 GHz WiFi, not the 5 GHz WiFi.

10. Warranty Card

- Return
- Exchange
- Repair

User Info: Name, Gender, Phone, Address, Purchase date, Product order number, Product Serial Number, Return reason.

Failure condition, Handling situation, Delivery date, Maintenance Serial Number.

Inspector: Delivery date.

11. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm from the radiator your body.

12. IC Warning

IC Caution: Radio Standards Specification RSS-Gen, issue 5- English: This device complies with license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt (RSS). Operation is subject to the following two conditions: This device must not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.

The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- French: Cet appareil conforme des émetteurs / récepteurs exempts de licence d'Innovation, Science et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: Cet appareil ne doit pas produire d'interférence radioélectrique. Cet appareil doit accepter toute interférence radioélectrique, y compris celle qui peut causer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF: L'équipement est conforme à la limite d'exposition aux rayonnements de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

03. 注意事項

- 必ず当社の公式電源アダプターを使用してください。
- 印刷ヘッドは非常に熱い。印刷ヘッドに触ると火傷の原因となる場合があります。
- 紙の切断刃は非常に鋭い。取り扱いには注意してください。(紙の切断機能は一部のモデルにのみ搭載されています。)
- 2.4 GHz WiFiに接続してください。5 GHzは現在サポートされていません。
- 印刷中は、紙を無理に引っ張らないでください。印刷体験に影響する可能性があります。
- 最適な動作温度は約0°C〜40°Cです。温度が高すぎたり低すぎたりすると、印刷品質に影響する可能性があります。

04. 使用ガイド

- プリンタ両側の蓋開けボタンを押して上蓋を開けます。</