

	
物料名称(Name)	WC14 说明书
材质(Material)	80g铜纸
尺寸(Dimension)	82x52mm,共40P,骑马钉装
印刷(Printing)	800K
表面工艺(Finish)	按照标准做喷油处理,如有疑问随时沟通。
备注(remarks)	按照标准做喷油(打),英、法、公署±0.2mm

封面

目录



BotLab PT 4G LTE Cellular Camera Quick Start Guide

Contents

English: PT473

French: PT472

Packing list

Check the packing list to ensure that the package contains the correct components and accessories.


Accessories List

- 1x BotLab PT 4G LTE Cellular Camera
- 1x Solar Panel
- 1x Battery Pack
- 1x Mounting Bracket
- 1x USB Cable
- 1x Power Adapter
- 1x User Manual

Before Installation

- Check the package for any damage.
- Read the user manual carefully.
- Ensure the camera is fully charged.

Product Appearance



Guidelines for Connecting to the Network

1. Connect the camera to the network using the provided USB cable.

2. Follow the steps in the user manual to configure the network settings.

Installation Guide

1. Mount the camera on a stable surface using the provided bracket.

2. Connect the solar panel and battery pack to the camera.

Support

For more information, please contact our support team at support@botlab.com.

Declaration of Solar Panels

The solar panels are made of high-quality monocrystalline silicon cells, providing efficient power generation.

英语

Contact Us

- Customer Service: support@botlab.com
- Technical Support: tech@botlab.com
- Feedback: feedback@botlab.com

How to adjust the orientation of solar panels

1. Adjust the solar panel angle to maximize power generation.

2. Ensure the solar panel is clean and free of debris.

Camera and Solar Panel Installation and Connection

1. Mount the camera and solar panel on a stable surface.

2. Connect the solar panel to the camera using the provided cable.

Precautions

- Do not touch the camera lens or sensor.
- Avoid exposing the camera to direct sunlight for extended periods.

Working Status Description

Working Status	Indicator
Power On	Green LED
Power Off	Red LED
Network Connected	Blue LED
Network Disconnected	Yellow LED

Description of Product Material Contents

Material	Quantity
Monocrystalline Silicon	100g
Polycrystalline Silicon	50g
Amorphous Silicon	20g
Thin-Film Silicon	10g

Regulatory Information

The product complies with the following regulatory standards:

- CE Marking
- FCC Part 15
- RoHS

After-sales Service

We provide a 1-year warranty for the product. For more details, please refer to the warranty card.

封底

Contenu de l'emballage

Check the packing list to ensure that the package contains the correct components and accessories.


Accessories List

- 1x BotLab PT 4G LTE Cellular Camera
- 1x Solar Panel
- 1x Battery Pack
- 1x Mounting Bracket
- 1x USB Cable
- 1x Power Adapter
- 1x User Manual

Before Installation

- Check the package for any damage.
- Read the user manual carefully.
- Ensure the camera is fully charged.

Product Appearance



Guidelines for Connecting to the Network

1. Connect the camera to the network using the provided USB cable.

2. Follow the steps in the user manual to configure the network settings.

Installation Guide

1. Mount the camera on a stable surface using the provided bracket.

2. Connect the solar panel and battery pack to the camera.

Support

For more information, please contact our support team at support@botlab.com.

Declaration of Solar Panels

The solar panels are made of high-quality monocrystalline silicon cells, providing efficient power generation.

Comment ajuster l'orientation des panneaux solaires

1. Ajustez l'angle du panneau solaire pour maximiser la production d'énergie.

2. Assurez-vous que le panneau solaire est propre et exempt de débris.

Installation et connexion de la caméra et du panneau solaire

1. Montez la caméra et le panneau solaire sur une surface stable.

2. Connectez le panneau solaire à la caméra à l'aide du câble fourni.

Précautions

- Nécessitez pas de toucher la lentille ou le capteur de la caméra.
- Évitez d'exposer la caméra à la lumière directe du soleil pendant de longues périodes.

Description de l'état de la substance en cours de travail

État de la substance	Indicateur
Alimentation allumée	LED verte
Alimentation éteinte	LED rouge
Connexion réseau réussie	LED bleue
Connexion réseau échouée	LED jaune

Description de l'état de la substance en cours de travail

État de la substance	Indicateur
Alimentation allumée	LED verte
Alimentation éteinte	LED rouge
Connexion réseau réussie	LED bleue
Connexion réseau échouée	LED jaune

Informations réglementaires

Le produit est conforme aux normes réglementaires suivantes :

- CE Marquage
- FCC Partie 15
- RoHS

Service après-vente

Nous offrons une garantie de 1 an pour le produit. Pour plus de détails, veuillez consulter la carte de garantie.

法语

变更记录(Describe)	签名(Name)	日期(Date)
10页/37页售后服务内容文字修改	陈凤莲	202310-08
螺丝包改两个--鑫胜	陈凤莲	202311-16
修改内容---宗情	陈凤莲	202312-1
修改内容---宗情	陈凤莲	202312-4