

Mini PC B88M\_User manual(120\*110mm)\_Ch\_2023/11/16

使用说明书

Mini PC

注意事项

- 产品仅适用于海拔2000米以下非热带地区。
- 请勿靠近水源或潮湿的地方，如浴室、厨房、地下室、游泳池等。
- 确保设备安装放置在平稳处，避免本机跌落地面或受其它强烈冲击。
- 在阴凉、干燥、通风处存放、使用，请勿靠近热源合热源。
- 设备存放温度：-15℃~45℃
- 尽量避免在强磁、强静电环境下使用。
- 当设备长期不使用，请切断电源，防止在雷雨天受到电击或异常电压的损伤。
- 一旦有水或其它液体泼洒到本机上，应立即关机将本机擦拭，晾干后才使用。
- 切勿使用任何化学成分的清消剂或其它液体擦拭本机，避免因腐蚀和受潮造成损伤，如确实有必要请洁，请用干燥的软布或纸巾拭。
- 请勿重压、摔落外壳上的通风孔。请勿置于床、沙发、毛毯或类似物体表面使用。
- 请使用可靠地插线板，勿让插线板过载，否则会引起火灾或电击。
- 请勿将异物放入设备内，否则可能会引起短路而导致火灾或电击。
- 请勿过度拉扯、扭曲电源线。
- 请购买并使用正规品牌的内存和硬盘。
- 本公司对人为非正常的软硬件操作、维修或其他意外情况导致的设备内资料丢失或删除不承担责任，也不承担因此而导致的其它损失。
- 请随时备份您的重要资料，以免丢失。
- 请不要自行拆卸本机，否则可能会失去保修的权利。

塑料包装安全警告：  
请将塑料包装袋放在婴儿和儿童接触不到的位置，避免窒息危险。

产品介绍

按键及接口布局示意图和说明

前

后

左

右

1 电源按钮/指示灯

2 USB 接口

3 以太网接口

4 HDMI 线接口

5 电源适配器接口

6 SD 卡槽

7 耳机与麦克风两用接口

8 Type-C 接口

9 散热出风口

包装清单

主机

电源适配器

HDMI线

使用说明书

壁挂式支架

螺丝包

快速安装指南

1. 请自行准备有线或无线键盘、鼠标。

安装步骤：  
1. 连接电源适配器接入电源；  
2. 连接显示器HDMI接口；  
3. 连接键盘有线键盘鼠标（无线键盘进入系统后连接）；  
4. 连接以太网口接入家用网络站端。  
5. 按下电源键，开机使用。

连接键盘鼠标

连接显示器

连接以太网

连接电源适配器

连接显示器HDMI接口

壁挂式安装步骤：

壁挂式支架

1 用螺丝将支架固定在迷你主机上

2 用螺丝将支架固定到显示器背面

电源键及指示灯状态说明：

电源键及指示灯

电源键操作说明  
关机状态下短按 开机  
开机状态下短按 睡眠  
开机状态下长按 睡眠

指示灯状态说明  
接通电源时 亮红灯  
按下电源键 亮绿灯

电脑保修条款说明

一、服务范围

1. 产品自销售之日起（以购机发票或三包凭证日期为准）七日内，整机出现电性能故障，您可以选择维修、换货或退货；  
2. 产品自销售之日起第八日至第十五日（以购机发票或三包凭证日期为准）；整机出现电性能故障，您可以选择维修或换货；  
3. 自您购机之日起一年内（以购机发票或三包凭证日期为准），产品如出现主要部件故障，请送至本公司授权维修机构；  
4. 自您购机之日起一年内（以购机发票或三包凭证日期为准），产品随机配备的外接设备，摄像头、各类板卡、线材、喇叭/电池等机器内部的其它部件出现故障，请送至我司授权服务机构维修；  
5. 本公司电脑服务机构只负责咨询和维修业务，退换货请您与销售商联系，退换货时请保证原机的所有附件（随机资料和其它配件）完好无缺。

二、响应时间

1. 为确保您的服务需求得到有效满足，当您的电脑出现故障时，请您首先拨打本公司电脑服务热线进行咨询和报修；

2.2小时电话响应：当接到您的报修电话时，我们的授权服务机构将在2小时内与您取得电话联系，确定维修事宜；  
3.7天x24小时服务：我司认证的授权服务机构将为您提供7天x24小时。

三、服务细则

1. 保修凭证：您的电脑在保修范围内的硬件故障时，均可凭该电脑的“电脑保修主证书”（含三包凭证）或购机发票享受我们的维修服务；  
2. 保修起始日期：通常情况下，将以您的购机发票或“电脑保修证书”标注的日期计算，若您不能提供有效的保修凭证，或购买日期超过生产日期45天，我们将以产品的生产日期加45天计算保修日期；  
3. 在保修范围内维修或更换后的产品或部件，在剩余保修期内继续享有保修，剩余保修期不足3个月的按3个月计算，但对初始保修期在1年以下的产品或部件，在上述情况下，剩余保修期不足30天的按30天计算。

温馨提示：保修条例仅例中国。

有毒、有害物质或元素情况一览

依据中国政府针对“电子信息产品污染控制管理办法”为控制减少电子信息产品废弃后对环境造成的污染，促进生产安全和销售电子信息产品，保护环境对人体健康，仅提供有关产品可能含有毒及有害物质如下：

部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Gr6+)	多溴联苯(PBB)	多溴二苯醚(PBDE)
电路板组件	×	○	×	○	○	○
金属外壳	×	○	○	×	○	○
塑料外壳	○	○	○	○	○	○
紧固件	○	○	○	×	○	○
电源	○	○	○	×	○	○
安装硬件	○	○	○	×	○	○
电缆	×	○	○	○	○	○
连接部件	×	○	○	×	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均SJ/T11363-2006标准规定的限量要求以下。  
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量。

10

此电子信息产品在说明书所诉的使用条件下使用本产品，含有的有毒有害物质或元素不致发生外泄，从而对环境造成污染或对人体、财产造成严重损害的期限为10年。  
注：除根据中华人民共和国法规的强制性规定在此作出明示声明的以外，本公司对电子信息产品环保使用期限不作任何形式的陈述或保证（无论是明示或默示），并且不对电子信息产品环保使用期限的任何陈述或保证（无论是明示或默示）承担任何责任。

温馨提示：保修条例仅例中国。

本凭证是商品三包的重要依据，请您妥善保管！

用户信息

用户姓名

联系电话

通信地址及邮编

E-mail

商品信息

产品型号

见产品后铭牌

出厂编号

见产品包装配置标

服务热线

经销商名称

地址及邮编

安装调试日期

联系电话

发货票号码

销售日期

维修记录表

送修日期

故障描述

故障处理情况

交验日期

维修人员签名

经销商盖章处：（盖章生效）

Mini PC B88M\_User manual(120\*110mm)\_En\_2023/11/16

User manual

Mini PC

Attention

- This product is suitable for non-tropical areas below 2000 meters above sea level.
- Do not put to damp places, such as bathrooms, kitchens, basements, etc.
- Ensure that the equipment is installed in a stable place to avoid the machine falling or other strong impacts.
- Store and use in a cool, dry and ventilated place, and do not close to the radiation source or heat source.
- Equipment storage temperature: -15°C~45°C
- When the device is not in use for a long time, please cut off the power to prevent damage from electric shock or abnormal power supply voltage during thunderstorms.
- Once liquid is spilled on the device, it should be shut down immediately, and the machine should be wiped and dried before use.
- Do not use any chemical detergents or liquids to wipe the machine to avoid damage caused by corrosion and moisture. If it is really necessary to clean, wipe it with a soft, dry towel.
- Do not cover or block the ventilation holes. Do not use on beds, sofas, blankets or similar surfaces.
- Please use a reliable grounding socket and do not overload the socket, otherwise it will cause fire or electric shock.
- Do not put external objects into the device, otherwise a short circuit may cause fire hazard or electric shock.
- Do not pull or twist the power cord excessively.
- Please purchase and use genuine brand memory and hard disk.
- Please keep a backup of your important data on time to avoid loss.
- Please do not disassemble the device or the warranty rights will be lost.

Plastic Packaging Safety Warning:  
Please keep plastic packaging bags out of reach of infants and children to prevent the risk of suffocation.

Product Introduction

The layout of buttons and ports

Front

Back

Left

Right

1 Power button/indicator

2 USB port

3 Ethernet cable port

4 HDMI cable port

5 Power adapter port

6 SD card slot

7 Headset and microphone port

8 Type-C port

9 Heat dissipation air outlets

Packing list

Mini PC

Power adapter

HDMI Cable

User manual

Wall-mounted brackets

Screws

Installation guide

Please prepare yourself: Wired or wireless keyboards and mouse.

Installation Steps:  
1. Connect the power adapter to the power supply;  
2. Connect the HDMI interface of the display;  
3. Connect the keyboard to the wired keyboard and mouse (the wireless keyboard can be connected after entering the system);  
4. Connect to network with a router;  
5. Press the power button to turn on the machine.

Connect a keyboard and mouse

Connect to Ethernet

Connect to power adapter

Connect to HDMI port

Wall-mounted installation procedure:

Wall-mounted brackets

1 Fix the bracket on the Mini PC with screws

2 Secure the bracket to the back of the monitor with screws

Power button and indicator status:

Power button/indicator

Power button operation  
Short press when powered off on  
Short press when powered on sleep mode

Indicator status description  
Connected to the electricity Red light on  
Press the power button Green light on

Warranty Terms

① Service scope

1. Within seven days from the date of sale of the product (based on the date of the purchase invoice), consumers can choose to repair, exchange, or return if the entire device had electrical performance malfunction;  
2. From the eighth to the fifteenth day from the date of sale of the product (based on the date of the purchase invoice), consumers can choose to repair or exchange the product if there was an electrical performance malfunction;  
3. Within one year from the date of purchase (based on the date of the purchase invoice), if there is a major component failure in the product, please send it to our authorized service agency for repair;  
4. Within one year from the date of purchase (based on the date of the purchase invoice), if the external devices, cameras, various boards, wires, speaker batteries, and other internal components of the device that are malfunctions, please send them to our authorized service agency for repair;  
5. Our computer service organization is only responsible for consulting and repairing. Please contact the seller for returns and exchanges and ensure that all accessories of the original machine are intact;

② Response time

1. To ensure the consumers' demands are effectively meet, Please call our service hotline for consultation and repair if malfunctions;

② Service Details

1. Warranty Certificate: A hardware failure is supported to maintain under the valid Warranty Certificate or purchase invoice.  
2. Warranty start date: It will be based on the date indicated on your purchase invoice or warranty certificate. The after-sales service is not supported within the warranty period shall continue to enjoy warranty for the remaining warranty period. If the repair period is less than 3 months, it will be calculated as 3 months. However, for products or components with an initial warranty period of less than 1 year, if the remaining warranty period is less than 30 days, it will be calculated as 30 days.

Kindly Remind: The warranty regulations apply to China only.

Toxic, harmful substances or elements

According to the Chinese government's "Management Measures for Pollution Control of Electronic Products", in order to control and reduce environmental pollution caused by discarded electronic products, promote the production and sale of low-polluting electronic products, and protect the environment and human health, there are some may contain toxic and harmful substances:

Component	(Pb)	(Hg)	(Cd)	(Gr6+)	(PBB)	(PBDE)
Board assembly	×	○	×	○	○	○
Metal shell	×	○	○	×	○	○
Plastic shell	○	○	○	○	○	○
Fastener	○	○	○	×	○	○
Power	○	○	○	×	○	○
Installation Hardware cable	×	○	○	×	○	○
Connection Components	×	○	○	×	○	○

○：Indicates that the above of the toxic and harmful substances in the component of the device are below the limit requirements specified in the SJ/T11363-2006 standard.  
×：Indicates that the above of the toxic and harmful substances in the component of the device exceeds the limit requirements specified in the SJ/T11363-2006 standard.

10

This product is used under the conditions stated in the manual, and the toxic and harmful substances or elements contained in it will not be leaked. The deadline for causing pollution to the environment or serious damage to people and property is 10 years.  
Note: Except as expressly stated herein in accordance with the mandatory provisions of the laws and regulations of the People's Republic of China. Our company does not make any representations or warranties of any kind and does not assume any responsibility (whether express or implied) for the environmental protection life of electronic information products.

Please keep the warranty certificate properly!

Customer

Name

Tel

Address

E-mail

Producer

Product name

Refer to nameplate

SKU

Refer to packaging label

Hotline

Distributor

Sales

Address

Installation date

Tel

Shipping number

Date of sale

Dealer's stamp: (effective with seal)

Repair records

Delivery date

Error description

Disposal situation

Date of submission

Signature of the maintainer

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co - located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and  
(2)This device must accept any interference received , including interference that may cause undesired operation.