Instruction Manual Botzee mini Screen-free Coding Robot

PDF

Product Information


Product Name: Botzees Mini Product Number: 83122 Product Material: ABS plastic Suitable Age: 3 years old and above Manufacturer: Pai Technology Ltd. Address: Building 10, Block 3, No.1016 Tianlin Road, Minhang District, Shanghai, CHINA Website: www.paibloks.com Service Number: 400 920 6161

Product List:




nstruction Card

Мар



Content of the second s



3、How to use the Instruction Card:



Note: The device will play the corresponding note sound effect immediately after it recognizes the command during line tracking.

Movement & other commands



Turn right: The device will turn right at the front intersection after recognizing this command during line-tracking



Turn left: The device will turn left at the front intersection after recognizing this command during line-tracking.



Temporary stop: The device will stop for 2 seconds as soon as it recognizes this command during line-tracking.



Stop (End point): The device will stop and play a victory sound as soon as it recognizes this command during line-tracking.



Start: The device will play the Start sound as soon as it recognizes this command during line-tracking.



Treasure: The device will record a treasure and play corresponding sound effects after it recognizes this command during line-tracking.

4、Paired with an RF device







The motor turnsThe motor turnsclockwise for 2counterclockwisesecondsfor 2 seconds

The motor turns counterclockwise

e steering

The steering gear rotates 90° clockwise The steering gear rotates 90° counterclockwise



The recording module plays sound.



The light module lights up/goes out.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

1. The battery is not replaceable .

It shall be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

The toy is not to be connected to more than the recommended number of power supplies.

5. Rechargeable batteries are only to be charged under adult supervision.

FCC ID: 2APRA83004

